

Next Generation Firewall

Installation Guide

6.2

Revision A

© 2017 Forcepoint

Forcepoint and the FORCEPOINT logo are trademarks of Forcepoint.

Raytheon is a registered trademark of Raytheon Company.

All other trademarks used in this document are the property of their respective owners.

Published 2017

This document may not, in whole or in part, be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form without prior consent in writing from Forcepoint. Every effort has been made to ensure the accuracy of this manual. However, Forcepoint makes no warranties with respect to this documentation and disclaims any implied warranties of merchantability and fitness for a particular purpose. Forcepoint shall not be liable for any error or for incidental or consequential damages in connection with the furnishing, performance, or use of this manual or the examples herein. The information in this documentation is subject to change without notice.

Table of contents

Pretace	
Introduction to the Forcepoint Next Generation Firewall solution	(
1 Introduction to Forcepoint NGFW	1
Components in the Forcepoint NGFW solution	
Security Management Center (SMC)	12
NGFW Engines	12
2 Preparing for installation	1
Supported platforms	
Clustering	
Deployment options for Forcepoint NGFW in the IPS and Layer 2 Firewall roles	18
Cable connection guidelines	
Speed and duplex settings for NGFW Engines	
Obtain installation files	
Licensing Forcepoint NGFW components	
Installation overview	2
Security Management Center (SMC) deployment	29
3 Installing the SMC	
SMC installation options	
Install SMC components Install the SMC in Demo Mode	
Install the SMC from the command line	
Install the SMC Appliance	
Start the SMC after installation	
Post-installation SMC configurations	
4 Configuring the SMC	5.
Configuring NAT addresses for SMC components	
Add Management Servers for high availability	
Distribute Management Clients through Web Start	
Forcepoint NGFW deployment	63
5 Configuring Forcepoint NGFW for the Firewall/VPN role	6
Install licenses for NGFW Engines	
Configuring Single Firewalls	66
Configuring Firewall Clusters	82
6 Configuring Forcepoint NGFW for the IPS role	9
Install licenses for NGFW Engines	
Configuring IPS engines	
Bind engine licenses to IPS elements	107

	7 Configuring Forcepoint NGFW for the Layer 2 Firewall role	
	Install licenses for NGFW Engines	109
	Configuring Layer 2 Firewalls	
	Bind engine licenses to Layer 2 Firewall elements	122
	8 Configuring NGFW Engines as Master NGFW Engines and Virtual NGFW Engines	123
	Master NGFW Engine and Virtual NGFW Engine configuration overview	
	Install licenses for NGFW Engines	
	Add Master NGFW Engine elements	
	Add Virtual Firewall elements	132
	Add Virtual IPS elements	137
	Add Virtual Layer 2 Firewall elements	139
	9 Configuring Forcepoint NGFW software	143
	Options for initial configuration	143
	Using plug-and-play configuration	144
	Using automatic configuration	
	Configure Forcepoint NGFW software using the NGFW Initial Configuration Wizard	149
	10 NGFW Engine post-installation tasks	163
	Configuring routing and basic policies	163
	Monitor and command NGFW Engines	172
Ma	intenance	173
	44 Maintaining the CMC	471
	11 Maintaining the SMC	
	Upgrading the SMCUninstall the SMC	
	12 Upgrading NGFW Engines	
	How engine upgrades work	
	Obtain NGFW Engine upgrade files	
	Prepare NGFW Engine upgrade files	
	Upgrading or generating licenses for NGFW Engines	
	Upgrade engines remotely	
	Upgrade engines locally	190
Ap	pendices	193
	A Default communication ports	19
	Security Management Center ports	195
	Forcepoint NGFW Engine ports	198
	B Command line tools	203
	Security Management Center commands	
	Forcepoint NGFW Engine commands	216
	Server Pool Monitoring Agent commands	222
	C Installing SMC Appliance software on a virtualization platform	225
	Hardware requirements for installing SMC Appliance software on a virtualization platform	
	Install SMC Appliance software using an .iso file	
	D Installing Forcepoint NGFW on a virtualization platform	227
	· · · · · · · · · · · · · · · · · · ·	

	Hardware requirements for installing Forcepoint NGFW software on a virtualization platform	227
	Install Forcepoint NGFW software using an .iso file	228
E Inst	talling Forcepoint NGFW software on third-party hardware	229
	Hardware requirements for installing Forcepoint NGFW on third-party hardware	229
	Start the Forcepoint NGFW installation on third-party hardware	234
	Install Forcepoint NGFW in expert mode	235
F Exa	mple network (Firewall/VPN)	239
	Example Firewall Cluster	239
	Example Single Firewall	242
	Example headquarters management network	243
G Exa	ample network (IPS)	245
	Example network overview (IPS)	245
	Example headquarters intranet network	247
	HQ IPS Cluster	247
	Example headquarters DMZ network	248
H Clu	ster installation worksheet instructions	249
	Cluster installation worksheet	249



Preface

This guide provides the information you need to work with your Forcepoint product.

Conventions

This guide uses these typographical conventions and icons.

Book title, term, emphasis	Title of a book, chapter, or topic; a new term; emphasis.
Bold	Text that is strongly emphasized.
User input, code, message	Commands and other text that the user types; a code sample; a displayed message.
Interface text	Words from the product interface like options, menus, buttons, and dialog boxes.
Hypertext	A link to a topic or to an external website.
	Note: Additional information, like an alternate method of accessing an option.
	Tip: Suggestions and recommendations.
A	Important/Caution: Valuable advice to protect your computer system, software installation, network, business, or data.
•	Warning: Critical advice to prevent bodily harm when using a hardware product.

Find product documentation

On the Forcepoint support website, you can find information about a released product, including product documentation, technical articles, and more.

You can get additional information and support for your product on the Forcepoint support website at https://support.forcepoint.com. There, you can access product documentation, Knowledge Base articles, downloads, cases, and contact information.





Introduction to the Forcepoint Next Generation Firewall solution

Contents

- Introduction to Forcepoint NGFW on page 11
- Preparing for installation on page 15

Before setting up Forcepoint[™] Next Generation Firewall (Forcepoint NGFW), it is useful to know what the different components do and what engine roles are available. There are also tasks that you must complete to prepare for installation. Forcepoint NGFW was formerly known as Stonesoft[®] Next Generation Firewall by Forcepoint (Stonesoft NGFW).

■ Forcepoint Next Generation Firewall 6.2 Installation Guide

CHAPTER 1

Introduction to Forcepoint NGFW


Contents

- Components in the Forcepoint NGFW solution on page 11
- Security Management Center (SMC) on page 12
- NGFW Engines on page 12

The Forcepoint Next Generation Firewall solution consists of Forcepoint NGFW Engines and the Forcepoint™ NGFW Security Management Center (SMC), formerly known as Stonesoft® Management Center by Forcepoint (SMC). The SMC is the management component of the Forcepoint NGFW solution.

Components in the Forcepoint NGFW solution

The Forcepoint NGFW solution includes NGFW Engines, SMC server components, and SMC user interface components.



Number	Component	Description	
1	Management Client	The Management Client is the user interface for the SMC. You use the Management Client for all configuration and monitoring tasks. You can install the Management Client locally as an application, or you can start the Management Client with a web browser using the Java Web Start feature. You can install an unlimited number of Management Clients.	
2	Web Portal	The Web Portal is the browser-based user interface for the services provided by the Web Portal Server.	
3	Management Server	The Management Server is the central component for system administration. One Management Server can manage many different types of engines.	
4	Log Server	Log Servers store traffic logs that can be managed and compiled into reports. Log Servers also correlate events, monitor the status of engines, show real-time statistics, and forward logs to third-party devices.	
5	Web Portal Server	The Web Portal Server is a separately licensed optional component that provides restricted access to log data, reports, and policy snapshots.	
6	NGFW Engines	NGFW Engines inspect traffic. You can use NGFW Engines in the Firewall/VPN, IPS, or Layer 2 Firewall role.	

Security Management Center (SMC)

The basic SMC components are the Management Server, Log Server, and one or more Management Clients.

The Management Client is the user interface for the SMC. You can use the same SMC installation to manage multiple NGFW Engines in different roles.

The SMC can optionally include multiple Management Servers, multiple Log Servers, and multiple Web Portal Servers. Your licenses specify the type and number of optional components and engines that your environment can include. You can install the SMC components separately on different computers or on the same computer, depending on your performance requirements. The SMC all-in-one appliance is shipped with the Management Server and a Log Server pre-installed on it.

NGFW Engines

You can use NGFW Engines in the Firewall/VPN, IPS, and Layer 2 Firewall roles. You can also use NGFW Engines as Master NGFW Engines to host Virtual NGFW Engines in these roles.

NGFW Engines are represented by different types of NGFW Engine elements in the SMC. The following elements represent NGFW Engines in the SMC:

Engine Role	Elements
Firewall/VPN	Single Firewall elements represent firewalls that consist of one physical device.
	Firewall Cluster elements consist of 2–16 physical firewall devices that work together as a single entity.
	Virtual Firewall elements are Virtual NGFW Engines in the Firewall/VPN role.

Engine Role	Elements	
IPS	Single IPS elements represent IPS engines that consist of one physical IPS device.	
	IPS Cluster elements combine 2–16 physical IPS devices into a single entity.	
	Virtual IPS elements are Virtual NGFW Engines in the IPS role.	
Layer 2 Firewall	Single Layer 2 Firewall elements represent Layer 2 Firewalls that consist of one physical device.	
	Layer 2 Firewall Cluster elements combine 2–16 physical Layer 2 Firewall devices into a single entity.	
	Virtual Layer 2 Firewall elements are Virtual NGFW Engines in the Layer 2 Firewall role.	
Master NGFW Engine	Master NGFW Engine elements represent physical devices that host Virtual NGFW Engines.	

These elements are containers for the main configuration information directly related to the NGFW Engines.

Forcepoint NGFW in the Firewall/VPN role

In addition to standard firewall features, Forcepoint NGFW in the Firewall/VPN role provides several advanced features.

The main features of Forcepoint NGFW in the Firewall/VPN role include:

- Advanced traffic inspection Multi-Layer packet and connection verification process provides maximum security without compromising system throughput. An anti-malware scanner, and anti-spam and web filtering complement the standard traffic inspection features when the firewall is licensed for the UTM (unified threat management) feature. Anti-malware and anti-spam are not supported on Virtual Firewalls. Master NGFW Engines do not directly inspect traffic.
- Built-in load balancing and high availability The clustering of the firewall nodes is integrated. The firewall dynamically load-balances individual connections between the cluster nodes.
- Multi-Link technology Multi-Link allows configuring redundant network connections without the more complex traditional solutions that require redundant external routers and switches. It provides high availability for inbound, outbound, and VPN connections.
- QoS and bandwidth management You can set up the minimum and maximum bandwidth value and the priority value for different types of traffic.
- Virtual private networks The firewall provides fast, secure, and reliable VPN connections with the added benefits of the clustering and Multi-Link technologies. These features provide load balancing and failover between ISPs and VPN gateways.
- Unified SMC and integration with other NGFW Engines You can configure and monitor the Firewall/ VPN and the other NGFW Engines through the same SMC and the same user interface. The SMC provides extensive reporting tools for generating statistical reports based on logs, alerts, and operating statistics.

Forcepoint NGFW in the IPS and Layer 2 Firewall roles

IPS engines and Layer 2 Firewalls pick up network traffic, inspect it, and create event data for further processing by the Log Server.

The main features of Forcepoint NGFW in the IPS and Layer 2 Firewall roles include:

- Multiple detection methods Misuse detection uses fingerprints to detect known attacks. Anomaly detection uses traffic statistics to detect unusual network behavior. Protocol validation identifies violations of the defined protocol for a particular type of traffic. Event correlation processes event information to detect a pattern of events that might indicate an intrusion attempt.
- Response mechanisms There are several response mechanisms to anomalous traffic. These include different alerting channels, traffic recording, TCP connection termination, traffic blacklisting, and traffic blocking with Inline Interfaces.
- Unified SMC and integration with other NGFW Engines The IPS engines, Layer 2 Firewalls, Master NGFW Engines, Virtual IPS engines, and Virtual Layer 2 Firewalls are managed centrally through the SMC. The SMC provides extensive reporting tools for generating statistical reports based on logs, alerts, and operating statistics.

Master NGFW Engines and Virtual NGFW **Engines**

Master NGFW Engines are physical devices that provide resources for multiple Virtual NGFW Engines.

Any NGFW Engine that has a license that allows the creation of Virtual Resources can be used as a Master NGFW Engine. Virtual NGFW Engines are represented by the following elements in the SMC:

- Virtual Firewall is a Virtual NGFW Engine in the Firewall/VPN role.
- Virtual IPS engine is a Virtual NGFW Engine in the IPS role.
- Virtual Layer 2 Firewall is a Virtual NGFW Engine in the Layer 2 Firewall role.

Each Master NGFW Engine can only host one Virtual NGFW Engine role. To use more than one Virtual NGFW Engine role, you must create a separate Master NGFW Engine for each Virtual NGFW Engine role. Each Master NGFW Engine must be on a separate physical Master NGFW Engine device.

CHAPTER 2

Preparing for installation

Contents

- Supported platforms on page 15
- Clustering on page 17
- Deployment options for Forcepoint NGFW in the IPS and Layer 2 Firewall roles on page 18
- Cable connection guidelines on page 20
- Speed and duplex settings for NGFW Engines on page 23
- Obtain installation files on page 24
- Licensing Forcepoint NGFW components on page 26
- Installation overview on page 27

Before installing Forcepoint NGFW, identify the components of your installation and how they integrate into your environment.

Supported platforms

Several platforms are supported for deploying Forcepoint NGFW and SMC components.

Supported platforms for SMC deployment

SMC server components can be installed on third-party hardware or they are available as a dedicated Forcepoint™ NGFW Security Management Center Appliance (SMC Appliance).

Third-party hardware



CAUTION: Do not install the SMC components on the Forcepoint NGFW hardware.

- You can install the SMC on third-party hardware that meets the hardware requirements. The hardware requirements can be found at https://support.forcepoint.com.
- You can install all SMC server components on the same computer, or install separate components on different computers.
- In a large or geographically distributed deployment, we recommend installing the Management Server, Log Server, and optional Web Portal Server on separate computers.

SMC Appliance

The Management Server and a Log Server are integrated with the hardware operating system as a dedicated server appliance.

Management Client

Although the Web Start distribution of the Management Client is certified to run only on the listed official platforms, it can run on other platforms. These platforms include Mac OS X and additional Linux distributions with JRE (Java Runtime Environment) installed.

Supported platforms for Forcepoint NGFW deployment

You can run NGFW Engines on various platforms.

The following general types of platforms are available for NGFW Engines:

Purpose-built Forcepoint NGFW appliances



Note: For information about supported appliance models, see Knowledge Base article 9743.

- The VMware ESX and KVM virtualization platforms are officially supported.
- Amazon Web Services (AWS) cloud (Firewall/VPN role only)
- Third-party hardware that meets the hardware requirements

The NGFW Engine software includes an integrated, hardened Linux operating system. The operating system eliminates the need for separate installation, configuration, and patching.

Deploying NGFW Engines in the Amazon Web Services cloud

You can deploy NGFW Engines in the Amazon Web Services (AWS) cloud to provide VPN connectivity, access control, and inspection for services in the AWS cloud.

When you deploy NGFW Engines in the AWS cloud, only the Firewall/VPN role is supported. Firewall Clusters, Master NGFW Engines, and Virtual Firewalls are not supported.

For deployment instructions and supported features, see Knowledge Base article 10156. After deployment, you can manage NGFW Engines in the AWS cloud using the Management Client in the same way as other NGFW Engines.

Two licensing models are supported for Forcepoint NGFW in the AWS cloud. There are two engine images, depending on the licensing model:

- Bring Your Own License You pay only Amazon's standard runtime fee for the engine instance. You must install a license for the engine in the SMC.
- Hourly (pay as you go license) You pay Amazon's standard runtime fee for the engine instance plus an hourly license fee based on the runtime of the engine. No license installation is needed for the engine in the SMC.



Note: In Forcepoint NGFW versions 6.1 and 6.2, only the Bring Your Own License image is available.

The SMC automatically detects which platform the engine image is running on for features that require separate licenses.

Running NGFW Engines as Master NGFW **Engines**

There are some hardware requirements and configuration limitations when you use an NGFW Engine as a Master NGFW Engine.

Running the NGFW Engine as a Master NGFW Engine does not require a third-party virtualization platform. When you run Forcepoint NGFW as a Master NGFW Engine, the Forcepoint NGFW hardware provides the virtual environment and resources for the hosted Virtual NGFW Engines. You must always install the Forcepoint NGFW software on a hardware device to run the NGFW Engine as a Master NGFW Engine.

You can run Master NGFW Engines on the following types of hardware platforms:

- Purpose-built Forcepoint NGFW appliances with 64-bit architecture
- Third-party hardware with 64-bit architecture that meets the hardware requirements

The following requirements and limitations apply when you use an NGFW Engine as a Master NGFW Engine:

- Each Master NGFW Engine must run on a separate 64-bit physical device.
- All Virtual NGFW Engines hosted by a Master NGFW Engine or Master NGFW Engine cluster must have the same role and the same Failure Mode (fail-open or fail-close).
- Master NGFW Engines can allocate VLANs or interfaces to Virtual NGFW Engines. If the Failure Mode of the Virtual IPS engines or Virtual Layer 2 Firewalls is Normal (fail-close) and you want to allocate VLANs to several engines, you must use the Master NGFW Engine cluster in standby mode.

Related concepts

Hardware requirements for installing Forcepoint NGFW on third-party hardware on page 229

Clustering

There are special considerations when you deploy an NGFW Engine as a Firewall Cluster, IPS Cluster, or Layer 2 Firewall Cluster.

Heartbeat connection and state synchronization for clusters

The nodes in a cluster use a heartbeat connection to monitor the other nodes' operation and to synchronize their state tables.

The nodes in a cluster exchange status information through a heartbeat network using multicast transmissions. If a node becomes unavailable, the other nodes of the cluster immediately notice the change, and connections

are reallocated to the available nodes. A dedicated network is recommended for at least the primary heartbeat communications.

The heartbeat connection is essential for the operation of the cluster. Make sure that these conditions are true:

- The heartbeat network works correctly and reliably.
- You are using the correct type of network cables (after testing that they work).
- The network interface cards' duplex and speed settings match.
- Any network devices between the nodes are correctly configured.

It is possible to authenticate and encrypt the heartbeat traffic.

Problems in the heartbeat network might seriously degrade the performance and operation of the cluster.

In the Firewall/VPN role, the nodes of a Firewall Cluster periodically exchange synchronization messages to synchronize state data.

Hardware for Firewall Cluster nodes

You can run different nodes of the same cluster on different types of hardware.

The hardware the cluster nodes run on does not need to be identical. Different types of equipment can be used as long as all nodes have enough network interfaces for your configuration. Firewall Clusters can run on a Forcepoint NGFW appliance, on a standard server with an Intel-compatible processor, or as a virtual machine on a virtualization platform.

If equipment with different performance characteristics is clustered together, the load-balancing technology automatically distributes the load so that lower performance nodes handle less traffic than the higher performance nodes. However, when a node goes offline, the remaining nodes must be able to handle all traffic on their own to ensure High Availability. For this reason, it is usually best to cluster nodes with similar performance characteristics.

Deployment options for Forcepoint NGFW in the IPS and Layer 2 Firewall roles

There are several ways to deploy Forcepoint NGFW in the IPS and Layer 2 Firewall roles depending on how you want to inspect and respond to traffic.

Table 1: Forcepoint NGFW in the IPS and Layer 2 Firewall roles

Forcepoint NGFW role	Mode	Description
IPS	Inline	In an Inline installation, the traffic flows through the IPS engine. The IPS engine has full control over the traffic flow and can automatically block any traffic. An inline IPS engine can also enforce blacklisting commands from other components. Fail-open network cards can ensure that traffic flow is not disrupted when the IPS engine is offline. An inline IPS engine also provides access control and logging for any Ethernet traffic (layer 2).

Forcepoint NGFW role	Mode	Description
	Capture	In a Capture installation, external equipment duplicates the traffic flow for inspection, and the IPS engine passively monitors traffic. The IPS engine does not have direct control over the traffic flow, but it can respond to selected threats by sending packets that reset the connections. An IDS-only IPS engine can send blacklisting requests to other IPS engines, Layer 2 Firewalls, or Firewalls, but it cannot enforce blacklisting requests from other components.
Layer 2 Firewall	Inline	In an Inline installation, the traffic flows through the Layer 2 Firewall. The Layer 2 Firewall has full control over the traffic flow and can automatically block any traffic. An inline Layer 2 Firewall can also enforce blacklisting commands received from other components. An inline Layer 2 Firewall also provides access control and logging for any Ethernet traffic (layer 2).
	Capture (Passive Firewall)	In a Capture (Passive Firewall) installation, external equipment duplicates the traffic flow for inspection to the Layer 2 Firewall, and the Layer 2 Firewall passively monitors traffic.
		The Layer 2 Firewall does not have direct control over the traffic flow, but it can respond to selected threats by sending packets that reset the connections. A Layer 2 Firewall in Passive Firewall mode can send blacklisting requests to other Layer 2 Firewalls, IPS engines, or Firewalls. It cannot enforce blacklisting requests from other components.
	Passive Inline	In a Passive Inline installation, the traffic flows through the Layer 2 Firewall, but the Layer 2 Firewall only logs connections. A Layer 2 Firewall in Passive inline mode can send blacklisting requests to other Layer 2 Firewalls, IPS engines, or Firewalls. It cannot enforce blacklisting requests from other components.

You can connect Capture Interfaces on an IPS engine or a Layer 2 Firewall to a Switched Port Analyzer (SPAN) port or a network Test Access Port (TAP) to capture network traffic.

A SPAN port captures network traffic to a defined port on an external switch. This action is also known as port mirroring. The capturing is passive, so it does not interfere with the traffic. All traffic to be monitored must be copied to this SPAN port.

A network TAP is a passive device at the network wire between network devices. The capturing is done passively, so it does not interfere with the traffic. With a network TAP, the two directions of the network traffic are divided to separate wires. For this reason, the IPS engine or Layer 2 Firewall needs two capture interfaces for a network TAP; one capture interface for each direction of the traffic. The two related capture interfaces must have the same logical interface that combines the traffic of these two interfaces for inspection. You could also use the pair of capture interfaces to monitor traffic in two separate network devices.

Cable connection guidelines

Follow these cable connection guidelines when connecting cables to Forcepoint NGFW hardware and the SMC Appliance.

Cable connection guidelines for SMC **Appliance**

For an SMC Appliance, make sure that all copper cables are correctly rated (CAT 5e or CAT 6 in gigabit networks).

Cable connection guidelines for Firewalls

The cabling of Firewalls depends on the engine type and the installation.

Make sure that all copper cables are correctly rated (CAT 5e or CAT 6 in gigabit networks).

If you have a two-node Firewall Cluster, it is recommended to use a crossover cable without any intermediary devices between the nodes. If you use an external switch between the nodes, follow these guidelines:

- Make sure that portfast is enabled on the external switches.
- Make sure that the speed/duplex settings of the external switches and the Firewall devices are set to Auto.
- Configure the external switches to forward multicast traffic.

Cable connection guidelines for IPS and Layer 2 Firewalls

The cabling of IPS engines and Layer 2 Firewalls depends on the engine type and the installation.

Make sure that all copper cables are correctly rated (CAT 5e or CAT 6 in gigabit networks).


Follow standard cable connections with inline IPS engines and Layer 2 Firewalls:


- Use straight cables to connect the IPS engines and Layer 2 Firewalls to external switches.
- Use crossover cables to connect the IPS engines and Layer 2 Firewalls to hosts (such as routers or Firewalls).





Note: Fail-open network interface cards support Auto-MDIX, so both crossover and straight cables might work when the IPS engine is online. However, only the correct type of cable allows traffic to flow when the IPS engine is offline and the fail-open network interface card is in bypass state. It is recommended to test the IPS deployment in offline state to make sure that the correct cables are used.


Cable connections for Master NGFW Engines that host Virtual IPS engines or Virtual Layer 2 Firewalls follow the same principles as the connections for inline IPS engines and Layer 2 Firewalls.












Speed and duplex settings for NGFW **Engines**

Mismatched speed and duplex settings are a frequent source of networking problems.

The basic principle for speed and duplex settings is that network cards at both ends of each cable must have identical settings. This principle also applies to the automatic negotiation setting: if one end of the cable is set to auto-negotiate, the other end must also be set to auto-negotiate and not to any fixed setting. Gigabit standards require interfaces to use auto-negotiation. Fixed settings are not allowed at gigabit speeds.

For Inline Interfaces, the settings must be identical on both links within each Inline Interface pair. Use identical settings on all four interfaces, instead of just matching settings at both ends of each cable (two + two interfaces). If one of the links has a lower maximum speed than the other link, the higher-speed link must be set to use the lower speed.



Obtain installation files

If you did not receive an installation DVD for the Forcepoint NGFW software or the SMC, download installation files.

You do not have to download installation files under these circumstances:

- Forcepoint NGFW appliances and the SMC Appliance are delivered with the necessary software pre-installed on them. You do not need to download installation files for these appliances.
- You might have received ready-made installation DVDs of the Forcepoint NGFW software and the SMC software.

Download installation files

Download the files you need to install the Forcepoint NGFW software and the SMC components.

Installation files for the SMC components are available only as .zip files. Installation files for the Forcepoint NGFW software are available as .zip files or .iso image files.

Steps

- Go to https://support.forcepoint.com.
- Enter your license code or log on using an existing user account.
- Select Downloads.

- 4) Under Network Security, click the version of the SMC software that you want to download, then download the .zip file installation file.
- 5) Under Network Security, click the version of the Forcepoint NGFW software that you want to download, then select the type of installation file to download.
 - The .zip file is used in the remote upgrade on all supported platforms. It can also be used for a local upgrade from a USB drive or a non-bootable DVD.
 - The .iso file allows you to create a bootable installation DVD for a local upgrade on platforms that have an optical drive.

Check file integrity

Before installing the Forcepoint NGFW software from downloaded files, check that the installation files have not become corrupt or been changed.

Using corrupt files might cause problems at any stage of the installation and use of the system. Check file integrity by generating a file checksum of the files. Compare the checksum of the downloaded files with the checksum for the software version in the Release Notes or on the download page at the Forcepoint website.



Note: Windows does not have checksum tools by default, but there are several third-party programs available.

Steps

- 1) Look up the correct checksum at https://support.forcepoint.com.
- Change to the directory that contains the files to be checked.
- Generate a checksum of the file using one of the following commands, where filename is the name of the installation file:
 - shalsum filename
 - sha256sum filename
 - sha512sum filename
- Compare the displayed output to the checksum for the software version. They must match.



CAUTION: Do not use files that have invalid checksums. If downloading the files again does not help, contact Forcepoint support to resolve the issue.

Next steps

If you downloaded the installation files as a .zip file, unzip the contents at the installation location and install the licenses.

Create an installation DVD for Forcepoint **NGFW** software

To use the installation DVD successfully, it must have the correct structure stored in the .iso images. Otherwise you cannot use it for installing the Forcepoint NGFW software.

Steps

1) Use a DVD burning application that can correctly read and burn the DVD structure stored in the .iso image for the Forcepoint NGFW software.

For instructions, see the documentation that came with your application.

Licensing Forcepoint NGFW components

Generate and download a license for each SMC server and NGFW Engine node before you start installing the Forcepoint NGFW.

You install the SMC server license when you start the SMC after installation. You install the NGFW Engine licenses when you start configuring the NGFW Engines.

Types of licenses for NGFW Engines

Each NGFW Engine node must have its own license.

- Some engines use an NGFW Engine Node license. Other engines use role-specific licenses. The correct type of license for each engine is generated based on your Management Server proof-of-license (POL) code or the appliance proof-of-serial (POS) code.
- Virtual NGFW Engines do not require a separate license. However, the Master NGFW Engine license limits the number of Virtual Resources that can be created. The limit for the number of Virtual Resources limits how many Virtual NGFW Engines can be created.
- The Management Server's license might be limited to managing only a specific number of NGFW Engines.
- Forcepoint NGFW Engines deployed in the AWS cloud with the Bring Your Own License image must have a license in the SMC. Forcepoint NGFW Engines deployed in the AWS cloud with the Hourly (pay as you go) image do not require a separate license in the SMC.

Future engine licenses can be downloaded and installed automatically after the NGFW Engines and the SMC are fully installed. For more information about automatic downloading and installation of licenses, see the Forcepoint Next Generation Firewall Product Guide.

If there is no connection between the Management Server and the License Center, the appliance can be used without a license for 30 days. After this time, you must generate the licenses manually at the License Center webpage and install them using the Management Client.

Obtain license files

Generate the licenses based on your Management Server proof-of-license (POL) code or the appliance proof-of-serial-number (POS) code.

If you are licensing several components of the same type, remember to generate a license for each component.

Evaluation licenses are also available. Evaluation license requests might need manual processing. See the license page for current delivery times and details.

All licenses include the latest version for which they are valid. Automatic upgrade and installation of licenses is enabled by default. If you have disabled automatic license upgrades, you must upgrade the licenses when you upgrade to a new major release of the software.

Steps

- 1) Go to the License Center at https://stonesoftlicenses.forcepoint.com.
- 2) In the License Identification field, enter the required code (POL or POS) and click Submit.
 - The proof-of-license (POL) code identifies a license. Later on, this information is shown in the **Administration** > **Licenses** branch of the **Configuration** view in the Management Client.
 - Forcepoint NGFW appliances also have a proof-of-serial number (POS) that you can find on a label attached to the appliance hardware.

The license page opens.

3) Check which components are listed as included in this license. Click Register.



Tip: POS binding is always recommended when the option is available.

The license generation page opens.

4) Enter the Management Server's POL code or the appliance POS code for the engines you want to license.



Tip: POS binding is always recommended when the option is available.

5) Click Submit Request.

The license file is available for download on the license page.

Related tasks

Install licenses for SMC servers on page 50 Install licenses for NGFW Engines on page 65

Installation overview

The process of installing Forcepoint NGFW consists of several high-level steps.

1) Install and configure the Security Management Center and a Management Client.

- (Optional) Set up Management Client distribution through Java Web Start for automatic installation and upgrade.
- If network address translation (NAT) is applied to communications between system components, define contact addresses.
- Configure and install the NGFW Engines.
 - Download and install licenses for the NGFW Engines.
 - Define the Firewall, IPS, and Layer 2 Firewall elements in the Management Client.
 - (Optional) Define Master NGFW Engine and Virtual Firewall, Virtual IPS, and Virtual Layer 2 Firewall elements in the Management Client.
 - d) Generate the initial configuration for the Firewalls, IPS engines, Layer 2 Firewalls, or Master NGFW Engines. No initial configuration is needed for Virtual Firewalls, Virtual IPS engines, or Virtual Layer 2 Firewalls.
 - e) On virtualization platforms or third-party hardware, install the Forcepoint NGFW software.
 - Configure the Forcepoint NGFW software. No software configuration is needed for Virtual Firewalls, Virtual IPS engines, or Virtual Layer 2 Firewalls.
 - Configure basic routing and install a policy on the engines.

Related tasks

Install licenses for NGFW Engines on page 65 Add Management Servers for high availability on page 58



Security Management Center (SMC) deployment

Contents

- Installing the SMC on page 31
- Configuring the SMC on page 55

SMC is the management component of the Forcepoint NGFW system. SMC must be installed and running before you can deploy the Forcepoint NGFW engines.

■ Forcepoint Next Generation Firewall 6.2 Installation Guide	

CHAPTER 3

Installing the SMC

Contents

- SMC installation options on page 31
- Install SMC components on page 34
- Install the SMC in Demo Mode on page 40
- Install the SMC from the command line on page 42
- Install the SMC Appliance on page 47
- Start the SMC after installation on page 48
- Post-installation SMC configurations on page 53

The SMC is the management component of the Forcepoint NGFW solution. The SMC manages and controls the other components in the system. You must install the SMC before you can install Forcepoint NGFW Engines.

SMC installation options

You can install SMC server components on your own hardware or use an all-in-one SMC Appliance.



CAUTION: Make sure that the operating system version you plan to install on is supported. The supported operating systems for running the SMC are listed in the Security Management Center Release Notes.

There are several ways to install the SMC server components for production use:

(Recommended) You can install the SMC server components using the Installation Wizard.



Tip: To evaluate the Forcepoint Next Generation Firewall system in a simulated network environment, you can install the SMC in demo mode.

• In Linux, you can install the SMC server components from the command line.



Note: You need a graphical environment to use the Management Client. Only the SMC server components can be run in a command line-only environment.

• The Management Server and a default Log Server are pre-installed on the SMC Appliance. When you start the appliance, the installation wizard includes the configuration of these components.

During the installation, certificates can be generated for the SMC server components. The certificates are needed for authentication in establishing the secure encrypted communication channel between system components.

After the installation, you can install more Management Clients on other computers.

- You can install them locally by running the Security Management Center installer.
- You can make them available through Java Web Start.
 Making the Management Client available through Java Web Start eliminates the need to update all Management Clients individually at each version upgrade. The Management Client has no configurable parameters. The SMC Appliance has Java Web Start enabled by default.



Note: For third-party hardware, we recommend installing a Management Client on the same computer as the Management Server.

Related tasks

Install the SMC in Demo Mode on page 40
Install the SMC from the command line on page 42

Requirements for running SMC on third-party hardware

There are some minimum requirements and recommendations when you run the SMC on third-party hardware.

The following are the minimum requirements for a basic SMC:

- Intel® Core™ family processor or higher recommended, or equivalent on a non-Intel platform
- A mouse or pointing device (for the Management Client only)
- SVGA (1024x768) monitor or higher (for the Management Client only)
- Disk space for the Management Server: 6 GB
- Disk space for the Log Server: 50 GB
- Memory requirements for 64-bit operating systems:
 - 6 GB RAM for the Management Server, Log Server, or Web Portal Server (8 GB if all servers are installed on the same computer)
 - 2 GB RAM for the Management Client
- Memory requirements for 32-bit Linux operating systems:
 - 2 GB RAM for the Management Server, Log Server, or Web Portal Server (3 GB if all servers are installed on the same computer)
 - 1 GB RAM for the Management Client

More information about hardware requirements can be found at https://support.forcepoint.com.

Security considerations for SMC deployment

The information stored in the Security Management Center (SMC) is highly valuable to anyone conducting or planning malicious activities in your network. Someone who gains administrator rights to the Management Server can change the configurations.

An attacker can gain access by exploiting operating system weaknesses or other services running on the same computer to gain administrator rights in the operating system.



Important: Secure the Management Server computer. Anyone who has administrator rights to the operating system can potentially view and change any SMC configurations.

Consider at least the following points to secure the Management Server and Log Server:

- Prevent any unauthorized access to the servers. Restrict access to the minimum required both physically and with operating system user accounts.
- We recommend allowing access only to the required ports.

- Never allow Management Client connections from insecure networks.
- Take all necessary steps to keep the operating system secure and up to date.
- We recommend that you do not run any third-party server software on the same computer with the SMC servers.
- We recommend placing the servers in a separate, secure network segment without third-party servers and limited network access.

You can optionally use 256-bit encryption for the connection between NGFW Engines and the Management Server. 256-bit encryption requires both the engines and the Management Server to be version 5.5 or later. You must also use an Internal ECDSA Certificate Authority to sign certificates for SMC communication.

Related information

Forcepoint NGFW Engine ports on page 198 Security Management Center ports on page 195

Basic system settings for the SMC components

Check these operating system settings on the computers that you use as a platform for the SMC components.

Date and time settings for SMC components

Make sure that the date, time, and time zone settings are correct on any computer that you use as a platform for any SMC component, including the Management Client workstations. The time settings of the NGFW Engines do not need to be adjusted, as they are automatically synchronized with the Management Server's time setting. For this operation, the time is converted to UTC time according to the Management Server's time zone setting. The SMC always uses UTC internally.

Hosts file for SMC servers

Due to a restriction of the Java platform, the Management Server and Log Server host names must be resolvable on the computer running the Management Client. This restriction applies even if the Management Client is running on the same computer as the servers.

To guarantee that the host names can be resolved, add the IP address and host name pairs to the local hosts file on the client computer:

- In Windows: \%SystemRoot%\system32\drivers\etc\hosts
- In Linux: /etc/hosts

Installing on Linux

The installation creates sgadmin user and group accounts.

If there is a pre-existing sgadmin account, the installation fails. All shell scripts belong to sgadmin and are executed either by root or the sgadmin user. The shell scripts are executed with sgadmin rights. After the installation, the sgadmin account is disabled. The sgadmin account is deleted at uninstallation.

SMC installation overview

The process of installing SMC consists of several high-level steps.

1) Install the SMC components or start the SMC Appliance.



Note: If you are installing components on separate computers, install the Management Server first.

- 2) Start the SMC.
- Install licenses for SMC servers.
- 4) (Optional) Install additional Management Servers.

Install SMC components

You can install the SMC in a user interface in Windows and Linux.



Note: For the all-in-one appliance, see Install the SMC Appliance.

Related tasks

Obtain installation files on page 24
Install the SMC from the command line on page 42
Install the SMC Appliance on page 47

Start the SMC installation

Start the Installation Wizard to install the Security Management Center components.

Steps

- Log on to the system where you are installing the SMC with the correct administrator rights.
 - In Windows, log on with administrator rights.
 - In Linux, log on as root.

- 2) Start the installation in one of the following ways:
 - From a .zip file Unzip the file and run setup.exe on Windows or setup.sh on Linux.
 - From a DVD Insert the installation DVD and run the setup executable from the DVD.

Operating system	Path to executable	
Windows 64-bit	Forcepoint_SMC_Installer\Windows-x64\setup.exe	
Linux 32-bit	/Forcepoint_SMC_Installer/Linux/setup.sh	
Linux 64-bit /Forcepoint_SMC_Installer/Linux-x64/setup.sh		



Tip: If the DVD is not automatically mounted in Linux, mount the DVD with mount /dev/cdrom /mnt/cdrom.

3) Select the language for the installation and click **OK**.

The language that you select is also set as the default language of the Management Client. The **Installation Wizard** starts in the selected language.

- 4) When the Installation Wizard shows the Introduction view, click Next to start the installation. The License Agreement appears.
 - You can click Cancel at any time to exit the wizard.
 - You can click Previous at any time to go back.
- 5) Indicate that you agree to the license agreement and click **Next**.
- 6) (Optional) The default installation directory in Windows is C:\Program Files\Forcepoint\Stonesoft Management Center. Click Choose to browse to a different installation folder. This folder is for the application. Log Servers can have a separate data storage location.



Note: If you install the SMC in C:\Program Files\Forcepoint\Stonesoft Management Center, the installation creates an extra C:\ProgramData\Forcepoint\Stonesoft Management Center folder, which duplicates some of the folders in the installation directory. Some of the program data is also stored in the C:\ProgramData\Forcepoint\Stonesoft Management Center folder.

Click Next.



Important: When you run setup.sh on Linux, make sure to verify the hosts file in Linux distributions.

- 8) Select where to create shortcuts. These shortcuts can be used to manually start components and to run some maintenance tasks.
- 9) Click Next.
- **10)** Select the installation type:
 - Typical installs all SMC components except the Web Portal Server.
 - Management Client Only installation is meant for administrators' workstations.
 - **Custom** installation allows you to select components one by one. Use this option if you want to install SMC components on different computers or if you want to install the Web Portal Server.

- 11) Click Next.
- (Custom installation only) Select the components that you want to install and click Next.



Important: Make sure that you have a license for any separately licensed components before installing them. The Web Portal Server is not included in standard Security Management Center licenses.

Result

The Installation Wizard continues according to the installation type and the selected components.

Next steps

Continue the installation in one of the following ways:

- For a Typical installation, install a Management Server.
- For a Custom installation, install the first selected component.

Install a Management Server

In a **Typical** installation, you must install the Management Server first. In a **Custom** installation, you usually install the Management Server first.

Steps

- In the Installation Wizard, select the Management Server's IP address from the list.
 The Management Server's license must be generated using this IP address.
- In the Log Server IP Address field, enter the IP address to which this Management Server sends its log data.
- 3) (Optional) If you want the Management Server to distribute the Management Client through Java Web Start, select Enable and Configure Web Start Server.
- 4) (Optional) To use 256-bit encryption for communication between the Management Server and the engines, select 256-bit Security Strength.

This setting requires all engines to be version 5.5 or higher.



CAUTION: Engines with versions lower than 5.5 and SSL VPN gateways cannot communicate with the SMC when 256-bit encryption is used for the communication between the Management Server and the engines.

 (Optional) If you are required to follow the FIPS 140-2 standards, select Enable FIPS 140-2 Configuration Restrictions.



Note: This option only is for environments that are required to follow the FIPS 140-2 standards. Do not select this option unless you have a specific reason to do so.

Leave Install as a Service selected to make the Management Server start automatically.

7) (256-bit Security Strength only) Click **Next**.

A warning about the compatibility of 256-bit security strength is displayed.

If you did not select Enable and Configure Web Start Server, proceed to step 9.

- 8) Click Next. You are prompted to configure the Web Start Server.
- 9) (Web Start Server only) Configure the Web Start Server settings.

Setting	Description	
Port	Enter the TCP port that the service listens to. By default, the standard HTTP port is used on Windows. Port 8080 is used on Linux (which does not allow the use of reserved ports for this type of service).	
	Note: Make sure that the listening port is not in use on the server.	
Host Name (Optional)	Enter the Host Name that the Web Start service uses. Leave the field blank to allow requests to any of the server's host names.	

10) Click Next.

You are prompted to create a superuser account.



Important: This account is the only one that can log on after the installation.

- 11) In the Enter the User Name field, enter a user name.
- 12) In the Enter the Password and Confirm the Password fields, enter and confirm the password.
- 13) Click Next.

Result

The Installation Wizard continues according to the installation type and the selected components.

Next steps

Continue the installation in one of the following ways:

- For a typical installation, install a Log Server.
- For a custom installation, install the next selected component or finish the SMC installation.

Install a Log Server

The SMC requires the installation of one or more Log Servers.

Steps

In the Installation Wizard, select the Log Server's IP address from the list.
 If IP address binding is used, the Log Server's license must be generated with this IP address as the binding.

- 2) Enter the IP addresses of the Management Servers that control this Log Server.
- 3) If the components are installed on different computers and the Management Server is not reachable at the moment, deselect Certify the Log Server During the Installation to avoid connection attempts after installation.



Tip: Certifying is mandatory for running the Log Server.

- 4) Leave Install as a Service selected to make the Log Server start automatically.
- Click Next.
- 6) (Optional) Click Choose to browse to a different storage folder for log data.



Note: Remote locations are not suitable for active storage, as quick and reliable access is required.

Click Next.

Result

The Installation Wizard continues according to the installation type and the selected components.

Next steps

Continue the installation in one of the following ways:

- For a Typical installation, finish the SMC installation.
- For a Custom installation, install the next selected component or finish the SMC installation.

Install a Web Portal Server

If you want to provide restricted access to log data, reports, and policy snapshots, install a Web Portal Server.

Before you begin

Make sure that you have a license for the Web Portal Server before installing it. The Web Portal Server is an optional component and is not included in standard Security Management Center licenses. You can use the **Previous** button to return to component selection.

Steps

- In the Installation Wizard, select the Web Portal Server's IP address from the list.
 If IP address binding is used, the Web Portal Server's license must be generated with this IP address as the binding.
- Enter the IP addresses of the Management Servers that control this Web Portal Server.

- 3) If the components are installed on different computers and the Web Portal Server is not reachable at the moment, deselect Certify the Web Portal Server During the Installation to avoid connection attempts after installation.
 - Certifying is mandatory for running the Web Portal Server.
- 4) Enter the IP address of the Log Server to which this Web Portal Server sends its log data.
- 5) Leave Install as a Service selected to make the Web Portal Server start automatically.
- 6) Click Next.

Result

The Installation Wizard continues to the Pre-Installation Summary.

Next steps

Finish the SMC installation.

Finish the SMC installation

Finish the configuration in the Installation Wizard and install the selected components.

Before you begin

If you are installing any server components as a service on a Windows system, make sure that the Services window is closed before you proceed.



Important: This is the last chance to cancel or make changes by clicking **Previous**.

Steps

- 1) Check that the information in the **Pre-Installation Summary** is correct and click **Install** to install the selected components.
 - Depending on the options, you selected, you might be prompted to generate certificates during the installation.
- 2) Click Done to close the installer.



Note: If any Log Server or Web Portal Server certificate was not retrieved during the installation, retrieve a certificate manually before starting the server.

Related tasks

Generate SMC server certificates on page 52

Install the SMC in Demo Mode

The Demo Mode installation creates a simulated network environment for evaluation.

Demo Mode installation is for evaluation only. SMC in Demo Mode cannot be used with any traffic inspection engines and cannot be upgraded.

Steps

- Log on to the system where you are installing the SMC with the correct administrator rights. 1)
 - In Windows, log on with administrator rights.
 - In Linux, log on as root.
- Start the installation in one of the following ways: 2)
 - From a .zip file Unzip the file and run setup.exe on Windows or setup.sh on Linux.
 - From a DVD Insert the installation DVD and run the setup executable from the DVD.

Operating system	Path to executable	
Windows 64-bit	\Forcepoint_SMC_Installer\Windows-x64\setup.exe	
Linux 32-bit	/Forcepoint_SMC_Installer/Linux/setup.sh	
Linux 64-bit	/Forcepoint_SMC_Installer/Linux-x64/setup.sh	



Tip: If the DVD is not automatically mounted in Linux, mount the DVD using this command: mount /dev/cdrom /mnt/cdrom.

3) Select the language for the installation and click **OK**.

> The language that you select is also set as the default language of the Management Client. The Installation Wizard starts in the selected language.

- 4) When the Installation Wizard shows the Introduction view, click Next to start the installation. The License Agreement appears.
 - You can click Cancel at any time to exit the wizard.
 - You can click Previous at any time to go back.
- 5) Indicate that you agree to the license agreement and click **Next**.
- 6) (Optional) The default installation directory in Windows is C:\Program Files\Forcepoint\Stonesoft Management Center. Click Choose to browse to a different installation folder. This folder is for the application. Log Servers can have a separate data storage location.



Note: If you install the SMC in C:\Program Files\Forcepoint\Stonesoft Management Center, the installation creates an extra C:\ProgramData\Forcepoint\Stonesoft Management Center folder, which duplicates some of the folders in the installation directory. Some of the program data is also stored in the C:\ProgramData\Forcepoint\Stonesoft Management Center folder.

7) Click Next.



Important: When you run setup.sh on Linux, make sure to verify the hosts file in Linux distributions.

- 8) Select where to create shortcuts. These shortcuts can be used to manually start components and to run some maintenance tasks.
- Click Next.
- 10) Select **Demo Mode** as the installation type.
- 11) Click Next.
- 12) Select the type of demo to install.
 - Use a standard backup to simulate a standard preconfigured environment.
 - Select Demo MSSP/Stonesoft Management Center MSSP Demo to simulate a preconfigured environment with MSSP features.
 - Select your own backup file to create the simulation based on your own backup.
- 13) (Custom backup file only) Click Choose and browse to the location of the backup file.
- 14) Click Next.

A description of the Demo Mode installation is displayed.

15) Click Next.

The Pre-Installation Summary is displayed.

16) Click Install.

The installation starts.

- 17) When the installation finishes, click **Next**.
- 18) Click **Done** to close the installer.

The Security Management Center starts automatically in the background.

Result

The simulated environment is now ready for testing.

Related tasks

Log on to the SMC on page 49

Install the SMC from the command line

In Linux, you can install the Security Management Center on the command line.

Before you begin

Before installing, check the installation package integrity using the MD5 or SHA-1 file checksums.



Important: You need a graphical environment to use the Management Client. It cannot be run on the command line. Only the SMC server components can be run in a command line-only environment.

Related tasks

Check file integrity on page 25

Start the SMC installation on the command line

Start the command line installer to install SMC components from the command line.

Steps

- 1) Start the installation in one of the following ways:
 - From a .zip file: Unzip the file and run setup.sh.
 - From a DVD: Insert the installation DVD and run the setup executable from the DVD:

Operating system	Path to executable	
Linux 32-bit	/Forcepoint_SMC_Installer/Linux/setup.sh	
Linux 64-bit	/Forcepoint_SMC_Installer/Linux-x64/setup.sh	



Tip: If the DVD is not automatically mounted in Linux, mount the DVD with mount / dev/cdrom /mnt/cdrom.

2) Run the command ./setup.sh -nodisplay (the -nodisplay option can be omitted if there is no graphical environment running).

The installer starts. You can use the following general commands at any point where the installer asks for your input:

- Type back to return to the previous step.
- Type quit to cancel the installation.
- Press Enter to continue.

The license agreement is displayed.

4) Press **Enter** to scroll through the license agreement and accept it by typing Y.

You are prompted to select the installation directory.

- 5) Press **Enter** to install in the default installation directory or specify a different directory and press **Enter** to continue.
 - If you specify a different directory, you are prompted to confirm it.
 - A reminder to verify that the hosts file is displayed.
- Press Enter to continue.

You are prompted to select the link location for shortcuts to the most commonly used command-line tools.

7) Press Enter to create links in the default directory or select one of the other options and press Enter to continue.

You are prompted to select the type of installation.

8) Select the Install Set:

Option	Description
Press Enter	Installs all Security Management Center components except the Web Portal Server.
Press 2 and press Enter	Installs only the Management Client.
Press 3 and press Enter	Installs a simulated network environment for evaluation in Demo Mode.
Press 4 and press Enter	Installs a custom selection of components.

- 9) (Customized installation only) Type a comma-separated list of numbers for the components you want to select or deselect and press **Enter**.
 - Entering the number of a selected component deselects it.
 - Entering the number of a component that is not selected selects it.
 - By default, the Management Server, Log Server, and Management Client are selected.

Example: To install only the Web Portal Server, type 1, 2, 3, 4 and press **Enter**.

You are prompted to review and confirm the component selection.

10) Press Enter to continue.

Configure the Management Server from the command line

Configure the Management Server settings in a command line installation.

Steps

1) Press **Enter** to use the default IP address for the Management Server or enter a different IP address and press **Enter** to continue.

You are prompted to enter the IP address of the Log Server to which the Management Server sends its log data.

Press Enter to use the default IP address for the Log Server or enter a different IP address and press Enter to continue.

You are prompted to select whether to install the Management Server as an extra Management Server for high availability.

- 3) Type Y to install the Management Server as an extra Management Server for high availability, or type N to install the Management Server as a standalone Management Server or as the primary Management Server in a high-availability environment.
- Press Enter to continue.

You are prompted to select whether to enable and configure a Web Start Server.

- 5) Type Y to enable and configure Web Start or type N.
- 6) Press **Enter** to continue.

You are prompted to select whether to enable 256-bit security strength for communication between the Management Server and the engines. This option requires all engines to be version 5.5 or higher.



CAUTION: Engines with versions lower than 5.5 and SSL VPN gateways cannot communicate with the SMC when 256-bit encryption is used for the communication between the Management Server and the engines.

- 7) Type Y to enable 256-bit security strength or N to use the default security strength.
- Press Enter to continue.

You are prompted to select whether to install the Management Server as a service.

- Type \underline{Y} to install the Management Server as a service or \underline{N} if you always want to start the Management Server manually.
- Press Enter to continue.

If you enabled 256-bit security strength, a warning about the compatibility of 256-bit security strength is displayed.

11) (256-Bit Security Strength only) Press **Enter** to continue or type back and start the Management Server configuration again from Step 1 to disable 256-bit security strength.

12) (Web Start only) Enter the TCP port that the service listens to.

By default, the standard HTTP port 80 is used on Windows and 8080 on Linux. Linux does not allow the use of reserved ports for this type of service.



Important: Make sure that the listening port is not in use on the server.

- (Web Start only) Enter the Host Name that the Web Start service uses. Leave the option blank to allow requests to any of the server's host names. Press Enter to continue.
- 14) Create a superuser account.
 - a) Type a new user name.
 - b) Type the password for this account.
 - c) Confirm the password.

Related information

Default communication ports on page 195

Configure the Log Server from the command line

Configure the Log Server settings in a command line installation.

Steps

 Press Enter to use the default IP address for the Log Server or enter a different IP address and press Enter to continue.

You are prompted to enter the IP addresses of the Management Servers that control the Log Server.

2) Press **Enter** to use the default IP address for the Management Server or enter different IP addresses and press **Enter** to continue.

You are prompted to enter the port on which the Log Server receives data.

3) Press Enter to use the default port or enter a different port and press Enter to continue.

You are prompted to select whether to install the Log Server as a service.

- 4) Type Y to install the Log Server as a service or N if you always want to start the Log Server manually.
- Press Enter to continue.

You are prompted to select the directory for log files.

6) Press Enter to use the default directory or specify a different directory and press Enter to continue.

Configure the Web Portal Server from the command line

Configure the Web Portal Server settings in a command line installation.

Steps

1) Press **Enter** to use the default IP address for the Web Portal Server or enter a different IP address and press **Enter** to continue.

You are prompted to enter the IP addresses of the Management Servers that control the Web Portal Server.

2) Press **Enter** to use the default IP address for the Management Server or enter different IP addresses and press **Enter** to continue.

You are prompted to enter the IP address of the Log Server.

 Press Enter to use the default IP address for the Log Server or enter a different IP address and press Enter to continue.

You are prompted to select whether to install the Web Portal Server as a service.

- 4) Type Y to install the Web Portal Server as a service or N if you always want to start the Web Portal Server manually.
- 5) Press Enter to continue.

Install the SMC Appliance

The SMC Appliance ships with the Management Server and a Log Server pre-installed on it. Starting the SMC Appliance initiates an installation wizard.

Before you begin

Prepare the appliance for installation:

- Determine the appliance networking information:
 - IPv4 network address
 - IPv4 network mask
 - (Optional) Default gateway address
 - (Optional) DNS server addresses
- Mount the appliance in a rack.
- Connect the network and console cables.
- Access the appliance through a KVM or the integrated Dell Remote Access Controller (iDRAC) port.

See the Forcepoint NGFW Security Management Center Appliance Hardware Guide for complete details.

Steps

- 1) Turn on the SMC Appliance.
- 2) Select the keyboard layout for accessing the SMC Appliance on the command line.
- Accept the EULA.
- Enter the account name and password.

The password must be at least ten characters long and contain at least one number. The account name and password become an administrator account with unrestricted permissions (superuser) on the Management Server.

a) Enter the account name.

This field is case sensitive and limited to eight characters.

b) Enter the password.

The password is case sensitive and must have a minimum of ten characters.

- c) Enter the password again.
- Make your security selections.
 - Specify if the appliance runs in FIPS 140-2 mode.
 No is the default.



Note: This option is for environments that are required to follow the FIPS 140-2 standards.

Specify if the appliance uses 256-bit security strength.
 Yes is the default.



Note: The security strength is for the connection to the NGFW Engines. The engines must also use 256-bit security strength.

- Complete the network interface and network setup fields.
 - a) Select the main network interface for management.
 - b) Complete the network setup fields for the interface.
- Enter a host name for the Management Server.
- Select the time zone.
- Set the time.
- (Optional) Configure NTP settings.

Result

When the installation is complete, the SMC Appliance restarts.

Related tasks

Contact the Management Server on the command line on page 155

Start the SMC after installation

Proceed through the listed sections in sequence to start the SMC for the first time.

Start the Management Server

If the Management Server does not start automatically, you must start it.

If the Management Server has been installed as a service, it starts automatically both after the installation and during the operating system boot process. In Windows, the **Forcepoint NGFW Management Server** service is controlled in the **Services** window. That window is in the Windows Control Panel under the Administrative Tools category.

Steps

- 1) Start the Management Server manually.
 - In Windows, use the shortcut icon in the location you selected during installation or run the script <installation directory>/bin/sgStartMgtSrv.bat.
 - In Linux, run the script <installation directory>/bin/sgStartMgtSrv.sh.

Next steps

When the Management Server has successfully started, start the Management Client.

Start the Management Client

After you start the Management Server, start the Management Client

Steps

- 1) To start a locally installed Management Client, use the appropriate step.
 - In Windows, use the shortcut icon in the location you selected during installation or run the script <installation directory>/bin/sgClient.bat.
 - In Linux, run the script <installation directory>/bin/sgClient.sh. A graphical environment is needed for the Management Client.
- To start a Management Client using Web Start, follow these steps.
 - a) In a web browser, enter http://<server address>:<port>.



Note: :<port> is only needed if the server is configured to run on a different port from the HTTP standard port 80.

b) Click the link for the Web Start Management Client.

Log on to the SMC

The Management Client connects to the Management Server and to Log Servers.

Steps of For more details about the product and how to configure features, click Help or press F1.

 Select an existing Management Server IP address or DNS name, or click Add Server and enter an IP address or DNS name.

In Demo Mode, select 127.0.0.1.

2) Enter the user name and password for the Administrator you defined during the Management Server or SMC Appliance installation.

In Demo Mode, use the following credentials:

- User name demo
- Password demo
- Click Log On.

Related information

Default communication ports on page 195

Accept the Management Server certificate

A certificate dialog box is displayed when the Management Client contacts any Management Server for the first time.

Before you begin

As a precaution, you can make sure that the communication really is with your Management Server by checking the Certificate Authority fingerprint.

Steps

- 1) View the Management Server fingerprint on the Management Server:
 - In Windows, use the shortcut icon in the location you selected during installation (default: Start > All Programs > Forcepoint > Stonesoft Management Center > Tools > Show Fingerprint) or run the script <installation directory>/bin/sgShowFingerPrint.bat.
 - In Linux, run the script <installation directory>/bin/sgShowFingerPrint.sh.
 - On the SMC Appliance, log on to the command line with your administrator credentials and run the command sudo /usr/local/forcepoint/smc/bin/sgShowFingerPrint.sh -nodisplay.
- If the fingerprint matches, click Accept.

The Management Client opens.

Install licenses for SMC servers

Install the SMC server licenses that you downloaded while preparing for installation.

The SMC servers require licenses to become operational. If you do not have a valid Management Server license, a message appears when you log on. If the message appears after licensing, make sure that the licensed IP addresses are correct and active on the server when the Management Server service starts.

Steps of For more details about the product and how to configure features, click **Help** or press F1.

- In the Management Client, install licenses through the License Information message.
 - a) Click Continue.
 - b) Select the license files in the dialog box.

If the message is not shown, install the licenses as explained in the next step. Otherwise, check that the licenses were installed correctly.

- If you are not prompted to install a Management Server license, install the license files for the other SMC servers.
 - a) Select ≡ Menu > System Tools > Install Licenses.
 - b) Select the license files and click Install.
- To check that the licenses were installed correctly, select . Configuration, then browse to Administration > Licenses > All Licenses.

Related tasks

Obtain license files on page 27

Bind Management Server POL-bound licenses to servers

You must bind Management Server POL-bound licenses for Log Servers and Web Portal Servers to specific Server elements.

Steps 9 For more details about the product and how to configure features, click **Help** or press **F1**.

- 1) Select . Configuration, then browse to Administration.
- Browse to Licenses > Servers.
 Installed licenses appear in the right pane.
- Right-click a Management Server POL-bound license.
 The Select License Binding dialog box opens.
- 4) Select the correct server from the list.
- 5) Click Select.



Tip: If you bound the license to an incorrect element, right-click the license and select **Unbind**.



Note: The license is permanently bound to the Log Server or Web Portal Server element when the server is started for the first time. A permanently bound license cannot be rebound to a different Log Server or Web Portal Server element without relicensing or deleting the element that the license is bound to. Until you do that, the unbound license is shown as **Retained**.

Result

The license is now bound to the selected Log Server or Web Portal Server element.

Start SMC servers

If the Log Server and optional Web Portal Server do not start automatically, you must start them.

If the Log Server and Web Portal Server have been installed as a service, the servers are started automatically during the operating system boot process. If the operating system is restarted and the servers do not yet have a license, you might need to start them manually.

Steps

- 1) Start the Log Server and the optional Web Portal Server.
 - If you installed the Log Server or Web Portal Server as a service, start or stop the server manually in Windows through the **Services** window.
 - Start the Log Server or Web Portal Server manually by running scripts in a console window.
 Read the console messages for information about the progress. Closing the console stops the service.

Server type	Windows script	Linux script
Log Server	<installation directory="">/bin/ sgStartLogSrv.bat</installation>	<installation directory="">/bin/ sgStartLogSrv.sh</installation>
Web Portal Server	<installation directory="">/bin/ sgStartWebPortalServer.bat</installation>	<installation directory="">/bin/ sgStartWebPortalServer.sh</installation>

- If the Log Server or Web Portal Server does not start, troubleshoot and resolve issues that cause starting to fail.
 - Try starting the server by running scripts in a console window to see if an error is displayed on the console.
 - Check that licenses are correctly bound to components.
 - Make sure that the server has a valid certificate for secure system communications. If there are certificate-related problems or problems you are not able to identify, try regenerating the certificate.

Generate SMC server certificates

If necessary, you can manually certify an SMC server or generate an SMC server certificate.

To manually certify an SMC server, run one of the following scripts in Windows or in Linux depending on the server type:

Server type	Windows script	Linux script
Log Server	<installation directory="">/bin/ sgCertifyLogSrv.bat</installation>	<installation directory="">/bin/sgCertifyLogSrv.sh</installation>
Web Portal Server	<installation directory="">/bin/ sgCertifyWebPortalServer.bat</installation>	<installation directory="">/bin/ sgCertifyWebPortalServer.sh</installation>

To generate a server certificate, follow these steps:

Steps

1) Enter the user name and password for the account you created during the Management Server installation (other accounts with unrestricted permissions can also be used).

- 2) Click Accept to accept the certificate fingerprint of the Management Server's Certificate Authority. As a precaution, you can make sure that the communication really is with your Management Server.
 The Server Selection dialog box opens.
- 3) Identify the component that you want to certify:
 - If the server element that represents the component is listed, select it.
 - If recommended follows the name of a server element, the component ID of the server element matches
 the ID of the component that you are certifying. It is suggested that you select the recommended server
 element.



CAUTION: Selecting a server element that is not the recommended server element might cause serious problems. For example, the server's log data or the monitoring status of the server might be displayed incorrectly.

- If the correct server element is not listed, select Create a New Log Server or Create a New Web Portal Server and enter a name in the Name field.
- 4) Click OK.

Post-installation SMC configurations

After installation, you can configure settings for system communication and add more functions to the SMC.

- If NAT is applied to communications between any SMC components, configure NAT addresses for SMC components.
- If you want to install high availability Management Servers, configure and install more Management Servers.
- If you want to enable Web Start or you want to change the Web Start Server settings, distribute Management Clients through Web Start.

When you are finished configuring the SMC, you are ready to use the Management Client to configure Firewall, IPS, and Layer 2 Firewall elements. The elements must be configured before installing the physical engines.

Related concepts

Configuring NAT addresses for SMC components on page 55

Related tasks

Add Management Servers for high availability on page 58
Distribute Management Clients through Web Start on page 60

R CHAPTER 4

Configuring the SMC

Contents

- Configuring NAT addresses for SMC components on page 55
- Add Management Servers for high availability on page 58
- Distribute Management Clients through Web Start on page 60

After initial installation is complete, configure the SMC to allow adding the other components for your system.


Configuring NAT addresses for SMC components

You must configure Locations and contact addresses when network address translation (NAT) is applied to the communications between any of the SMC components.

If there is NAT between communicating SMC components, the translated IP address might have to be defined for system communications.

You use Location elements to configure SMC components for NAT. There is a Default Location to which all elements belong if you do not assign them to a specific Location. If NAT is applied between two SMC components, you must separate them into different Locations and then add a contact address for the component to be contacted.

You can define a Default contact address for contacting an SMC component (defined in the Properties dialog box of the corresponding element). The component's Default contact address is used in communications when SMC components that belong to another Location contact the component and the component has no contact address defined for its Location.



Component	Description		
Headquarters Location			
1	Management/Log server		
2	Internet		
3	IPS		

Component	Description		
4	Firewall		
Between locat	Between locations		
5	Internet		
Branch Office Location			
6	Firewall		
7	IPS		
8	Internet		

In the example scenario above, the same Management Server and Log Server manage SMC components both at a company's headquarters and at the branch office.

NAT could typically be applied at the following points:

- The firewall at the headquarters or an external router can provide the SMC servers external IP addresses on the Internet. The external addresses must be defined as contact addresses so that the SMC components at the branch offices can contact the servers across the Internet.
- The branch office firewall or an external router can provide external addresses for the SMC components at the branch office. In this case, the external IP addresses must also be defined as contact addresses so that the Management Server can contact the components.

When contact addresses are needed, it might be enough to define a single new Location element, for example, for the branch office, and to group the SMC components at the branch office into the "Branch Office" Location. The same Location element could also be used to group SMC components at any other branch office when they connect to the SMC servers at the headquarters.

To be able to view logs, the administrators at the branch office must select the "Branch Office" Location in the Management Client.

Configuration overview

- 1) Define Location elements.
- 2) Define contact addresses for the Management Servers and Log Servers.
- 3) Select the Location for your Management Client.
- Select the Locations for NGFW Engines when you create the engine elements.

Related information

Default communication ports on page 195

Add Location elements

Group the SMC components into **Location** elements based on which components are on the same side of a NAT device.

The elements that belong to the same **Location** element always use the primary IP address when contacting each other.

Steps • For more details about the product and how to configure features, click **Help** or press **F1**.

- 1) Select . Configuration, then browse to Administration.
- 2) Expand the Other Elements branch.
- 3) Right-click Locations and select New Location.
- 4) In the Name field, enter a name.
- 5) Select elements from the **Resources** pane and click **Add**.
- 6) Click OK.

Next steps

Continue the configuration in one of the following ways:

- If your Management Server or Log Server needs a contact address, add SMC server contact addresses.
- Configure the Firewall, IPS, and Layer 2 Firewall elements in the Management Client. You must configure
 the elements before configuring the Forcepoint NGFW software.

Add SMC Server contact addresses

The Management Server and Log Server can have more than one contact address for each Location.

- If you have additional Management Servers or Log Servers, define two or more contact addresses for each Location. Multiple contact addresses are required so that remote components can connect to a Management Server or a Log Server even if one of the Management Servers or Log Servers fails.
- If you have configured Multi-Link, define two or more contact addresses per Location so that remote components can connect to the servers even if a NetLink goes down.

Steps @ For more details about the product and how to configure features, click Help or press F1.

- 1) Right-click a server and select **Properties**.
- From the Location drop-down menu, select the location to which the server belongs.

- If necessary, edit the contact addresses.
 - A Default contact address is automatically entered based on the element properties.
 - If the server has multiple Default contact addresses, separate the addresses with commas.
 - If necessary, click Exceptions to define other contact addresses for specific Locations



Note: Elements that belong to the same Location element always use the primary IP address when contacting each other instead of any contact addresses. Elements that do not belong to a specific Location are considered to belong to the Default Location.

Click OK.

Set the Management Client location

When there is a NAT device between the Management Client and a Log Server, select the correct Location for your Management Client. Make the selection in the status bar at the bottom of the Management Client window to be able to view logs.



Note: You must select the Management Client Location separately in each administrative Domain if there are multiple Domains in your environment.

Steps @ For more details about the product and how to configure features, click Help or press F1.

- In the Management Client, click the **Default Location** name in the status bar at the bottom of the window.
- Select the Location that includes the IP address or network of the computer where you use the Management Client.

Add Management Servers for high availability

You can optionally install one or more additional Management Servers for high availability.



Note: The SMC Appliance does not support high availability for the Management Server or the Log Server.

Additional Management Servers control the system if the active Management Server is damaged, loses power, or becomes otherwise unusable. Configuration data is automatically replicated between the Management Servers. Only one Management Server at a time can be used as an active Management Server to configure and manage the system.

To use additional Management Servers, you must have a special Management Server license that lists the IP addresses of all Management Servers within the same SMC.



Note: You must install the license in the Management Client before installing the additional Management Servers. If you do not yet have the license, generate the license at the Forcepoint website after receiving the Proof-of-License, then install the license.

Perform this task for each Management Server that you want to add.

Steps

- 1) Start the installation in one of the following ways:
 - From a .zip file: Unzip the file and run setup.exe on Windows or setup.sh on Linux.
 - From a DVD: Insert the installation DVD and run the setup executable from the DVD:

Operating system	Path to executable	
Windows 64-bit	\Forcepoint_SMC_Installer\Windows-x64\setup.exe	
Linux 32-bit	/Forcepoint_SMC_Installer/Linux/setup.sh	
Linux 64-bit	/Forcepoint_SMC_Installer/Linux-x64/setup.sh	



Note: If the DVD is not automatically mounted in Linux, mount the DVD with mount / dev/cdrom /mnt/cdrom.

Proceed according to the instructions in the Installation Wizard until you are prompted to select which components you want to install.



Note: If you install the SMC in C:\Program Files\Forcepoint\Stonesoft Management Center, the installation creates an extra C:\ProgramData\Forcepoint\Stonesoft Management Center folder, which duplicates some of the folders in the installation directory. Some of the program data is also stored in the C:\ProgramData\Forcepoint\Stonesoft Management Center folder.

- 3) Select the installation type.
 - If you want to install a Log Server and a local Management Client on this computer, leave Typical selected and click Next.
 - If you only want to install a Management Server on this computer, select **Custom**, select the components you want to install and click **Next**.
- 4) Select the IP address of the Management Server from the list or type it in.
 - This address must be the IP address defined for the corresponding Management Server element.
 - The Management Server's license must be generated using this IP address.
- Enter the IP address of the Log Server to which the Management Server sends its log data.
- Select Install as an Additional Management Server for High Availability.
- 7) To make the Management Server start automatically, leave Install as a Service selected.
- 8) Click **Next** and follow the instructions to start the installation. A logon prompt for Replication opens.

- Log on using an unrestricted administrator account.
 The Management Server Selection dialog opens.
- 10) Select the correct Management Server from the list or select Create a new Management Server and enter the name of the Management Server element you are creating.
- 11) Click OK.

The databases are synchronized.



Note: If the synchronization fails, run the sgOnlineReplication script on the additional Management Server when connectivity is restored.

Result

You can now use the Management Client to configure the Firewall, IPS, and Layer 2 Firewall elements in the Management Client. The elements must be configured before installing the physical engines.

Next steps

- If NAT is applied to communications between any SMC components, configure NAT addresses for SMC components.
- If there is a Firewall or Layer 2 Firewall between the first Management Server you installed and the additional Management Servers, add rules that allow the communications between the servers when you define your Firewall or Layer 2 Firewall Policy.

Related tasks

Install licenses for SMC servers on page 50 Install SMC components on page 34

Distribute Management Clients through Web Start

In addition to installing Management Clients on a local workstation, you can also distribute them through Java Web Start.

Management Clients distributed with Web Start have the same set of features as clients installed on a local workstation. However, when you upgrade, Web Start automatically downloads the new version when the user logs on to the Management Client through a web browser.

There are two ways to configure Web Start access:

- You can activate an internal web server on the Management Server (the server distributes only Web Start Management Clients). There is no need for manual installation or upgrade.
- You can use a separate web server or network drive for distributing the clients. You must install Web Start files manually and reinstall them at each SMC version upgrade.

Distribute Management Clients from SMC servers

You can configure a Web Start Server to distribute Management Clients from the Management Server. If you have already configured the Web Start Server, you can configure additional settings.

Steps • For more details about the product and how to configure features, click **Help** or press **F1**.

- In the Management Client, select # Home. 1)
- 2) Browse to Others > Management Server.
- 3) Right-click a Management Server, then select Properties.
- 4) Click the Web Start tab.
- 5) Select Enable. The Web Start Server options are enabled.
- 6) (Optional) Enter the Host Name that the Web Start service uses.
- 7) (Optional) Enter the TCP port that the service listens to.



Tip: By default, the standard HTTP port 80 is used on Windows and 8080 on Linux. Linux does not allow the use of reserved ports for this type of service.



Important: Make sure that the listening port is not in use on the server.

- 8) (Optional) If the Management Server has several addresses and you want to restrict access to one address, specify the IP address in the Listen Only on Address field.
- (Optional) Select Generate Server Logs if you want to log all file load events for further analysis with 9) external web statistics software.
- Click OK. 10)

Related information

Default communication ports on page 195

Distribute Management Clients from a separate server

If you want to use a Web Start Server to distribute Management Clients, but you don't want to use the Management Server as a Web Start Server, you can install the Web Start Server on a separate server.

The Web Start package can also be put on a shared network drive. The path to the Web Start files, including the drive letter, must be the same for all administrators who use that particular version of the installation package. If the network drive paths vary, consider putting the package on a web server instead.



Important: You must delete the existing Web Start files and install a new Web Start package according to these instructions each time you upgrade the SMC. Otherwise, any administrators who use Management Clients that are installed through Web Start are not able to log on.

Steps

1) On the installation DVD, browse to Forcepoint_SMC_Installer > Webstart.



CAUTION: The Web Start installation creates an index.html file in the installation directory. Any existing index.html file is overwritten. We strongly recommend creating a directory for the Web Start files.

- Copy all files and all directories from the Web Start directory on the installation DVD to the directory where you want the Web Start files to be served.
- 3) On the command line, change to the directory where the Web Start files are on your server.
- 4) Run the Web Start setup script and give the URL or the path of the directory where the Web Start files are stored on your server:
 - Windows: cscript webstart_setup.vbs <web start directory>
 - Linux: Run webstart_setup.sh <web start directory>

Installation on	Example Web Start directory
Web server	http://www.example.com/webstart/
Network drive	file://localhost/c:/webstart/

- 5) If necessary, change the configuration of the web server to return the appropriate MIME type for .jnlp files (application/x-java-jnlp-file).
 - See the manual of your web server for instructions on how to configure the MIME type.
- 6) Delete the webstart_setup.vbs and webstart_setup.sh files from the directory.

B PART III **Forcepoint NGFW** deployment

Contents

- Configuring Forcepoint NGFW for the Firewall/VPN role on page 65
- Configuring Forcepoint NGFW for the IPS role on page 93
- Configuring Forcepoint NGFW for the Layer 2 Firewall role on page 109
- Configuring NGFW Engines as Master NGFW Engines and Virtual NGFW Engines on page 123
- Configuring Forcepoint NGFW software on page 143
- NGFW Engine post-installation tasks on page 163

Forcepoint NGFW deployment consists of adding and configuring engine elements in the SMC, and configuring the Forcepoint NGFW software on the engine.

Forcepoint Next Generation Firewall 6.2 Installation Guide	

G CHAPTER 5

Configuring Forcepoint NGFW for the Firewall/VPN role

Contents

- Install licenses for NGFW Engines on page 65
- Configuring Single Firewalls on page 66
- Configuring Firewall Clusters on page 82

Configuring engine elements in the SMC prepares the SMC to manage NGFW Engines in the Firewall/VPN role.

Install licenses for NGFW Engines

Install the NGFW Engine licenses that you downloaded while preparing for installation.

Before you begin

The license files must be available to the computer that you use to run the Management Client.

You can install all licenses at the same time even though you have not yet created all elements that the licenses are bound to.

Steps 9 For more details about the product and how to configure features, click Help or press F1.

- 1) In the Management Client, select ≡ Menu > System Tools > Install Licenses.
- 2) Select one or more license files to install in the dialog box that opens and click Install.
- 3) To check that the licenses were installed correctly, select . Configuration, then browse to Administration > Licenses > All Licenses.
 - One license shows for each NGFW Engine node. You must bind POL-bound engine licenses manually to the correct engines after you have configured the engine elements. POS-bound engine licenses are automatically attached to the correct engines after the engine is fully installed.

Next steps

Define the engine elements.

Related concepts

Types of licenses for NGFW Engines on page 26

Configuring Single Firewalls on page 66

Configuring Firewall Clusters on page 82

Configuring Single Firewalls

After you have the SMC installed and running, you can configure the Single Firewall elements.

Little configuration is done directly on the engines. Most of the configuration is done using the Management Client. The engines cannot be successfully installed before defining them in the Management Client.

The tasks you must complete are as follows:

- Add Single Firewall elements.
- 2) Add interfaces and define their properties.
- 3) (Optional) Select system communication roles for the interfaces.
- 4) Bind Management Server POL-bound licenses to specific Single Firewall elements.

Types of interfaces for Single Firewalls

Interface numbers identify the interfaces for a Single Firewall element.

You can configure the following types of interfaces on Single Firewalls:

Table 2: Interface types for Single Firewalls

Interface type	Description		SMC numbering
1 -		ents an Ethernet port of a network e card on the engine.	Each physical interface has a unique interface ID number in the SMC.
		Tip: You can add VLAN interfaces to physical interfaces to divide a single physical network link into several virtual links.	

Interface type	Description	SMC numbering
ADSL interface	Represents the ADSL port of a purpose-built Forcepoint NGFW appliance. Note: Only certain Forcepoint NGFW appliances have an integrated ADSL network interface card with an ADSL port.	Each ADSL interface has a unique interface ID number in the SMC.
Wireless interface	Represents a wireless network interface card of a purpose-built Forcepoint NGFW appliance. Note: Only certain Forcepoint NGFW appliances have an integrated wireless network interface card.	The wireless interface has a unique interface ID number in the SMC. An SSID (service set identifier) interface represents an 802.11 wireless LAN. You can add several SSID interfaces to the wireless interface.
Modem interface	Represents a 3G modem connected to a USB port on a purpose-built Forcepoint NGFW appliance.	Modem Interfaces are identified with modem numbers in the SMC. The modem number is mapped to the modem's IMEI (international mobile equipment identity) number. Each modem is assigned a unique ID when you connect the modem to the Single Firewall engine.
Tunnel interface	A logical interface that is used as an endpoint for tunnels in the Route-Based VPN. Note: For detailed information about configuring tunnel interfaces and the Route-Based VPN, see the Forcepoint Next Generation Firewall Product Guide.	Tunnel interfaces are numbered with tunnel interface ID numbers. The tunnel interface IDs are automatically mapped to the network interfaces on the engine according to the routing configuration.
Integrated switch	Represents the switch functionality on a purpose-built Forcepoint NGFW appliance. Note: Only certain Forcepoint NGFW appliances have an integrated switch.	Integrated switches are identified with IDs in the SMC. You can add port group interfaces to switches. Port group interfaces are identified by port group IDs.

The modem numbers, switch IDs, and interface IDs are mapped to the corresponding network interfaces on the engine when you configure the Forcepoint NGFW software. Check the correct interface numbers in the Hardware Guide for your appliance model.



Note: If you configure the engine automatically with a USB drive, the interface IDs in the SMC are mapped to match the interface numbering in the operating system. For example, eth0 is mapped to Interface ID 0.

If necessary, you can change the interface ID, switch ID, and modem number mapping after the initial configuration using the command-line tools on the engine.

Add Single Firewall elements

To add a single-node firewall to the SMC, add a Single Firewall element that stores the configuration information related to the firewall.



Note: You can also define several Single Firewall elements at the same time by using the Create Multiple Single Firewalls wizard. For more information about creating several Single Firewall elements at the same time, see the *Forcepoint Next Generation Firewall Product Guide*.

Steps 9 For more details about the product and how to configure features, click **Help** or press **F1**.

- 1) Select . Configuration.
- Right-click NGFW Engines and select New > Firewall > Single Firewall.
 The Engine Editor opens.
- In the Name field, enter a unique name.
- 4) From the Log Server drop-down list, select the Log Server for storing this firewall's logs.
- 5) (Optional) In the DNS IP Addresses list, add one or more DNS IP addresses.

These addresses are the IP addresses of the DNS servers that the Single Firewall uses to resolve malware signature mirrors, domain names, and web filtering categorization services. There are two ways to define IP addresses:

- To enter a single IP address manually, click Add and select IP Address. Enter the IP address in the dialog that opens.
- To define an IP address by using a network element, click Add and select Network Element. Select a
 Host or External DNS Server element.
- From the Location drop-down list, select the Location to which the firewall belongs.
- 7) (Optional) If you have a Forcepoint NGFW appliance, copy and paste the proof-of-serial (POS) code delivered with the appliance to the **Proof of Serial** field.

Using the POS code allows you to configure the Single Firewall engine using plug and play configuration.

Click Save.

Do not close the Engine Editor.

Next steps

Add the interfaces.

Related tasks

Prepare for plug-and-play configuration on page 144

Add physical interfaces to Single Firewalls

To route traffic through the firewall, you must define at least two physical interfaces.



Note: Only the interface that is used for communications between the Management Server and the Firewall is required when you install the Single Firewall. Although you can configure more interfaces at any time, it is recommended to add more interfaces right away.

There are three types of physical interfaces:

- An interface that corresponds to a single network interface on the firewall engine. In the Management Client, the interface type is None.
- An aggregated link in high availability mode represents two interfaces on the firewall engine. Only the first interface in the aggregated link is actively used. The second interface becomes active only if the first interface fails
 - Connect the first interface in the link to one external switch and the second interface to another external switch.
- An aggregated link in load balancing mode represents two or more interfaces (up to eight interfaces) on the firewall engine. All interfaces in the aggregated link are actively used and connections are automatically balanced between the interfaces.
 - Link aggregation in load-balancing mode is implemented based on the IEEE 802.3ad Link Aggregation standard. Connect all interfaces to a single external switch. Make sure that the switch supports the Link Aggregation Control Protocol (LACP) and that LACP is configured on the switch.

Steps • For more details about the product and how to configure features, click **Help** or press **F1**.

- 1) In the navigation pane on the left, select Interfaces.
- 2) Right-click the empty space and select New > Physical Interface.
- From the Interface ID drop-down list, select an ID number.
 This ID maps to a network interface during the initial configuration of the engine.
- 4) From the **Type** drop-down list, select the interface type.
- 5) If the type is aggregated link, select one or more other interfaces that belong to the aggregated link.
 - For an aggregated link in high availability mode, select an interface ID from the Second Interface ID drop-down list.
 - For an aggregated link in load balancing mode, click Add to add one or more interface IDs to the Additional Interface(s) list.
- 6) Click OK.
- 7) Click Save.Do not close the Engine Editor.

Result

The physical interface is added to the interface list.

Add VLAN interfaces to Single Firewalls

VLANs divide a single physical network link into several virtual links.

You can add up to 4094 VLANS to each physical interface.

Steps • For more details about the product and how to configure features, click **Help** or press **F1**.

- 1) In the navigation pane on the left, select Interfaces.
- 2) Right-click a physical interface and select New > VLAN Interface.
- 3) In the VLAN ID field, enter a VLAN ID number (1-4094).



Note: The VLAN ID must be the same VLAN ID used in the external switch at the other end of the VLAN trunk.

4) Click OK.

The specified VLAN ID is added to the physical interface.

5) Click H Save.

Do not close the Engine Editor.

Result

The VLAN interface is now ready to be used as a network interface. The VLAN interface is identified as Interface-ID.VLAN-ID, for example 2.100 for interface ID 2 and VLAN ID 100.

Add ADSL Interfaces to Single Firewalls

You can add one ADSL interface to a Single Firewall.

ADSL is only supported on specific Forcepoint NGFW appliances that have an ADSL network interface card. The supported ADSL standards are ANSI T1.413 issue 2n, G.dmt, G.lite, ADSL2 DMT, ADSL2 G.lite, Annex A, and Annex B.

Steps 9 For more details about the product and how to configure features, click **Help** or press **F1**.

- 1) In the navigation pane on the left, select **Interfaces**.
- 2) Right-click the empty space and select New > ADSL Interface.
- 3) From the Interface ID drop-down list, select the number of the ADSL port on the appliance as the Interface ID.

The Interface ID is automatically mapped to the ADSL port on the engine's ADSL card during the initial configuration of the engine.

- 4) In the VCI field, enter the VCI (Virtual Channel Identifier) value according to the configuration information provided by your ISP.
- 5) In the **VPI** field, enter the VPI (Virtual Path Identifier) value according to the configuration information provided by your ISP.
- 6) From the **Multiplexing Mode** drop-down list, select LLC (Logical Link Control) or VC (Virtual Circuit) according to the configuration information provided by your ISP.
- Define the ADSL Interface properties.

Option	Explanation
Interface ID	Select the number of the ADSL port on the appliance as the Interface ID. The Interface ID is automatically mapped to the ADSL port on the engine's ADSL card during the initial configuration of the engine.
VCI	Enter the VCI (Virtual Channel Identifier) value according to the configuration information provided by your ISP.
VPI	Enter the VPI (Virtual Path Identifier) value according to the configuration information provided by your ISP
Multiplexing Mode	Select LLC (Logical Link Control) or VC (Virtual Circuit) according to the configuration information provided by your ISP.

- 8) Click OK to close the ADSL Interface properties.
- 9) Click **H** Save.

 Do not close the Engine Editor.

Add wireless interfaces to Single Firewalls

You can add one wireless interface to a Single Firewall.

Wireless interfaces are only supported on specific Forcepoint NGFW appliances that have an integrated wireless network interface card.

Steps 9 For more details about the product and how to configure features, click **Help** or press **F1**.

- 1) In the navigation pane on the left, select **Interfaces**.
- 2) Right-click the empty space and select New > Wireless Interface.
- From the Interface ID drop-down list, select the interface ID number.
 This ID number maps to the wireless port during the initial configuration of the engine.
- 4) In the Country field, enter or select the country where the firewall is used as a wireless access point.
- 5) From the Band drop-down list, select the band for the wireless interface access point.

From the Wireless Mode drop-down list, select the mode for transmitting the wireless traffic according to the capabilities of the connecting clients.

The wireless mode options that you can select depend on the band.

Band	Wireless mode
2.4 GHz	802.11b
	802.11bg
	802.11g
	802.11n
	802.11bgn
5 GHz	802.11a
	802.11an
	802.11n
	802.11ac
	802.11acn



Note: Some wireless clients do not support the 802.11n, 802.11ac, and 802.11acn wireless modes with the WEP security mode.

- 7) From the **Channel** drop-down list, select the channel for transmitting the wireless traffic.

 If there are other wireless access points nearby, use channels that are as far apart as possible to avoid interference. Security Management Center might sometimes select another channel to use the best frequency available. If you select **Automatic**, the best channel is automatically selected.
- 8) (Optional) From the **Width** drop-down list, select the width of the channel. This option is only available if the Wireless Mode is one of the following: 802.11n, 802.11bgn, 802.11an, 802.11n, 802.11ac, or 802.11acn.
- 9) (Optional) From the **Transmit Power** drop-down list, select the maximum power of the signal for transmitting the wireless traffic.
 - The power options are shown as milliwatts (mW) and as the power ratio in decibels of the measured power referenced to 1 milliwatt (dBm).
 - The values available depend on the regulatory limits for the selected country and the channel for the wireless interface.
 - If you are not sure what value to use, leave the default value selected.
- 10) Click OK.

The wireless interface is added to the interface list.

11) Click H Save.

Do not close the Engine Editor.

Add SSID Interfaces to Single Firewalls

A service set identifier (SSID) interface represents an 802.11 wireless LAN.

You can add several SSID Interfaces to the Wireless Interface.

Steps • For more details about the product and how to configure features, click **Help** or press **F1**.

- 1) In the navigation pane on the left, select Interfaces.
- Right-click the wireless interface and select New SSID Interface.
- In the Wireless Network Name (SSID) field, enter the wireless network name.
 It identifies the network to the end users.
- 4) From the Wireless SSID Broadcast drop-down list, select one of the following options:
 - Enabled The wireless network name is broadcast to anyone in range.
 - Disabled Users must type the name to connect.
- 5) From the MAC Address Type drop-down list, select one of the following options:
 - Hardware The first SSID Interface that you define is automatically assigned the MAC address of the wireless card.
 - Custom A custom MAC address.
- 6) (Custom MAC address only) In the MAC Address field, enter a MAC address.
- 7) Click the Security tab.
- 8) From the **Security Mode** drop-down list, select the security mode.



Tip: When you select the security mode, the options particular for that mode are enabled. We recommend using one of the WPA security modes.

- If you selected WEP Open System or WEP Shared Key, configure these options.
 - a) From the Key Length drop-down list, select the key length.
 - b) From the **Default Key** drop-down list, select which key is used by default.
 - c) Enter 1–4 encryption keys.
- 10) If you selected WPA Personal, configure these options.
 - a) From the WPA Mode drop-down list, select the WPA mode.
 - b) In the Pre-Shared Key field, enter a pre-shared key of 8 to 64 ASCII characters.
- 11) If you selected **WPA Enterprise**, configure these options.
 - a) From the WPA Mode drop-down list, select the WPA mode.

- b) Next to the Authentication Method field, click Select.
- c) Select the RADIUS authentication method for authenticating users and click Select.
- 12) Click OK.
- 13) Click H Save.

Next steps

Continue the configuration in one of the following ways:

- · Add other types of interfaces.
- Select system communication roles for the interfaces.

Add Switches to Single Firewalls

You can add one integrated switch to each Single Firewall.

An integrated switch eliminates the need for an external switch device and simplifies port and network segment configuration.

The switch functionality is only supported on Single Firewall engines that run on specific Forcepoint NGFW appliances that have an integrated switch.

Steps @ For more details about the product and how to configure features, click Help or press F1.

- 1) In the navigation pane on the left, select Interfaces.
- 2) Right-click the empty space and select New > Switch.
- 3) From the **Switch ID** drop-down list, select the ID according to your switch type. For example, the switch ID of the Forcepoint NGFW 110 appliance is 0. See the *Hardware Guide* for your appliance for more information.
- 4) From the Switch Type drop-down list, select the type of your Forcepoint NGFW switch.
- 5) Click OK.
- 6) Click Save.Do not close the Engine Editor.

Next steps

Add port group interfaces to the switch.

Add Port Group Interfaces to Single Firewalls

You can define one or more port groups interfaces for an integrated switch. Port groups provide a flexible way to group and configure ports and network segments.

Steps • For more details about the product and how to configure features, click **Help** or press **F1**.

- 1) In the navigation pane on the left, select Interfaces.
- Right-click the switch and select New Port Group Interface.
- Define the port group interface properties.
- 4) Click OK.

The port group interface is added to the interface list. The defined switches and port group interfaces are displayed, for example, as "0.1" for switch ID 0 with port group 1.

5) Click Save.Do not close the Engine Editor.

Add IP addresses for Single Firewall interfaces

You can add one or more IP addresses to each interface on a Single Firewall.

The number and types of IP addresses that you can add depend on the interface type.

Table 3: IP addresses for each interface type

Interface type	Static IPv4 addresses	Dynamic IPv4 Addresses	Static IPv6 Addresses	Dynamic IPv6 Addresses
Physical interface	One or more	One	One or more	One
Aggregated Link interface	One or more	None	One or more	None
VLAN interface	One or more	One	One or more	One
ADSL interface	One or more	One	None	None
Port group interface	One or more	One	One or more	One
SSID interface	One	None	One	None

Add static IPv4 addresses to Single Firewall interfaces

Depending on the type of interface, you can add one or more static IPv4 addresses to Single Firewall interfaces.

Steps • For more details about the product and how to configure features, click Help or press F1.

- 1) In the navigation pane on the left, select Interfaces.
- 2) Add an IPv4 address in one of the following ways:
 - Right-click a physical interface, VLAN interface, SSID interface, or port group interface and select New > IPv4 Address.
 - Right-click an ADSL interface and select New IPv4 Address.
- In the IPv4 Address field, enter the IPv4 address.



Tip: To resolve the IP address from a DNS name, right-click the field, then select **Resolve** From DNS Name.

4) In the Netmask field, adjust the automatically added netmask if necessary.
The Network Address and Broadcast IP address are updated accordingly.

- 5) If the interface is used for system communications and NAT is applied, add contact addresses.
 - a) Enter the default contact address in one of the following ways:
 - In the **Default** field, enter the contact address.
 - Select Dynamic and define the translated IP address of this component.
 - b) If components from some locations must use a different IP address for contact, click Exceptions and define the location-specific addresses.
- If you want to use Virtual Router Redundancy Protocol (VRRP), add a virtual router.



Note: One virtual router can be configured for each physical interface, VLAN interface, or port group interface. Although VRRP support is also available, for port group interfaces, it is not normally used.

- a) Click VRRP Settings.
- b) Select Enable VRRP.
- c) Fill in the ID, Priority, and IPv4 Address fields according to the configuration of the virtual router.
- d) Click OK.
- 7) Click OK.

The IPv4 address is added to the interface.

8) Click H Save.

If you plan to add more IP addresses or modem interfaces, do not close the Engine Editor.

Add static IPv6 addresses to Single Firewall interfaces

Depending on the type of interface, you can add one or more static IPv6 addresses to Single Firewall interfaces.

Steps @ For more details about the product and how to configure features, click Help or press F1.

- 1) In the navigation pane on the left, select Interfaces.
- Right-click a physical, VLAN, SSID, or port group interface and select New > IPv6 Address.
- In the IPv6 Address field, enter the IPv6 address.



Tip: To resolve the IP address from a DNS name, right-click the field, then select **Resolve** From DNS Name.

- Enter the Prefix Length (0–128).
- 5) Click OK.
- 6) Click H Save.

If you plan to add more IP addresses or modem interfaces, do not close the Engine Editor.

Add dynamic IPv4 addresses to Single Firewall interfaces

You can configure dynamic IPv4 addresses for physical, VLAN, ADSL, and port group interfaces on Single Firewalls.



Note: Dynamic IP addresses are not supported on Aggregated Link interfaces.

You can identify interfaces that have a dynamic IPv4 address using a DHCP Index. A modem interface always has a dynamic IP address.

Steps @ For more details about the product and how to configure features, click Help or press F1.

- 1) In the navigation pane on the left, select Interfaces.
- 2) Add an IPv4 address in one of the following ways:
 - Right-click a physical interface, VLAN, or port group interface and select New > IPv4 Address.

- Right-click an ADSL interface and select New IPv4 Address.
- 3) In the IP Address Properties dialog box, select Dynamic.
- 4) From the **Dynamic Index** drop-down list, select a DHCP index.

The index is used for identification in other parts of the configuration (such as Firewall Policies) to represent the possibly changing IP address.

- 5) If the interface is used for system communications and NAT is applied, add contact addresses.
 - If the default contact address is not dynamic, deselect Dynamic and enter the static contact address.
 - b) If components from some locations must use a different IP address for contact, click **Exceptions** and define the location-specific addresses.
- 6) If the interface's dynamic IP address is assigned through PPPoA or PPPoE, set up PPP.
 - a) Click PPP Settings.
 - b) From the **Mode** drop-down list, select the mode that the ADSL modem connected to the interface supports.
 - **PPPoE** can be used with physical interfaces, ADSL interfaces, or port group interfaces. **PPPoA** can be used with ADSL interfaces only.
 - c) Fill in the User Name, Password, and (optional) Service Name fields according to the information provided by your service provider.
 - If you do not have this information, contact your service provider.



Tip: Select **Hide** to hide the input password characters.

- d) Click OK.
- 7) Click OK.

The dynamic IPv4 address is added to the interface.

8) Click H Save.

If you plan to add more IP addresses or modem interfaces, do not close the Engine Editor.

Add dynamic IPv6 addresses to Single Firewall interfaces

You can add dynamic IPv6 addresses to physical interfaces, VLAN interfaces, and port group interfaces on Single Firewalls.



Note: Dynamic IP addresses are not supported on Aggregated Link interfaces.

You can identify interfaces that have a dynamic IPv6 address using a DHCP Index.

Steps @ For more details about the product and how to configure features, click Help or press F1.

- 1) In the navigation pane on the left, select Interfaces.
- Right-click a physical interface and select New > IPv6 Address.
- 3) In the IP Address Properties dialog box, select Dynamic.
- 4) From the **Dynamic Index** drop-down list, select a DHCP index.

The index is used for identification in other parts of the configuration (such as IPS Policies) to represent the possibly changing IP address.

- 5) If the interface is used for system communications and NAT is applied, add contact addresses.
 - a) Enter the default contact address in one of the following ways:
 - In the **Default** field, enter the contact address.
 - Select **Dynamic** and define the translated IP address of this component.
 - b) If components from some locations must use a different IP address for contact, click **Exceptions** and define the location-specific addresses.
- 6) (Optional) If you do not want a default route to be automatically created through the interface, deselect **Automatic Default Route**.
- 7) (Optional) If you want to use DHCPv6 to get the IPv6 address, select Use DHCPv6 to get IPv6 Address.
- 8) Click OK.

The IP address is added to the interface.

9) Click H Save.

If you plan to add more IP addresses or modem interfaces, do not close the Engine Editor.

Add Modem Interfaces to Single Firewalls

You can use 3G modems with Single Firewalls to provide wireless links for outbound connections.

Two active 3G modems are supported on Forcepoint NGFW appliances.

Steps @ For more details about the product and how to configure features, click Help or press F1.

- 1) In the navigation pane on the left, select **Interfaces**.
- 2) Right-click the empty space and select New > Modem Interface.
- 3) In the **Modem Number** field, select the modem number that is mapped to the modem's IMEI (international mobile equipment identity) number.

- 4) In the DHCP index field, select the DHCP index number.
 It is used to distinguish different DHCP interfaces from one another.
- 5) In the PIN field, enter the PIN code if it is needed for the modem's SIM card.
- In the Phone Number field, enter the modem's phone number if it differs from the default phone number.
- 7) Fill in the Access Point Name, Username, Password, Service Name, and Zone fields according to the instructions that you have received from your service provider.
- 8) Click OK.

The Modem Interface is added to the interface list.

9) Click H Save.

If you plan to add more interfaces or change the roles that interfaces have in system communications, do not close the Engine Editor.

Select system communication roles for Single Firewall interfaces

Select which IP addresses are used for particular roles in system communications.

For example, you can select which IP addresses are used in communications between the Firewall and the Management Server.

The interfaces you have defined are shown as a tree-table on the Interfaces tab. Global interface options have codes in the tree-table.

Table 4: Interface option codes

Code	Description
А	The interface that has the IP address used as the identity for authentication requests.
С	The interfaces that have the primary and backup control IP addresses.
0	The default IP address for outgoing connections.

Steps • For more details about the product and how to configure features, click Help or press F1.

- In the navigation pane on the left, select Interfaces > Interface Options.
- 2) Select the interface options.
 - a) From the **Primary** drop-down list, select the primary control IP address for Management Server contact.
 - **b)** (Optional, recommended) From the **Backup** drop-down list, select a backup control IP address for Management Server contact (used if the primary fails).

- c) If the control IP address for Management Server contact is a dynamic IP address, select Node-initiated contact to Management Server.
 - When this option is selected, the engine opens a connection to the Management Server and maintains connectivity.
- d) From the Identity for Authentication Requests drop-down list, select the IP address that identifies the firewall to external authentication servers.

Note: This selection has no effect on routing.

e) (Optional) From the Source for Authentication Requests drop-down list, select the IP address that identifies the firewall when it sends an authentication request to an external authentication server over a VPN.



Note: This selection has no effect on routing.

- f) From the Default IP Address for Outgoing Traffic drop-down list, select the IP address that nodes use if they have to initiate connections through an interface that has no Node Dedicated IP address.
- 3) Click H Save, then close the Engine Editor.

Next steps

Bind engine licenses to the Single Firewall elements.

Bind engine licenses to Single Firewall elements

After you have configured the Single Firewall elements, you must manually bind Management Server POL-bound licenses to specific Single Firewall elements.

Licenses are created based on the Management Server's proof-of-license (POL) code or based on the appliance's proof-of-serial (POS) code. POS-bound appliance licenses are automatically bound to the correct Firewall element when the engine is fully installed.

Steps • For more details about the product and how to configure features, click **Help** or press **F1**.

- 1) Select . Configuration, then browse to Administration.
- 2) Browse to Licenses > Engine or Licenses > Firewall depending on the type of licenses you have.

 All installed licenses appear in the right pane.
- 3) Right-click a Management Server POL-bound license and select Bind.
- 4) Select the Firewall element and click Select.
 The license is now bound to the selected Firewall element.



Tip: If you bound the license to an incorrect element, right-click the license and select **Unbind**.



CAUTION: When you install or refresh the policy on the engine, the license is permanently bound to that engine. Permanently bound licenses can't be rebound to another engine without relicensing or deleting the engine element the license is bound to. Until you do that, the unbound license is shown as Retained.

Next steps

Transfer the configuration to the Firewall engines.

Related concepts

Options for initial configuration on page 143

Configuring Firewall Clusters

After you have the SMC installed and running, you can configure the Firewall Cluster elements.

Little configuration is done directly on the engines. Most of the configuration is done using the Management Client. The engines cannot be successfully installed before defining them in the Management Client.

The tasks you must complete are as follows:

- 1) Add Firewall Cluster elements.
- 2) Add the necessary number of nodes to the Firewall Cluster.
- Add interfaces and define their properties.
- (Optional) Select system communication roles for the interfaces.
- Bind Management Server POL-bound licenses to specific nodes in the Firewall Cluster.

Types of interfaces for Firewall Clusters

Interface numbers identify the interfaces for a Firewall Cluster element.

There are two types of interfaces on Firewall Clusters:

- A physical interface represents an Ethernet port of a network interface card on the engine.
 - Each physical interface has a unique interface ID number in the SMC.
 - You can add VLAN interfaces to physical interfaces to divide a single physical network link into several virtual links.
- A tunnel interface is a logical interface that is used as an endpoint for tunnels in the Route-Based VPN.

- Tunnel interfaces are numbered with *tunnel interface ID* numbers. The tunnel interface IDs are automatically mapped to the network interfaces on the engine according to the routing configuration.
- For detailed information about configuring tunnel interfaces and the Route-Based VPN, see the *Forcepoint Next Generation Firewall Product Guide*.

The interface IDs are mapped to the corresponding network interfaces on the engine when you configure the Forcepoint NGFW engine software. Check the correct interface numbers in the *Hardware Guide* for your appliance model.



Note: If you configure the engine automatically with a USB drive, the interface IDs in the SMC are mapped to match the interface numbering in the operating system. For example, eth0 is mapped to Interface ID 0.

If necessary, you can change the interface ID and modem number mapping after the initial configuration using the command-line tools on the engine.

Operating modes for Firewall Cluster interfaces

There are several operating modes for the physical interfaces of a Firewall Cluster. Packet dispatch mode is recommended for new installations.

The other modes are provided for backward compatibility. See the *Forcepoint Next Generation Firewall Product Guide* for more information about the other operating modes.

In packet dispatch mode:

- There is only one contact MAC address for each physical interface. The dispatcher node controls this MAC address.
- The dispatcher node forwards the packets to the other nodes for processing. Any node in the cluster can process the traffic.
- The dispatcher node is chosen separately for each physical interface.



Note: Different nodes might be selected as dispatcher nodes for different physical interfaces.

The packet dispatcher for the physical interface changes automatically if the dispatcher goes offline. When the dispatcher changes:

- The packet dispatcher MAC address is moved to another firewall node.
- The firewall sends an ARP message to the external switch or router.
- The switch or router updates its address table.



Note: This process is a standard network addressing operation where the switch or router learns that the MAC address is located behind a different port.

• The switch or router forwards traffic destined to the physical interface to this new packet dispatcher.

Add Firewall Cluster elements

To introduce a new Firewall Cluster to the SMC, you must define a Firewall Cluster element that stores the configuration information related to the Firewalls.

Steps 9 For more details about the product and how to configure features, click **Help** or press **F1**.

- 1) Select . Configuration.
- Right-click NGFW Engines and select New > Firewall > Firewall Cluster.
 The Engine Editor opens.
- In the Name field, enter a unique name.
- 4) From the Log Server drop-down list, select the Log Server for storing this Firewall Cluster's logs.
- 5) (Optional) In the DNS IP Addresses list, add one or more DNS IP addresses.

These addresses are the IP addresses of the DNS servers that the Firewall Cluster uses to resolve malware signature mirrors, domain names, and web filtering categorization services. There are two ways to define IP addresses:

- To enter a single IP address manually, click Add and select Add IP Address. Enter the IP address in the dialog that opens.
- To define an IP address by using a network element, click Add and select Add Network Element.
- 6) From the Location drop-down list, select the Location to which the firewall belongs.
- 7) Click H Save.

Do not close the Engine Editor.

Add nodes to Firewall Clusters

The Firewall Cluster element has two nodes when the element is created.

Firewall Clusters can have up to 16 nodes. Add all nodes you plan to install before you begin configuring the interfaces.

Steps @ For more details about the product and how to configure features, click Help or press F1.

- 1) In the navigation pane on the left, select General > Clustering.
- 2) (Optional) In the Name field, change the name.
- 3) Click OK.

The node is added to the Firewall Cluster.

4) Click H Save.

Do not close the Engine Editor.

Add physical interfaces to Firewall Clusters

To route traffic through the Firewall Cluster, you must define at least two physical interfaces.

We recommend defining at least two interfaces for the Firewall Cluster:

- An interface used for communications between the Management Server and the Firewall.
- An interface for the heartbeat communications between the cluster nodes. The heartbeat traffic is critical to the functioning of the cluster, so it is highly recommended to have a dedicated heartbeat interface.

Although you can configure more interfaces at any later time, it is simplest to add more interfaces right away. This action allows traffic to be routed through the Firewall. You can use the Cluster installation worksheet to document the interfaces.

There are three types of physical interfaces on Firewall Clusters:

- An interface that corresponds to a single network interface on each node in the Firewall Cluster. In the Management Client, the interface type is **None**.
- An aggregated link in high availability mode represents two interfaces on each node. Only the first interface in
 the aggregated link is actively used. The second interface becomes active only if the first interface fails.
 Connect the first interface in the link to one external switch and the second interface to another external
 switch.
- An aggregated link in load balancing mode represents two or more interfaces (up to eight interfaces) on each node. All interfaces in the aggregated link are actively used and connections are automatically balanced between the interfaces.
 - Link aggregation in load-balancing mode is implemented based on the IEEE 802.3ad Link Aggregation standard. Connect all interfaces to a single external switch. Make sure that the switch supports the Link Aggregation Control Protocol (LACP) and that LACP is configured on the switch.

Steps @ For more details about the product and how to configure features, click Help or press F1.

- 1) In the navigation pane on the left, select Interfaces.
- 2) Right-click the empty space and select New Physical Interface.
- 3) From the Interface ID drop-down list, select an interface ID number.
 This ID maps to a network interface during the initial configuration of the engine.
- 4) From the **Type** drop-down list, select the interface type.
- If the type is Aggregated Link, select one or more other interfaces that belong to the aggregated link.
 - For an aggregated link in high availability mode, select an interface ID from the Second Interface ID drop-down list.
 - For an aggregated link in load balancing mode, click Add to add one or more interface IDs to the Additional Interface(s) list.

6) Leave Packet Dispatch selected as the CVI Mode and add a MAC Address with an even number as the first octet.



Important: This MAC address must not belong to any actual network card on any of the nodes.

- Packet Dispatch is the primary clustering mode in new installations.
- Different CVI modes can be used for different interfaces of a Firewall Cluster without limitations.



Note: All CVI addresses that are defined for the same physical interface must use the same unicast MAC address. The dispatcher nodes use the MAC address you define here. Other nodes use their network card's MAC address.

- (Optional) In the MTU field, enter the MTU value if this link requires a lower MTU than the Ethernet-default 1500.
- 8) Click OK.
- 9) Click H Save.

Do not close the Engine Editor.

Add VLAN Interfaces to Firewall Clusters

VLANs divide a single physical network link into several virtual links.

You can add up to 4094 VLANs to each physical interface.

Steps • For more details about the product and how to configure features, click **Help** or press **F1**.

- 1) In the navigation pane on the left, select Interfaces.
- Right-click a physical interface and select New > VLAN Interface.
- 3) In the VLAN ID field, enter a VLAN ID number (1-4094).



Note: The VLAN ID must be the same VLAN ID used in the external switch at the other end of the VLAN trunk.

4) Click OK.

The specified VLAN ID is added to the physical interface.

5) Click H Save.

Do not close the Engine Editor.

Result

The VLAN interface is now ready to be used as a network interface. The VLAN interface is identified as Interface-ID.VLAN-ID, for example 2.100 for interface ID 2 and VLAN ID 100.

Add IP addresses for Firewall Cluster interfaces

To route traffic through the firewall, each Firewall Cluster interface must have at least two IP addresses. Firewall Clusters can have two types of IP addresses.

Table 5: Types of IP addresses for Firewall Clusters

Interface type	Description	When to use it
Cluster Virtual IP address (CVI)	An IP address that is used to handle traffic routed through the cluster for inspection. All nodes in a cluster share this IP address. Allows other devices to communicate with the Firewall Cluster as a single entity.	Define a CVI for the interface if traffic that the firewall inspects is routed to or from the interface.
Node Dedicated IP address (NDI)	An IP address that is used for traffic to or from an individual node in a cluster. Each node in the cluster has a specific IP address that is used as the NDI. Used for the heartbeat connections between the engines in a cluster, for control connections from the Management Server, and other traffic to or from individual nodes.	Define at least two NDIs: one for management connections and one for the heartbeat traffic between the nodes. We recommend that you define an NDI for each interface that has a CVI, if practical. Some features might not work reliably without an NDI.

You can define several CVIs and NDIs on the same physical interface or VLAN interface. A physical interface or a VLAN interface can have only a CVI or only an NDI.

IPv6 addresses are supported on Firewall Clusters with dispatch clustering mode. IPv6 and IPv4 addresses can be used together on the same Firewall Cluster.

Add IPv4 addresses to Firewall Cluster interfaces

Add an IPv4 address to a Firewall Cluster interface.

Steps @ For more details about the product and how to configure features, click Help or press F1.

- 1) In the navigation pane on the left, select Interfaces.
- Right-click a physical interface or VLAN interface and select New > IPv4 Address.
- Select the types of IP addresses that you want to add using the Cluster Virtual IP Address and Node Dedicated IP Address options.
 - By default, both are selected. If the interface does not receive or send traffic that the Firewall examines, there is no need to define a Cluster Virtual IP address (CVI). We recommend adding a Node Dedicated IP address (NDI) for each network or subnetwork that is located behind the physical interface.

4) To add a CVI, enter the IP address in the IPv4 Address field in the Cluster Virtual IP Address section.



Tip: To resolve the IP address from a DNS name, right-click the field, then select **Resolve From DNS Name**.

- If the CVI is used for system communications and NAT is applied, define a contact address for the CVI.
 - a) Enter the default contact address in one of the following ways:
 - · In the **Default** field, enter the contact address.
 - Select Dynamic and define the translated IP address of this component.
 - b) If components from some locations must use a different IP address for contact, click **Exceptions** and define the location-specific addresses.
- To add NDIs for the nodes, enter the IP address in the IPv4 Address field for each node in the Node Dedicated IP Address table.



Tip: To resolve the IP address from a DNS name, right-click the field, then select **Resolve From DNS Name**.

- 7) If the NDIs are used for system communications and NAT is applied, define a contact address for the NDIs.
 - a) Double-click the node's Contact Address cell.
 - b) In the **Default** field, enter the contact address.
 - c) (Optional) If components from some locations must use a different IP address for contact, click Add and define the location-specific addresses.
 - d) Click OK.
- (Optional) In the Netmask field, change the automatically added netmask if necessary.
- 9) Click OK.

The IPv4 addresses are added to the interface.

10) Click H Save.

If you plan to add more IP addresses, or change the roles that interfaces have in system communications, do not close the Engine Editor.

Add IPv6 addresses to Firewall Cluster interfaces

Add an IPv6 address for a Firewall Cluster interface.

Steps • For more details about the product and how to configure features, click Help or press F1.

- 1) In the navigation pane on the left, select Interfaces.
- Right-click a physical interface or a VLAN interface and select New > IPv6 Address.
- Select the types of IP addresses that you want to add using the Cluster Virtual IP Address and Node Dedicated IP Address options.

By default, both are selected.

- If the interface does not receive or send traffic that the firewall examines, there is no need to define a
 Cluster Virtual IP address.
- We recommend that you add a Node Dedicated IP address for each (sub)network that is located behind the Physical Interface.
- 4) If you are adding a Cluster Virtual IP address, in the IPv6 Address field, enter the IP address that is used as the Cluster Virtual IP address.



Tip: To resolve the IP address from a DNS name, right-click the field, then select **Resolve** From DNS Name.

5) If you are adding a Node Dedicated IP address for the nodes, double-click the IPv6 Address cell for each node and enter the IP address.



Tip: To resolve the IP address from a DNS name, right-click the field, then select **Resolve** From DNS Name.

- 6) (Optional) In the Prefix Length field, change the automatically filled in prefix length (0-128).
- 7) Click OK.
- 8) Click H Save.

If you plan to add more IP addresses, or change the roles that interfaces have in system communications, do not close the Engine Editor.

Select system communication roles for Firewall Cluster interfaces

Select which IP addresses are used for particular roles in system communications.

For example, you can select which IP addresses are used in communications between the Firewall Cluster and the Management Server.

The interfaces you have defined are shown as a tree-table on the Interfaces tab. Global interface options have codes in the tree-table.

Table 6: Interface option codes

Code	Description
А	The interface that has the IP address used as the identity for authentication requests.
С	The interfaces that have the primary and backup control IP addresses.
Н	The primary and backup heartbeat Interfaces.
0	The default IP address for outgoing connections.

Steps 9 For more details about the product and how to configure features, click **Help** or press **F1**.

- 1) In the navigation pane on the left, select Interfaces > Interface Options.
- 2) Select the interface options.
 - a) From the Primary control IP address drop-down list, select the primary control IP address for communications with the Management Server.
 - **b)** (Optional, recommended) In the **Backup** control IP address drop-down list, select a backup control IP address for Management Server contact (used if the primary fails).
 - From the Primary heartbeat drop-down list, select the primary interface for communications between the nodes.

We recommend using a physical interface, not a VLAN interface. We strongly recommend that you do not direct any other traffic through this interface. A dedicated network helps guarantee reliable and secure operation.



CAUTION: Primary and backup heartbeat networks exchange confidential information. If dedicated networks are not possible, configure the cluster to encrypt the exchanged information.

- d) From the **Backup** heartbeat drop-down list, select the backup heartbeat interface that is used if the primary heartbeat interface is unavailable.
 - It is not mandatory to configure a backup heartbeat interface, but we strongly recommend it. If heartbeat traffic is not delivered, the cluster cannot operate and traffic is disturbed. We strongly recommend that you use a dedicated interface for the backup heartbeat as well.
- e) From the Identity for Authentication Requests drop-down list, select the IP address that identifies the firewall to external authentication servers.



Note: This selection has no effect on routing.

f) (Optional) From the Source for Authentication Requests drop-down list, select the IP address that identifies the firewall when it sends an authentication request to an external authentication server over a VPN.



Note: This selection has no effect on routing.

- g) From the Default IP Address for Outgoing Traffic field, select the IP address that the nodes use if they have to initiate connections through an interface that has no Node Dedicated IP address.
- 3) Click H Save.

Next steps

Continue the configuration in one of the following ways:

- If an interface used for external connections has only a Cluster Virtual IP address, add manual ARP entries for the nodes.
- Bind the engine licenses to the nodes in the Firewall Cluster.

Add manual ARP entries for Firewall Clusters

ARP entries are normally managed automatically based on the Firewall's routing configuration. However, you can also add manual ARP entries for the nodes.

If an interface used for external connections has only a cluster virtual IP address (CVI), you must add a static ARP entry. This entry gives the node a permanent reference to an IP address and MAC address.

Steps • For more details about the product and how to configure features, click Help or press F1.

- 1) In the navigation pane on the left, select Interfaces > ARP Entries.
- Click Add ARP Entry.A new entry is added to the table.
- Click Type and select Static.
- Click Interface ID and select the interface on which the ARP entry is applied.
- 5) Double-click IP Address and enter the IP address information.
- Double-click MAC Address and enter the MAC address information.
- 7) Click OK.
- 8) Click | Save, then close the Engine Editor.

Next steps

Bind the engine licenses to the nodes of the Firewall Cluster.

Bind engine licenses to Firewall Cluster elements

After you have configured the Firewall Cluster elements, you must manually bind Management Server POL-bound licenses to specific nodes in Firewall Cluster elements.

Licenses are created based on the Management Server's proof-of-license (POL) code or based on the appliance's proof-of-serial (POS) code. POS-bound appliance licenses are automatically bound to the correct Firewall element when the engine is fully installed. Each engine is licensed separately even when the engines are clustered.

Steps • For more details about the product and how to configure features, click Help or press F1.

- 1) Select . Configuration, then browse to Administration.
- 2) Browse to Licenses > NGFW Engines or Licenses > Firewall depending on the type of licenses you have. All installed licenses appear in the right pane.
- Right-click a Management Server POL-bound license and select Bind.
- 4) Select the node and click **Select**.

The license is now bound to the selected Firewall element.



Tip: If you bound the license to an incorrect element, right-click the license and select **Unbind**.



CAUTION: When you install or refresh the policy on the engine, the license is permanently bound to that engine. Permanently bound licenses cannot be rebound to another engine without relicensing or deleting the engine element the license is bound to. Until you do that, the unbound license is shown as Retained.

Next steps

Transfer the configuration to the Firewall engines.

Related concepts

Options for initial configuration on page 143

CHAPTER 6

Configuring Forcepoint NGFW for the IPS role

Contents

- Install licenses for NGFW Engines on page 93
- Configuring IPS engines on page 94
- Bind engine licenses to IPS elements on page 107

Configuring engine elements in the SMC prepares the SMC to manage Forcepoint NGFW in the IPS role.

Install licenses for NGFW Engines

Install the NGFW Engine licenses that you downloaded while preparing for installation.

Before you begin

The license files must be available to the computer that you use to run the Management Client.

You can install all licenses at the same time even though you have not yet created all elements that the licenses are bound to.

Steps 9 For more details about the product and how to configure features, click Help or press F1.

- 1) In the Management Client, select ≡ Menu > System Tools > Install Licenses.
- Select one or more license files to install in the dialog box that opens and click Install.
- 3) To check that the licenses were installed correctly, select . Configuration, then browse to Administration > Licenses > All Licenses.
 - One license shows for each NGFW Engine node. You must bind POL-bound engine licenses manually to the correct engines after you have configured the engine elements. POS-bound engine licenses are automatically attached to the correct engines after the engine is fully installed.

Next steps

Define the engine elements.

Configuring IPS engines

IPS elements are a tool for configuring nearly all aspects of your physical IPS components.

Little configuration is done directly on the engines. Most of the configuration is done using the Management Client. You cannot successfully install the engines before defining them in the SMC as outlined.

An important part of the IPS engine elements is the interface definitions. There are two main categories of IPS engine interfaces:

Table 7: IPS engine interfaces

Purpose of interface	Interface type	When to use it
System communications	Normal	These interfaces are used when the IPS engine is the source or the final destination of the communications. An example is control communications between the IPS engine and the Management Server.
		Define at least one interface that is dedicated to system communications for each IPS element.
Traffic inspection	Capture, Inline	Define one or more traffic inspection interfaces for each IPS engine element.

The interfaces have their own numbering in the SMC called *interface ID*. The interface IDs are mapped to the corresponding network interfaces on the engine when you configure the Forcepoint NGFW software.



Note: If you configure the engine automatically with a USB drive, the interface IDs in the SMC are mapped to match the interface numbering in the operating system. For example, eth0 is mapped to Interface ID 0.

If necessary, you can change the interface ID mapping after the initial configuration using the command-line tools on the engine.

After you have the SMC installed and running, you can configure the IPS engines.

The tasks you must complete are as follows:

- Add Single IPS or IPS Cluster elements.
- Add system communication interfaces.
- Add traffic inspection interfaces.
- Bind licenses to specific IPS elements.

Add IPS elements

To add IPS engines to the SMC, add a Single IPS element or an IPS Cluster element that stores the configuration information related to the IPS engine.

This procedure covers the basic configuration of IPS engine elements. For complete instructions about configuring IPS engines, see the Forcepoint Next Generation Firewall Product Guide.

Steps @ For more details about the product and how to configure features, click Help or press F1.

- 1) Select . Configuration.
- 2) Right-click NGFW Engines and select one of the following:
 - New > IPS > IPS Cluster
 - New > IPS > Single IPS

The Engine Editor opens.

- In the Name field, enter a unique name.
- 4) From the Log Server drop-down list, select the Log Server for storing this IPS engine's logs. If no Log Server is selected, the engine does not make any traffic recordings.
- 5) (Optional) In the DNS IP Addresses list, add one or more DNS IP addresses. These addresses are the IP addresses of the DNS servers that the IPS engine uses to resolve domain names and web filtering categorization services (which are defined as URLs).
 - To enter a single IP address manually, click Add and select IP Address. Enter the IP address in the dialog that opens.
 - To define an IP address by using a network element, click Add and select Network Element. Select a
 Host or External DNS Server element.
- 6) From the Location drop-down list, select the Location to which the IPS belongs.
- 7) Click Save.Do not close the Engine Editor.

Add system communication interfaces to IPS engines

Each IPS engine needs at least one interface for communicating with the SMC.

You can add more than one system communication interface to provide a primary and a backup interface for Management Server communications.

Add physical interfaces to IPS elements

Add a physical interface for system communications.

Steps @ For more details about the product and how to configure features, click Help or press F1.

- 1) In the navigation pane on the left, select **Interfaces**.
- Right-click the empty space and select New Physical Interface.

- 3) From the Interface ID drop-down list, select an ID number. This ID maps to a network interface during the initial configuration of the engine.
- 4) From the Type drop-down list, select Normal Interface.
- 5) Click OK.

The physical interface is added to the interface list

6) Click H Save.

Do not close the Engine Editor.

Next steps

Continue the configuration in one of the following ways:

- Add VLANs to the physical interface.
- Add IP addresses to the physical interface.

Related tasks

Add static IPv4 addresses to Single IPS interfaces on page 97 Add IP addresses to IPS Cluster interfaces on page 100

Add VLAN interfaces to IPS elements

VLANs divide a single physical network link into several virtual links.

You can add up to 4094 VLANs to each physical interface.



CAUTION: Do not add any manual VLAN definitions to an interface you want to use for sending resets. Adding VLANs prevents selecting the interface as a reset interface and also removes the reset interface from any existing selections.

Steps @ For more details about the product and how to configure features, click Help or press F1.

- 1) In the navigation pane on the left, select Interfaces.
- Right-click a physical interface and select New > VLAN Interface.
- In the VLAN ID field, enter a VLAN ID number (1-4094).



Note: The VLAN ID must be the same VLAN ID used in the external switch at the other end of the VLAN trunk.

Click OK.

The specified VLAN ID is added to the physical interface.

5) Click H Save.

Do not close the Engine Editor.

Result

The VLAN interface is now ready to be used as a network interface. The VLAN interface is identified as Interface-ID.VLAN-ID, for example 2.100 for interface ID 2 and VLAN ID 100.

Add static IPv4 addresses to Single IPS interfaces

You can add one or more static IPv4 addresses to each physical or VLAN interface on a Single IPS engine.

Steps • For more details about the product and how to configure features, click **Help** or press **F1**.

- 1) In the navigation pane on the left, select Interfaces.
- 2) Right-click a Physical Interface or a VLAN Interface and select New > IPv4 Address.
- 3) In the IPv4 Address field, enter the IPv4 address.



Tip: To resolve the IP address from a DNS name, right-click the field, then select **Resolve** From DNS Name.

4) Click Netmask and adjust the automatically added netmask if necessary.

The Network Address and Broadcast IP Address are updated accordingly

- If the interface is used for system communications and NAT is applied, add contact addresses.
 - a) Enter the default contact address in one of the following ways:
 - In the Default field, enter the contact address.
 - Select Dynamic and define the translated IP address of this component.
 - b) If components from some locations must use a different IP address for contact, click **Exceptions** and define the location-specific addresses.
- 6) Click OK.

The IP address is added to the interface.

7) Click H Save.

If you plan to add more IP addresses or change the roles that interfaces have in system communications, do not close the Engine Editor.



Tip: Write down the networks to which each Interface ID is connected.

Add dynamic IPv4 addresses to Single IPS interfaces

You can add one dynamic IPv4 address to each physical or VLAN interface on a Single IPS engine.

Steps @ For more details about the product and how to configure features, click Help or press F1.

- 1) In the navigation pane on the left, select Interfaces.
- Right-click a Physical Interface or a VLAN Interface and select New > IPv4 Address.
- 3) Select Dynamic.
- 4) From the **Dynamic Index** drop-down list, select a DHCP index.

The index is used for identification in other parts of the configuration (such as IPS Policies) to represent the possibly changing IP address.

- 5) If the interface is used for system communications and NAT is applied, add contact addresses.
 - a) Enter the default contact address in one of the following ways:
 - In the Default field, enter the contact address.
 - Select Dynamic and define the translated IP address of this component.
 - b) If components from some locations must use a different IP address for contact, click **Exceptions** and define the location-specific addresses.
- 6) Click OK.

The IP address is added to the interface.

Click H Save.

If you plan to add more IP addresses or change the roles that interfaces have in system communications, do not close the Engine Editor.



Tip: Write down the networks to which each Interface ID is connected.

Add static IPv6 addresses to Single IPS interfaces

You can add one or more static IPv6 addresses to each physical or VLAN interface on a Single IPS engine.

Steps For more details about the product and how to configure features, click **Help** or press **F1**.

1) In the navigation pane on the left, select Interfaces.

- 2) Right-click a Physical Interface or a VLAN Interface and select New > IPv6 Address.
- 3) In the IPv6 Address field, enter the IPv6 address.



Tip: To resolve the IP address from a DNS name, right-click the field, then select **Resolve** From DNS Name.

- Click Prefix Length and adjust the automatically added prefix length if necessary.
- 5) Click OK.

The IP address is added to the interface.

Click H Save.

If you plan to add more IP addresses or change the roles that interfaces have in system communications, do not close the Engine Editor.



Tip: Write down the networks to which each Interface ID is connected.

Add dynamic IPv6 addresses to Single IPS interfaces

You can add one dynamic IPv6 address to each physical or VLAN interface on a Single IPS engine.

Steps 9 For more details about the product and how to configure features, click **Help** or press **F1**.

- 1) In the navigation pane on the left, browse to **Interfaces**.
- 2) Right-click a Physical Interface or a VLAN Interface and select New > IPv6 Address.
- 3) Select Dynamic.
- 4) From the **Dynamic Index** drop-down list, select a DHCP index.

The index is used for identification in other parts of the configuration (such as IPS Policies) to represent the possibly changing IP address.

- If the interface is used for system communications and NAT is applied, add contact addresses.
 - a) Enter the default contact address in one of the following ways:
 - In the Default field, enter the contact address.
 - Select **Dynamic** and define the translated IP address of this component.
 - b) If components from some locations must use a different IP address for contact, click Exceptions and define the location-specific addresses.
- (Optional) If you do not want a default route to be automatically created through the interface, deselect Automatic Default Route.

- 7) (Optional) If you want to use DHCPv6 to get the IPv6 address, select Use DHCPv6 to get IPv6 Address.
- 8) Click OK.

The IP address is added to the interface.

Click H Save.

If you plan to add more IP addresses or change the roles that interfaces have in system communications, do not close the Engine Editor.



Tip: Write down the networks to which each Interface ID is connected.

Add IP addresses to IPS Cluster interfaces

You can add IP addresses to each node of an IPS Cluster.

You can add both IPv4 and IPv6 addresses to the same interface.

Steps • For more details about the product and how to configure features, click **Help** or press **F1**.

- 1) In the navigation pane on the left, browse to Interfaces.
- 2) Right-click a physical interface or a VLAN interface and add the IP address in one of the following ways:
 - To add an IPv4 address, select New > IPv4 Address
 - To add an IPv6 address, select New > IPv6 Address
- Click the IPv4 Address or IPv6 Address cell in the table and enter the IP address for each node.



Tip: To resolve the IP address from a DNS name, right-click the field, then select **Resolve From DNS Name**.

- 4) (IPv4 addresses only) If necessary, double-click the **Contact Address** cell in the table and define the contact address for each node.
 - In the Default field at the top of the dialog box, enter the default contact address. The default contact address is used by default whenever a component that belongs to another Location connects to this interface.
 - If components from some Locations cannot use the default contact address, click Add to define Locationspecific contact addresses.
- 5) (IPv4 addresses only) Check the automatically filled-in Netmask and adjust it as necessary.
- 6) (IPv6 addresses only) Check the automatically filled-in Prefix Length and adjust it as necessary.
- 7) Click OK.
- 8) Click H Save.

Next steps

Continue the configuration in one of the following ways:

- Select system communication roles for the interfaces.
- Add traffic inspection interfaces.

Select system communication roles for IPS interfaces

Select which interfaces are used for which types of system communications.

Steps 9 For more details about the product and how to configure features, click **Help** or press **F1**.

- 1) In the navigation pane on the left, browse to Interfaces > Interface Options.
- 2) Select the interface options.
 - a) From the Primary control IP address drop-down list, select the primary control IP address for communications with the Management Server.
 - b) (Optional, recommended) In the **Backup** control IP address drop-down list, select a backup control IP address for Management Server contact (used if the primary fails).
 - c) (IPS Cluster only) From the **Primary** heartbeat drop-down list, select the primary interface for communications between the nodes.



Important: This interface must not be a VLAN Interface.



CAUTION: Heartbeat traffic is time-critical. A dedicated network (without other traffic) is recommended for security and reliability of heartbeat communication.

- **d)** (IPS Cluster only) From the **Backup** heartbeat drop-down list, select the backup heartbeat interface that is used if the primary heartbeat interface is unavailable.
 - It is not mandatory to configure a backup heartbeat interface, but we strongly recommend it. If heartbeat traffic is not delivered, the cluster cannot operate and traffic is disturbed. We strongly recommend that you use a dedicated interface for the backup heartbeat as well.
- e) (Single IPS only) If the control IP address for Management Server contact is a dynamic IP address, select Node-initiated contact to Management Server.
 - When this option is selected, the engine opens a connection to the Management Server and maintains connectivity.
- f) From the **Default IP Address for Outgoing Traffic** drop-down list, select the IP address that nodes use if they have to initiate connections through an interface that has no Node Dedicated IP address.
- Click H Save.

Add traffic inspection interfaces to IPS engines

IPS engines pick up passing network traffic for inspection in real time.

You can define both capture interfaces and inline interfaces for the same IPS engine.

Table 8: Types of traffic inspection interfaces for IPS engines

Interface type	Inspection	Response
Capture interface	The traffic is passively captured for inspection.	The engine can reset traffic picked up through capture interfaces if you set up specific reset interfaces. The reset interfaces can send TCP resets and ICMP "destination unreachable" messages when the communications trigger a response.
		You can use a system communications interface for sending resets if the resets are routed correctly through that interface and there are no VLANs on the interface.
Inline interface	Traffic is actively inspected as it flows through the inline interfaces.	The engine actively filters the traffic that attempts to pass through its inline interfaces.

When traffic is inspected, it might be important to know the interface through which it arrives to the IPS engine. It is also important to be able to distinguish an IPS engine's capture interfaces from its inline interfaces. Logical interface elements are used for both these purposes. They allow you to group interfaces that belong to the same network segment and to identify the type of the traffic inspection interface.

Define a logical interface in the following cases:

- You want to create both capture interfaces and inline interfaces on the same IPS engine.
- You want to distinguish interfaces from each other.

Next steps

Continue the configuration in one of the following ways:

- If you want to use reset interfaces with capture interfaces, add reset interfaces.
- Add capture interfaces or inline interfaces.

Add logical interfaces to IPS engines

Logical Interface elements are used in the IPS Policy and the traffic inspection process to represent a network segment.

The SMC contains one default Logical Interface element. A logical interface can represent any number or combination of physical interfaces and VLAN interfaces. However, the same logical interface cannot be used to represent both capture interfaces and inline interfaces on the same IPS engine. The rules in the ready-made IPS Template policy match all logical interfaces.

Steps • For more details about the product and how to configure features, click **Help** or press **F1**.

1) Select . Configuration.

- 2) Expand the Other Elements branch.
- 3) Right-click Logical Interfaces and select New Logical Interface.
- 4) In the Name field, enter a unique name.
- 5) (Optional) If you use VLAN tagging, select View interface as one LAN.
 By default, the IPS engine treats a single connection as multiple connections when an external switch passes traffic between different VLANs and all traffic is mirrored to the IPS engine through a SPAN port.
- 6) Click OK.

Next steps

Continue the configuration in one of the following ways:

- If you want to use reset interfaces with capture interfaces, add reset interfaces.
- Add capture interfaces or inline interfaces.

Related tasks

Add capture interfaces to IPS engines on page 104 Add inline interfaces to IPS engines on page 105

Add reset interfaces to IPS engines

Reset interfaces can deliver TCP resets and ICMP destination unreachable messages to interrupt communications picked up from capture interfaces when the communications trigger a response.

VLANs are supported for sending resets, but the correct VLAN is selected automatically. An interface you want to use as the reset interface must not have any manually added VLAN configuration.

The reset interface must be in the same broadcast domain as the capture interface that uses the reset interface. The resets are sent using the IP addresses and MAC addresses of the communicating hosts.



Important: An interface that is used only as a reset interface must not have an IP address.

Steps • For more details about the product and how to configure features, click Help or press F1.

- Right-click the IPS engine and select Edit <element type>.
 The Engine Editor opens.
- 2) In the navigation pane on the left, browse to Interfaces.
- 3) Right-click the empty space and select New Physical Interface.
- 4) From the Interface ID drop-down list, select an ID number.
- 5) From the Type drop-down list, select Normal Interface.

- 6) Click OK.
- 7) Click H Save.

Result

This interface can now be used as a reset interface. When you set up the physical network, make sure that the reset interface connects to the same network as the capture interfaces.

Add capture interfaces to IPS engines

Capture interfaces listen to traffic that is not routed through the IPS engine.

You can have as many capture interfaces as there are available physical ports on the IPS engine (there are no license restrictions regarding this interface type).

External equipment must be set up to mirror traffic to the capture interface. You can connect a capture interface to an external switch SPAN port or a network TAP to capture traffic.

Steps • For more details about the product and how to configure features, click **Help** or press **F1**.

- Right-click the IPS engine and select Edit <element type>.
 The Engine Editor opens.
- 2) In the navigation pane on the left, browse to Interfaces.
- 3) Right-click the empty space and select New Physical Interface.
- 4) From the Interface ID drop-down list, select an ID number.
- 5) From the Type drop-down list, select Capture Interface.
- 6) (Optional) From the **Reset Interface** drop-down list, select a TCP reset interface for traffic picked up through this capture interface.
- 7) If your configuration requires you to change the logical interface from Default_Eth, select the logical interface in one of the following ways:
 - Select an existing Logical Interface element from the list.
 - Select Other and browse to another Logical Interface element.
 - Select New to create a Logical Interface element.
- 8) Click OK.
- Click H Save.

Next steps

Continue the configuration in one of the following ways:

Define Inline Interfaces.

- Define how an inline IPS engine handles traffic when the traffic load is too high using the Bypass Traffic on Overload setting.
- · Bind engine licenses to IPS elements.

Related tasks

Bypass traffic on overload on page 106

Bind engine licenses to IPS elements on page 107

Add inline interfaces to IPS engines

Inline interfaces allow traffic to flow through an engine.

One inline interface always comprises two physical interfaces. The traffic is forwarded from one interface to the other. The allowed traffic passes through as the inline interface if it was going through a network cable. The IPS engine drops the traffic you want to stop.

Inline interfaces are associated with a Logical interface element. The Logical interface is used in the IPS policies and the traffic inspection process to represent one or more IPS engine interfaces.

Fail-open network cards have fixed pairs of ports. Make sure to map these ports correctly during the initial configuration of the engine. Otherwise, the network cards do not correctly fail open when the IPS engine is offline. If you use the automatic USB memory stick configuration method for the engine's initial configuration, the ports are configured automatically.

Steps • For more details about the product and how to configure features, click **Help** or press **F1**.

- Right-click the IPS engine and select Edit <element type>.
 The Engine Editor opens.
- 2) In the navigation pane on the left, browse to Interfaces.
- Right-click the empty space and select New Physical Interface.
- 4) From the Interface ID drop-down list, select an ID number.
- 5) From the Type drop-down list, select Inline Interface.
- 6) (Optional) From the Second Interface ID drop-down list, change the automatically selected interface ID.
- 7) If you want the IPS engine to inspect traffic from VLANs that are not included in the IPS engine's interface configuration, leave **Inspect Unspecified VLANs** selected.
- 8) If your configuration requires you to change the logical interface from Default_Eth, select the logical interface in one of the following ways:
 - Select an existing Logical Interface element from the list.
 - Select Other and browse to another Logical Interface element.
 - Select New to create a Logical Interface element.
- 9) Click OK.

10) Click H Save.

Next steps

Continue the configuration in one of the following ways:

- Define how an inline IPS engine handles traffic when the traffic load is too high using the Bypass Traffic on Overload setting.
- · Bind engine licenses to IPS elements.

Related tasks

Bind engine licenses to IPS elements on page 107

Configure Forcepoint NGFW software using automatic configuration on page 148

Bypass traffic on overload

You configure the IPS engine to bypass traffic when the traffic load becomes too high.

By default, inline IPS engines inspect all connections. If the traffic load is too high for the inline IPS engine to inspect all connections, some traffic might be dropped. Alternatively, inline IPS engines can dynamically reduce the number of inspected connections if the load is too high. This reduction can improve performance in evaluation environments, but some traffic might pass through without any access control or inspection.



CAUTION: Using bypass mode requires a fail-open network interface card. If the ports that represent the pair of Inline Interfaces cannot fail open, policy installation fails on the engine. Bypass mode is not compatible with VLAN retagging. In network environments where VLAN retagging is used, normal mode is automatically enforced.

Steps @ For more details about the product and how to configure features, click Help or press F1.

- Right-click the IPS engine and select Edit <element type>.
 The Engine Editor opens.
- 2) In the navigation pane on the left, select Advanced Settings.
- 3) Select Bypass Traffic on Overload.
- 4) Click H Save.

Next steps

Bind engine licenses to IPS elements.

Bind engine licenses to IPS elements

After you have configured the IPS elements, you must manually bind Management Server POL-bound licenses to specific IPS elements.

Licenses are created based on the Management Server's proof-of-license (POL) code or based on the appliance's proof-of-serial (POS) code. POS-bound appliance licenses are automatically bound to the correct IPS element when the engine is fully installed.

Steps 9 For more details about the product and how to configure features, click **Help** or press **F1**.

- 1) Select . Configuration, then browse to Administration.
- 2) Browse to Licenses > Engine or Licenses > IPS depending on the type of licenses you have.
 All installed licenses appear in the right pane.
- 3) Right-click a Management Server POL-bound license and select Bind.
- 4) Select the IPS element and click Select.
 The license is now bound to the selected IPS element.



Tip: If you bound the license to an incorrect element, right-click the license and select **Unbind**.

Next steps

Transfer the configuration to the IPS engines.

■ Forcepoint Next Generation Firewall 6.2 Installation Guide					

G CHAPTER 7

Configuring Forcepoint NGFW for the Layer 2 Firewall role

Contents

- Install licenses for NGFW Engines on page 109
- Configuring Layer 2 Firewalls on page 110
- Bind engine licenses to Layer 2 Firewall elements on page 122

Configuring engine elements in the SMC prepares the SMC to manage NGFW Engines in the Layer 2 Firewall role.

Install licenses for NGFW Engines

Install the NGFW Engine licenses that you downloaded while preparing for installation.

Before you begin

The license files must be available to the computer that you use to run the Management Client.

You can install all licenses at the same time even though you have not yet created all elements that the licenses are bound to.

Steps 9 For more details about the product and how to configure features, click Help or press F1.

- 1) In the Management Client, select ≡ Menu > System Tools > Install Licenses.
- 2) Select one or more license files to install in the dialog box that opens and click Install.
- To check that the licenses were installed correctly, select . Configuration, then browse to Administration > Licenses > All Licenses.
 - One license shows for each NGFW Engine node. You must bind POL-bound engine licenses manually to the correct engines after you have configured the engine elements. POS-bound engine licenses are automatically attached to the correct engines after the engine is fully installed.

Next steps

Define the engine elements.

Configuring Layer 2 Firewalls

Layer 2 Firewall elements are a tool for configuring nearly all aspects of your Layer 2 Firewalls.

Little configuration is done directly on the engines. Most of the configuration is done using the Management Client. The engines cannot be successfully installed before defining them in the SMC as outlined.

An important part of the Layer 2 Firewall engine elements is the interface definitions. There are two main categories of IPS engine interfaces:

Table 9: Layer 2 Firewall interfaces

Purpose of interface	Interface type	When to use it
System communications	Normal	These interfaces are used when the Layer 2 Firewall engine is the source or the final destination of the communications. An example is control communications between the Layer 2 Firewall and the Management Server.
		Define at least one interface that is dedicated to system communications for each Layer 2 Firewall element.
Traffic inspection	Capture, Inline	Define one or more traffic inspection interfaces for each Layer 2 Firewall element.

The interfaces have their own numbering in the SMC called *interface ID*. The interface IDs are mapped to the corresponding network interfaces on the engine when you configure the Forcepoint NGFW software.



Note: If you configure the engine automatically with a USB drive, the interface IDs in the SMC are mapped to match the interface numbering in the operating system. For example, eth0 is mapped to Interface ID 0.

If necessary, you can change the interface ID mapping after the initial configuration using the command-line tools on the engine.

After you have the SMC installed and running, you can configure the Layer 2 Firewalls.

The tasks you must complete are as follows:

- 1) Add Single Layer 2 Firewall or Layer 2 Firewall Cluster elements.
- Add system communication interfaces.
- Add traffic inspection interfaces.
- 4) Bind licenses to specific Layer 2 Firewall elements.

Add Layer 2 Firewall elements

The basic configuration of Layer 2 Firewall engine elements begins with creating an engine element.

Steps • For more details about the product and how to configure features, click **Help** or press **F1**.

- 1) In the Management Client, select . Configuration.
- 2) Right-click NGFW Engines and select one of the following:
 - New > Layer 2 Firewall > Layer 2 Firewall Cluster
 - New > Layer 2 Firewall > Single Layer 2 Firewall

The Engine Editor opens.

- In the Name field, enter a unique name.
- 4) From the Log Server drop-down list, select the Log Server that stores the log events that the Layer 2 Firewall engine creates.
- (Optional) In the DNS IP Addresses field, add one or more DNS IP addresses for the Layer 2 Firewall engine.

These addresses are the IP addresses of the DNS servers that the Layer 2 Firewall engine uses to resolve domain names and web filtering categorization services (which are defined as URLs).

- To enter a single IP address manually, click Add and select IP Address. Enter the IP address in the dialog box that opens.
- To define an IP address by using a Network element, click Add and select Network Element. Select a
 predefined Alias element that represents the IP address of the DNS of a dynamic network interface, a
 Host element, or an External DNS Server element.
- 6) From the Location drop-down list, select the location for this engine if there is a NAT device between SMC components affecting this engine's communications.
- 7) Click H Save.

Do not close the Engine Editor.

Add system communications interfaces to Layer 2 Firewalls

Each Layer 2 Firewall needs at least one interface for communicating with the SMC.

You can add more than one system communication interface to provide a primary and a backup interface for Management Server communications.

Add physical interfaces to Layer 2 Firewalls

Add a physical interface for system communications.

Steps • For more details about the product and how to configure features, click **Help** or press **F1**.

- 1) In the navigation pane on the left, browse to Interfaces.
- 2) Right-click the empty space and select New Physical Interface.
- 3) From the Interface ID drop-down list, select an ID number.
 This ID maps to a network interface during the initial configuration of the engine.
- 4) From the Type drop-down list, select Normal Interface.
- 5) Click OK.

The physical interface is added to the interface list.

6) Click H Save.

Do not close the Engine Editor.

Next steps

Continue the configuration in one of the following ways:

- · Add VLANs to the physical interface.
- Add an IP address to the physical interface.

Related tasks

Add static IPv4 addresses to Single Layer 2 Firewall interfaces on page 113 Add IP addresses to Layer 2 Firewall Cluster interfaces on page 116

Add VLAN Interfaces to Layer 2 Firewalls

VLANs divide a single physical network link into several virtual links.

You can add up to 4094 VLANs to each physical interface.



CAUTION: Do not add any manual VLAN definitions to an interface you want to use for sending resets. Adding VLANs prevents selecting the interface as a reset interface and also removes the reset interface from any existing selections.

- 1) In the navigation pane on the left, select Interfaces.
- Right-click a physical interface and select New > VLAN Interface.

In the VLAN ID field, enter a VLAN ID number (1-4094).



Note: The VLAN ID must be the same VLAN ID used in the external switch at the other end of the VLAN trunk.

4) Click OK.

The specified VLAN ID is added to the physical interface.

5) Click H Save.

Do not close the Engine Editor.

Result

The VLAN interface is now ready to be used as a network interface. The VLAN interface is identified as Interface-ID.VLAN-ID, for example 2.100 for interface ID 2 and VLAN ID 100.

Add static IPv4 addresses to Single Layer 2 Firewall interfaces

You can add one or more static IPv4 addresses to each physical or VLAN interface on a Single Layer 2 Firewall.

Steps of For more details about the product and how to configure features, click Help or press F1.

- 1) In the navigation pane on the left, select Interfaces.
- Right-click a Physical Interface or a VLAN Interface and select New > IPv4 Address.
- In the IPv4 Address field, enter the IPv4 address.



Tip: To resolve the IP address from a DNS name, right-click the field, then select **Resolve** From DNS Name.

4) Click Netmask and adjust the automatically added netmask if necessary.

The Network Address and Broadcast IP Address are updated accordingly

- If the interface is used for system communications and NAT is applied, add contact addresses.
 - a) Enter the default contact address in one of the following ways:
 - In the Default field, enter the contact address.
 - Select Dynamic and define the translated IP address of this component.
 - b) If components from some locations must use a different IP address for contact, click **Exceptions** and define the location-specific addresses.
- 6) Click OK.

The IP address is added to the interface.

7) Click H Save.

If you plan to add more IP addresses or change the roles that interfaces have in system communications, do not close the Engine Editor.



Tip: Write down the networks to which each Interface ID is connected.

Add dynamic IPv4 addresses to Single Layer 2 Firewall interfaces

You can add one dynamic IPv4 address to each physical or VLAN interface on a Single Layer 2 Firewall.

Steps 9 For more details about the product and how to configure features, click **Help** or press **F1**.

- 1) In the navigation pane on the left, select Interfaces.
- Right-click a Physical Interface or a VLAN Interface and select New > IPv4 Address.
- 3) Select Dynamic.
- 4) From the Dynamic Index drop-down list, select a DHCP index.

The index is used for identification in other parts of the configuration (such as IPS Policies) to represent the possibly changing IP address.

- If the interface is used for system communications and NAT is applied, add contact addresses.
 - a) Enter the default contact address in one of the following ways:
 - In the Default field, enter the contact address.
 - Select Dynamic and define the translated IP address of this component.
 - b) If components from some locations must use a different IP address for contact, click **Exceptions** and define the location-specific addresses.
- 6) Click OK.

The physical interface is added to the interface list.

7) Click H Save.

If you plan to add more IP addresses or change the roles that interfaces have in system communications, do not close the Engine Editor.



Tip: Write down the networks to which each Interface ID is connected.

Add static IPv6 addresses to Single Layer 2 Firewall interfaces

You can add one or more static IPv6 addresses to each physical or VLAN interface on a Single Layer 2 Firewall.

Steps • For more details about the product and how to configure features, click Help or press F1.

- 1) In the navigation pane on the left, select Interfaces.
- Right-click a Physical Interface or a VLAN Interface and select New > IPv6 Address.
- In the IPv6 Address field, enter the IPv6 address.



Tip: To resolve the IP address from a DNS name, right-click the field, then select **Resolve** From DNS Name.

- Click Prefix Length and adjust the automatically added prefix length if necessary.
- 5) Click OK.

The IP address is added to the interface.

6) Click H Save.

If you plan to add more IP addresses or change the roles that interfaces have in system communications, do not close the Engine Editor.



Tip: Write down the networks to which each Interface ID is connected.

Add dynamic IPv6 addresses to Single Layer 2 Firewall interfaces

You can add one dynamic IPv6 address to each physical or VLAN interface on a Single Layer 2 Firewall.

- 1) In the navigation pane on the left, select Interfaces.
- 2) Right-click a physical interface or a VLAN interface and select New > IPv6 Address.
- 3) Select Dynamic.
- 4) From the Dynamic Index drop-down list, select a DHCP index.
 The index is used for identification in other parts of the configuration (such as IPS Policies) to represent the possibly changing IP address.

- 5) If the interface is used for system communications and NAT is applied, add contact addresses.
 - a) Enter the default contact address in one of the following ways:
 - In the **Default** field, enter the contact address.
 - Select Dynamic and define the translated IP address of this component.
 - b) If components from some locations must use a different IP address for contact, click **Exceptions** and define the location-specific addresses.
- 6) (Optional) If you do not want a default route to be automatically created through the interface, deselect Automatic Default Route.
- 7) (Optional) If you want to use DHCPv6 to get the IPv6 address, select **Use DHCPv6 to get IPv6 Address**.
- 8) Click OK.

The IP address is added to the interface.

9) Click H Save.

If you plan to add more IP addresses or change the roles that interfaces have in system communications, do not close the Engine Editor.



Tip: Write down the networks to which each Interface ID is connected.

Add IP addresses to Layer 2 Firewall Cluster interfaces

Add IP addresses to Layer 2 Firewall Cluster interfaces.

You can add both IPv4 and IPv6 addresses to the same interface.

Steps @ For more details about the product and how to configure features, click Help or press F1.

- 1) In the navigation pane on the left, select Interfaces.
- 2) Right-click a physical interface or a VLAN interface and add the IP address in one of the following ways:
 - To add an IPv4 address, select New > IPv4 Address
 - To add an IPv6 address, select New > IPv6 Address
- Click the IPv4 Address or IPv6 Address cell in the table and enter the IP address for each node.



Tip: To resolve the IP address from a DNS name, right-click the field, then select **Resolve** From DNS Name.

- 4) (IPv4 addresses only) If necessary, double-click the Contact Address cell in the table and define the contact address for each node.
 - In the Default field at the top of the dialog box, enter the default contact address. The default contact
 address is used by default whenever a component that belongs to another Location connects to this
 interface.

- If components from some Locations cannot use the default contact address, click Add to define Locationspecific contact addresses.
- (IPv4 addresses only) Check the automatically filled-in Netmask and adjust it as necessary.
- 6) (IPv6 addresses only) Check the automatically filled-in Prefix Length and adjust it as necessary.
- Click OK.
- 8) Click Save.Do not close the Engine Editor.

Next steps

Continue the configuration in one of the following ways:

- Select system communication roles for the interfaces.
- Add traffic inspection interfaces.

Select system communication roles for Layer 2 Firewall interfaces

Select which interfaces are used for particular roles in system communications.

Steps • For more details about the product and how to configure features, click **Help** or press **F1**.

- 1) In the navigation pane on the left, browse to Interfaces > Interface Options.
- 2) Select the interface options.
 - a) From the Primary control IP address drop-down list, select the primary control IP address for communications with the Management Server.
 - **b)** (Optional, recommended) In the **Backup** control IP address drop-down list, select a backup control IP address for Management Server contact (used if the primary fails).
 - c) (Layer 2 Firewall Cluster only) From the **Primary** heartbeat drop-down list, select the primary interface for communications between the nodes.



Important: This interface must not be a VLAN Interface.



CAUTION: Heartbeat traffic is time-critical. A dedicated network (without other traffic) is recommended for security and reliability of heartbeat communication.

d) (Layer 2 Firewall Cluster only) From the **Backup** heartbeat drop-down list, select the backup heartbeat interface that is used if the primary heartbeat interface is unavailable.

It is not mandatory to configure a backup heartbeat interface, but we strongly recommend it. If heartbeat traffic is not delivered, the cluster cannot operate and traffic is disturbed. We strongly recommend that you use a dedicated interface for the backup heartbeat as well.

- e) (Single Layer 2 Firewall only) If the control IP address for Management Server contact is a dynamic IP address, select **Node-initiated contact to Management Server**.
 - When this option is selected, the engine opens a connection to the Management Server and maintains connectivity.
- f) From the **Default IP Address for Outgoing Traffic** drop-down list, select the IP address that nodes use if they have to initiate connections through an interface that has no Node Dedicated IP address.
- 3) Click H Save.

Add traffic inspection interfaces to Layer 2 Firewalls

Layer 2 Firewalls pick up passing network traffic for inspection in real time.

You can define both capture interfaces and inline interfaces for the same Layer 2 Firewall.

Table 10: Types of traffic inspection interfaces for Layer 2 Firewalls

Interface type	Inspection	Response
Capture interface	The traffic is passively captured for inspection.	The engine can reset traffic picked up through capture interfaces if you set up specific reset interfaces. The reset interfaces can send TCP resets and ICMP "destination unreachable" messages when the communications trigger a response.
		You can use a system communications interface for sending resets if the resets are routed correctly through that interface and there are no VLANs on the interface.
Inline interface	Traffic is actively inspected as it flows through the inline interfaces.	The engine actively filters the traffic that attempts to pass through its inline interfaces.

When traffic is inspected, it might be important to know the interface through which it arrives to the Layer 2 Firewall. It is also important to be able to distinguish a Layer 2 Firewall's capture interfaces from its inline interfaces. Logical Interface elements are used for both these purposes. They allow you to group interfaces that belong to the same network segment and to identify the type of the traffic inspection interface.

Define a logical interface in the following cases:

- You want to create both capture interfaces and inline interfaces on the same Layer 2 Firewall.
- You want to create Logical Interfaces to distinguish interfaces from each other.

Add logical interfaces to Layer 2 Firewalls

A logical interface is used in the Layer 2 Firewall Policy and the traffic inspection process to represent a network segment.

The SMC contains one default Logical Interface element. A logical interface can represent any number or combination of physical interfaces and VLAN interfaces. However, the same logical interface cannot be used to

represent both capture interfaces and inline interfaces on the same Layer 2 Firewall. The rules in the ready-made Layer 2 Firewall Template match all logical interfaces.

Steps • For more details about the product and how to configure features, click **Help** or press **F1**.

- 1) Select . Configuration.
- Expand the Other Elements branch.
- Right-click Logical Interfaces and select New Logical Interface.
- 4) In the Name field, enter a unique name.
- 5) (Optional) If you use VLAN tagging, select View interface as one LAN.
 By default, the IPS engine treats a single connection as multiple connections when a switch passes traffic between different VLANs and all traffic is mirrored to the IPS engine through a SPAN port.
- 6) Click OK.

Next steps

Continue the configuration in one of the following ways:

- If you want to use reset interfaces with capture interfaces, add reset interfaces.
- · Add capture interfaces or inline interfaces.

Related tasks

Add capture interfaces to Layer 2 Firewalls on page 120 Add inline interfaces to Layer 2 Firewalls on page 121

Add reset interfaces to Layer 2 Firewalls

Reset interfaces can deliver TCP resets and ICMP destination unreachable messages to interrupt communications picked up from capture interfaces when the communications trigger a response.

VLANs are supported for sending resets, but the correct VLAN is selected automatically. An interface you want to use as the reset interface must not have any manually added VLAN configuration.

The reset interface must be in the same broadcast domain as the capture interface that uses the reset interface. The resets are sent using the IP addresses and MAC addresses of the communicating hosts.



Important: An interface that is used only as a reset interface must not have an IP address.

Steps @ For more details about the product and how to configure features, click Help or press F1.

Right-click the Layer 2 Firewall element and select Edit <element type>.
 The Engine Editor opens.

- 2) In the navigation pane on the left, browse to Interfaces.
- 3) Right-click the empty space and select New Physical Interface.
- 4) From the Interface ID drop-down list, select an ID number.
- 5) From the Type drop-down list, select Normal Interface.
- 6) Click OK.

Result

This interface can now be used as a reset interface. When you set up the physical network, make sure that the reset interface connects to the same network as the capture interfaces.

Next steps

Add capture interfaces and inline interfaces.

Add capture interfaces to Layer 2 Firewalls

Capture interfaces listen to traffic that is not routed through the Layer 2 Firewall.

You can have as many capture interfaces as there are available network ports on the Layer 2 Firewall (there are no license restrictions regarding this interface type).

External equipment must be set up to mirror traffic to the capture interface. You can connect a capture interface to an external switch SPAN port or a network TAP to capture traffic.

- 1) On the Interfaces pane, right-click and select New Physical Interface.
- 2) From the Interface ID drop-down list, select an ID number.
- 3) From the Type drop-down list, select Capture Interface.
- 4) (Optional) From the Reset Interface drop-down list, select a TCP reset interface for traffic picked up through this capture interface.
- 5) If your configuration requires you to change the logical interface from Default_Eth, select the logical interface in one of the following ways:
 - Select an existing Logical Interface element from the list.
 - Select Other and browse to another Logical Interface element.
 - Select New to create a Logical Interface element.

- 6) Leave Inspect Unspecified VLANs selected if you want the Layer 2 Firewall engine to inspect traffic from VLANs not included in the engine's interface configuration.
- 7) Click OK.
- 8) Click H Save.

If you plan to add inline interfaces, do not close the Engine Editor.

Next steps

Continue the configuration in one of the following ways:

- Add inline interfaces.
- Bind engine licenses to Layer 2 Firewall elements.

Related tasks

Bind engine licenses to Layer 2 Firewall elements on page 122

Add inline interfaces to Layer 2 Firewalls

Inline interfaces allow traffic to flow through an engine.

One inline interface always comprises two physical interfaces. The traffic is forwarded from one interface to the other. The allowed traffic passes through as the inline interface if it was going through a network cable. The Layer 2 Firewall drops the traffic you want to stop.

Inline interfaces are associated with a Logical Interface element. The Logical Interface is used in the Layer 2 Firewall Policy and the traffic inspection process to represent one or more Layer 2 Firewall interfaces.

- Right-click the IPS engine and select Edit <element type>.
 The Engine Editor opens.
- 2) In the navigation pane on the left, browse to **Interfaces**.
- Right-click the empty space and select New Physical Interface.
- From the Interface ID drop-down list, select an ID number.
- 5) From the Type drop-down list, select Inline Interface.
- (Optional) From the Second Interface ID drop-down list, change the automatically selected interface ID.
- 7) If you want the Layer 2 firewall engine to inspect traffic also from VLANs that are not included in the engine's interface configuration, leave **Inspect Unspecified VLANs** selected.
- 8) If your configuration requires you to change the logical interface from Default_Eth, select the logical interface in one of the following ways:
 - Select an existing Logical Interface element from the list.

- Select Other and browse to another Logical Interface element.
- Select New to create a Logical Interface element.
- Click OK.
- Click Save, then close the Engine Editor.

Next steps

Bind engine licenses to Layer 2 Firewall elements.

Related tasks

Bind engine licenses to Layer 2 Firewall elements on page 122

Bind engine licenses to Layer 2 Firewall elements

After you have configured the Layer 2 Firewall elements, you must manually bind Management Server POL-bound licenses to specific Layer 2 Firewall elements.

Licenses are created based on the Management Server's proof-of-license (POL) code or based on the appliance's proof-of-serial (POS) code. POS-bound appliance licenses are automatically bound to the correct Layer 2 Firewall element when the engine is fully installed.

Steps • For more details about the product and how to configure features, click **Help** or press **F1**.

- 1) Select . Configuration, then browse to Administration.
- Browse to Licenses > Engine.
 All installed licenses appear in the right pane.
- 3) Right-click a Management Server POL-bound license and select Bind.
- 4) Select the Layer 2 Firewall element and click Select.
 The license is now bound to the selected Layer 2 Firewall element.



Tip: If you bound the license to an incorrect element, right-click the license and select **Unbind**.

Next steps

Transfer the configuration to the Layer 2 Firewall engines.

CHAPTER 8

Configuring NGFW Engines as Master NGFW Engines and Virtual NGFW Engines

Contents

- Master NGFW Engine and Virtual NGFW Engine configuration overview on page 123
- Install licenses for NGFW Engines on page 124
- Add Master NGFW Engine elements on page 124
- Add Virtual Firewall elements on page 132
- Add Virtual IPS elements on page 137
- Add Virtual Layer 2 Firewall elements on page 139

Configuring engine elements in the SMC prepares the SMC to manage Master NGFW Engines and Virtual NGFW Engines.

Master NGFW Engine and Virtual NGFW Engine configuration overview

Virtual NGFW Engines are logically separate virtual engine instances on a physical engine device. A Master NGFW Engine is a physical engine device that provides resources for Virtual NGFW Engines. One physical Master NGFW Engine can support multiple Virtual NGFW Engines.

Little configuration is done directly on the Master NGFW Engine. No installation or configuration is done on the Virtual NGFW Engines. Most of the configuration is done using the Management Client. The engines cannot be successfully installed before defining them in the Management Client as outlined in this section.

The tasks you must complete are as follows:

- Add Master NGFW Engine elements.
 - a) Add Virtual Resource elements.
 - b) Add physical interfaces and optionally VLAN interfaces to the Master NGFW Engine.
 - c) Assign Virtual Resources to the interfaces that are used by the Virtual NGFW Engines hosted on the Master NGFW Engine.
- 2) Add Virtual Firewall, Virtual IPS, or Virtual Layer 2 Firewall elements.
 - Configure the automatically created physical interfaces.

- b) (Optional) Add VLAN interfaces for the Virtual NGFW Engines.
- Bind licenses to specific nodes of the Master NGFW Engine.

Install licenses for NGFW Engines

Install the NGFW Engine licenses that you downloaded while preparing for installation.

Before you begin

The license files must be available to the computer that you use to run the Management Client.

You can install all licenses at the same time even though you have not yet created all elements that the licenses are bound to.

Steps • For more details about the product and how to configure features, click **Help** or press **F1**.

- 1) In the Management Client, select ≡ Menu > System Tools > Install Licenses.
- Select one or more license files to install in the dialog box that opens and click Install.
- 3) To check that the licenses were installed correctly, select . Configuration, then browse to Administration > Licenses > All Licenses.

One license shows for each NGFW Engine node. You must bind POL-bound engine licenses manually to the correct engines after you have configured the engine elements. POS-bound engine licenses are automatically attached to the correct engines after the engine is fully installed.

Next steps

Define the engine elements.

Add Master NGFW Engine elements

To introduce a new Master NGFW Engine to the SMC, add a Master NGFW Engine element that stores the configuration information for the Master NGFW Engine and Virtual NGFW Engines.

- 1) In the Management Client, select . Configuration.
- Right-click NGFW Engines and select New > Master NGFW Engine.

- Select the role for the Virtual NGFW Engines the Master NGFW Engine hosts, then click OK.
 The Engine Editor opens.
- 4) In the Name field, enter a unique name.
- 5) Select the Log Server to which the Master NGFW Engine sends its log data.
- 6) (Optional) Define one or more DNS IP Addresses.

These addresses are the IP addresses of the DNS servers that the Master NGFW Engine uses to resolve domain names. There are two ways to define IP addresses.

- To enter a single IP address manually, click Add and select IP Address. Enter the IP address in the dialog box that opens.
- To define an IP address using a network element, click Add and select Network Element.
- 7) Select the Location for this Master NGFW Engine if there is a NAT device between this Master NGFW Engine and other SMC components.
- 8) (Optional) If you do not need to use clustering on the Master NGFW Engine:
 - a) In the navigation pane on the left, browse to General > ARP Entries.
 - b) Select one of the nodes, then click Remove Node.
 - c) When prompted to confirm that you want to delete the selected node, click Yes.
- 9) Click H Save.

Do not close the Engine Editor.

Next steps

Continue the configuration in one of the following ways:

- Add more nodes to the Master NGFW Engine.
- · Add Virtual Resource elements.

Add nodes to Master NGFW Engines

Add all nodes you plan to install before you begin configuring the interfaces.

The Master NGFW Engine has placeholders for two nodes when the element is created. A Master NGFW Engine can have up to 16 nodes.

- Right-click the Master NGFW Engine element and select Edit Master NGFW Engine.
 The Engine Editor opens.
- In the navigation pane on the left, select General > Clustering.

- 3) Click Add Node.
- 4) (Optional) Change the Name.
- 5) Click OK.

The node is added to the Master NGFW Engine.

6) Click H Save.

Create Virtual Resource elements

Virtual Resources associate Virtual NGFW Engines with Physical Interfaces or VLAN Interfaces on the Master NGFW Engine.

When you select the same Virtual Resource for a Physical Interface or VLAN Interface on the Master NGFW Engine and for a Virtual NGFW Engine, the Virtual NGFW Engine is automatically associated with the Master NGFW Engine. Create one Virtual Resource for each Virtual NGFW Engine that you plan to add.

Steps 9 For more details about the product and how to configure features, click **Help** or press **F1**.

- 1) Select . Configuration.
- 2) Right-click the Master NGFW Engine element and select Edit Master NGFW Engine. The Engine Editor opens.
- 3) In the navigation pane on the left, browse to Interfaces > Virtual Resources in the navigation pane on the left.
- 4) Click Add.

The Virtual Resource Properties dialog box opens.

- Enter a unique Name for the Virtual Resource.
- Select the **Domain** to which the Virtual Resource belongs.
- 7) (Optional) Enter the **Concurrent Connection Limit** to set a limit for the total number of connections that are allowed for the Virtual NGFW Engine associated with the Virtual Resource.
 - When the set number of connections is reached, the engine blocks the next connection attempts until a previously open connection is closed.
- 8) (Optional) Select **Show Master Interface IDs in Virtual Engine** if you want the Physical Interface IDs of the Master NGFW Engine to be shown in the Interface properties of the Virtual NGFW Engine.
- 9) Click OK.
- 10) Click H Save.

Next steps

Continue the configuration in one of the following ways:

- If you are creating a Master NGFW Engine, configure Master NGFW Engine interfaces.
- Associate the Virtual Resource with a Master NGFW Engine interface and with a Virtual NGFW Engine.

Add physical interfaces to Master NGFW Engines

Master NGFW Engines can have two types of physical interfaces: interfaces for the Master NGFW Engine's own communications, and interfaces that are used by the Virtual NGFW Engines hosted on the Master NGFW Engine.

You must add at least one physical interface for the Master NGFW Engine's own communications.

For Master NGFW Engine clusters, it is recommended to add at least two physical interfaces:

- An interface used for communications between the Management Server and the Master NGFW Engine.
- An interface for the heartbeat communications between the cluster nodes. The heartbeat traffic is critical to the functioning of the cluster, so it is highly recommended to have a dedicated heartbeat interface.

Steps • For more details about the product and how to configure features, click **Help** or press **F1**.

- Right-click the Master NGFW Engine element and select Edit Master NGFW Engine.
 The Engine Editor opens.
- 2) In the navigation pane on the left, select Interfaces.
- 3) Right-click the empty space and select New Physical Interface.
- (Interface for Master NGFW Engine communications only) Define the physical interface properties.
 - a) From the Type drop-down list, select the interface type according to the engine role.
 - b) Do not select a Virtual Resource for an interface that is used for the Master NGFW Engine's own communications.
 - c) In the Cluster MAC Address field, enter the MAC address for the Master NGFW Engine.



Note: Do not use the MAC address of any actual network card on any of the Master NGFW Engine nodes.



Note: Make sure that you set the interface speed correctly. When the bandwidth is set, the Master NGFW Engine always scales the total amount of traffic on this interface to the bandwidth you defined. The bandwidth is scaled even if there are no bandwidth limits or guarantees defined for any traffic.

- 5) (Interface for hosted Virtual NGFW Engine communications only) Define the physical interface properties.
 - a) From the Type drop-down list, select the interface type according to the engine role.

b) (Virtual IPS only) From the **Failure Mode** drop-down list, select how traffic to the inline interface is handled if the Virtual IPS engine goes offline.



Note: If there are VLAN interfaces under the inline interface, select Bypass.



CAUTION: Using Bypass mode requires the Master NGFW Engine appliance to have a fail-open network interface card. If the ports that represent the pair of inline interfaces on the appliance cannot fail open, the policy installation fails on the Virtual IPS engine. Bypass mode is not compatible with VLAN retagging. In network environments where VLAN retagging is used, normal mode is automatically enforced.

c) From the Virtual Resource drop-down list, select the Virtual Resource element associated with the interface.

Select the same Virtual Resource in the properties of the Virtual NGFW Engine to add the **Virtual IPS engine** to the Master NGFW Engine.



Note: Only one Virtual Resource can be selected for each physical interface. If you want to add multiple Virtual Resources, add VLAN interfaces to the physical interface and select the Virtual Resource in the VLAN interface properties.

- 6) Click OK.
 The physical interface is added to the interface list.
- 7) Click H Save.

Next steps

Continue the configuration in one of the following ways:

- · Add VLANs to physical interfaces.
- Add IP addresses to the physical interfaces used for Master NGFW Engine communications.

Add VLAN interfaces to Master NGFW Engines

Master NGFW Engines can have two types of VLAN interfaces: VLAN interfaces for the Master NGFW Engine's own traffic, and VLAN interfaces that are used by the Virtual NGFW Engines hosted on the Master NGFW Engine.

The maximum number of VLANs for a single physical interface is 4094. The VLANs must also be defined in the configuration of the external switch or router to which the interface is connected.

On Master NGFW Engines that host Virtual IPS engines or Virtual Layer 2 Firewalls, the Virtual NGFW Engines can inspect traffic from VLAN interfaces without configuring VLAN tagging.

Steps • For more details about the product and how to configure features, click **Help** or press **F1**.

Right-click a Master NGFW Engine and select Edit Master NGFW Engine.
 The Engine Editor opens.

- 2) In the navigation pane on the left, select Interfaces.
- 3) Right-click a physical interface and select New > VLAN Interface.
- 4) To associate the VLAN interface with a Virtual NGFW Engine, select a Virtual Resource from the Virtual Resource drop-down list.



Note: Do not select a Virtual Resource for a VLAN interface that is used for the Master NGFW Engine's own communications.

Define the VLAN interface properties.



CAUTION: The throughput for each VLAN interface must not be higher than the throughput for the physical interface to which the VLAN interface belongs.



CAUTION: Make sure that you set the interface speed correctly. When the bandwidth is set, the Master NGFW Engine always scales the total amount of traffic on this interface to the bandwidth you defined. The bandwidth is scaled even if there are no bandwidth limits or guarantees defined for any traffic.



CAUTION: The MTU for each VLAN interface must not be higher than the MTU for the physical interface to which the VLAN interface belongs.

6) Click OK.

The specified VLAN ID is added to the physical interface.

7) Click H Save.

Do not close the Engine Editor.

Next steps

Add IP addresses to the physical interfaces or VLAN interfaces for Master NGFW Engine system communications.

Add IPv4 and IPv6 addresses to Master NGFW Engine interfaces

You can add several IPv4 addresses to each Physical Interface or VLAN Interface that does not have a Virtual Resource associated with it.

Steps • For more details about the product and how to configure features, click Help or press F1.

Right-click a Master NGFW Engine and select Edit Master NGFW Engine.
 The Engine Editor opens.

- 2) In the navigation pane on the left, select Interfaces.
- 3) Right-click a physical interface or a VLAN interface and add the IP address in one of the following ways:
 - To add an IPv4 address, select New > IPv4 Address
 - To add an IPv6 address, select New > IPv6 Address
- 4) Click the IPv4 Address or IPv6 Address cell in the table and enter the IP address for each node.



Tip: To resolve the IP address from a DNS name, right-click the field, then select **Resolve From DNS Name**.

- 5) (IPv4 addresses only) If necessary, double-click the Contact Address cell in the table and define the contact address for each node.
 - In the Default field at the top of the dialog box, enter the default contact address. The default contact
 address is used by default whenever a component that belongs to another Location connects to this
 interface.
 - If components from some Locations cannot use the default contact address, click Add to define Location-specific contact addresses.
- (IPv4 addresses only) Check the automatically filled-in Netmask and adjust it as necessary.
- 7) (IPv6 addresses only) Check the automatically filled-in **Prefix Length** and adjust it as necessary.
- 8) Click OK.
- 9) Click H Save.
- 10) Continue the configuration in one of the following ways:
 - If you are configuring a new Master NGFW Engine, or if you want to change the roles the different interfaces have in the configuration, select system communication roles for Master NGFW Engine interfaces.
 - Otherwise, refresh the policy to transfer the configuration changes.

Select system communication roles for Master NGFW Engine interfaces

Select which Master NGFW Engine interfaces are used for particular roles in system communications.

- Right-click a Master NGFW Engine and select Edit Master NGFW Engine.
 The Engine Editor opens.
- 2) In the navigation pane on the left, select Interfaces > Interface Options.

- 3) In the Interface Options pane that opens on the right:
 - a) From the **Primary** control IP address drop-down list, select the primary control IP address for communications with the Management Server.



Note: We recommend that you do not use the IP address of an Aggregated Link interface as the primary or secondary control IP address of the engine.

- b) (Optional, recommended) From the **Backup** control IP address drop-down list, select a backup control IP address for Management Server contact (used if the primary fails).
- c) (Master NGFW Engine Cluster Only) From the **Primary** heartbeat drop-down list, select the primary interface for communications between the nodes.

We recommend using a physical interface, not a VLAN interface. We strongly recommend that you do not direct any other traffic through this interface. A dedicated network helps guarantee reliable and secure operation.



CAUTION: Primary and backup heartbeat networks exchange confidential information. If dedicated networks are not possible, configure the cluster to encrypt the exchanged information.

- d) (Master NGFW Engine Cluster Only) From the **Backup** heartbeat drop-down list, select the backup heartbeat interface that is used if the primary heartbeat interface is unavailable.
 - It is not mandatory to configure a backup heartbeat interface, but we strongly recommend it. If heartbeat traffic is not delivered, the cluster cannot operate and traffic is disturbed. We strongly recommend that you use a dedicated interface for the backup heartbeat as well.
- e) In the **Default IP Address for Outgoing Traffic** field, select the IP address that the nodes use if they have to initiate connections through an interface that has no Node Dedicated IP address.
- 4) Click OK.
- 5) Click Save and Refresh, then close the Engine Editor.

Next steps

Bind licenses to Master NGFW Engine elements.

Bind Master NGFW Engine licenses to Master NGFW Engine elements

You must manually bind Management Server POL-bound licenses to a specific Master NGFW Engine element.

Licenses are created based on the Management Server's proof-of-license (POL) code or based on the appliance's proof-of-serial (POS) code. POS-bound appliance licenses are automatically bound to the correct Master NGFW Engine element when the engine is fully installed. Virtual NGFW Engines do not require a separate license.

Steps @ For more details about the product and how to configure features, click Help or press F1.

- 1) Select . Configuration, then browse to Administration.
- Browse to Licenses > NGFW Engines.
 All installed licenses appear in the right pane.
- Right-click a Management Server POL-bound license and select Bind.
 The Select License Binding dialog box opens.
- 4) Select the node and click **Select**.

If you made a mistake, right-click the license and select Unbind.



CAUTION: When you install or refresh the policy on the engine, the license is permanently bound to that engine. Permanently bound licenses cannot be rebound to another engine without relicensing or deleting the engine element the license is bound to. Until you do that, the unbound license is shown as Retained.

Next steps

Add Virtual NGFW Engine elements.

Add Virtual Firewall elements

Virtual Firewall elements store the configuration information related to the Virtual Firewalls.

Selecting a Virtual Resource for the Virtual Firewall automatically adds the Virtual Firewall to the Master NGFW Engine where the Virtual Resource is used.

- 1) Select . Configuration.
- Right-click NGFW Engines and select New > Firewall > Virtual Firewall.
- 3) In the Name field, enter a unique name.
- 4) Next to the Virtual Resource field, click Select and select a Virtual Resource on the Master NGFW Engine to which you want to add the Virtual Firewall.

5) (Optional) In the DNS IP Addresses field, add one or more IP addresses.

DNS IP addresses are IP addresses of external DNS servers. Virtual Firewalls use these DNS servers to resolve Domain names to IP addresses. Virtual Firewalls need DNS resolution to contact services that are defined using URLs or domain names, and to resolve fully qualified domain names (FQDNs) used in policies. When DNS relay is configured, these DNS servers are used unless domain-specific DNS servers are specified in a DNS Relay Profile element.



Note: If you have defined NetLink-specific DNS IP addresses, adding DNS IP addresses overrides the NetLink-specific DNS IP addresses.

- To enter a single IP address manually, click Add and select IP Address. Enter the IP address in the dialog box that opens.
- To define an IP address using a network element, click Add and select Network Element.
- 6) (Optional) Next to the Category field, click Select and select one or more categories.
- 7) Click Save.Do not close the Engine Editor.

Next steps

Configure interfaces for the Virtual Firewall.

Configuring physical interfaces for Virtual Firewalls

Physical interfaces for Virtual NGFW Engines represent interfaces allocated to the Virtual NGFW Engine in the Master NGFW Engine.

When you select the Virtual Resource for the Virtual NGFW Engine, physical interfaces are automatically created based on the interface configuration in the Master NGFW Engine properties. The number of physical interfaces depends on the number of interfaces allocated to the Virtual NGFW Engine in the Master NGFW Engine. You cannot create new physical interfaces for Virtual Firewalls. You can optionally change the automatically created physical interfaces. For detailed instructions, see the *Forcepoint Next Generation Firewall Product Guide*.

You can optionally change the automatically created physical interfaces in the Virtual IPS engine properties. For detailed instructions, see the *Forcepoint Next Generation Firewall Product Guide*.

If the configuration of the Master NGFW Engine allows it, you can add VLANs to physical interfaces on the Virtual Firewall. If you do not want to add VLANs, add IP addresses to the physical interfaces.

Add VLAN interfaces to Virtual NGFW Engine interfaces

VLANs divide a single physical network link into several virtual links.

VLAN interfaces can only be added for Virtual NGFW Engines if the creation of VLAN interfaces for Virtual Firewalls is enabled in the Master NGFW Engine Properties. The maximum number of VLANs for a single

physical interface is 4094. The VLANs must also be defined in the configuration of the external switch or router to which the interface is connected.



Note: You cannot add VLAN interfaces on top of other VLAN interfaces. Depending on the configuration of the Master NGFW Engine, you might not be able to create valid VLAN interfaces for the Virtual NGFW Engine. Contact the administrator who configured the Master NGFW Engine.

Steps 9 For more details about the product and how to configure features, click **Help** or press **F1**.

- Right-click a Virtual Firewall, Virtual IPS engine, or Virtual Layer 2 Firewall and select Edit <element type>.
 The Engine Editor opens.
- 2) In the navigation pane on the left, select Interfaces.
 The Interfaces pane opens on the right.
- 3) Right-click a physical interface and select New > VLAN Interface.
- 4) Define the VLAN interface properties.



CAUTION: The throughput for the Virtual Firewall physical interface must not be higher than the throughput for the Master NGFW Engine interface that hosts the Virtual Firewall. Contact the administrator of the Master NGFW Engine before changing this setting.



CAUTION: Make sure that you set the interface speed correctly. When the bandwidth is set, the Virtual NGFW Engine always scales the total amount of traffic on this interface to the bandwidth you defined. The bandwidth is scaled even if there are no bandwidth limits or guarantees defined for any traffic.

5) Click OK.

The specified VLAN ID is added to the physical interface.

Next steps

Continue the configuration in one of the following ways:

- (Virtual Firewall only) If you do not want to add tunnel interfaces for the Route-Based VPN, add IP addresses directly to the physical interfaces.
- Otherwise, click ★ Save and Refresh to transfer the configuration changes.

Add IP addresses for Virtual Firewalls

You can add one or more IPv4 and IPv6 addresses to a Physical Interface or VLAN Interface on a Virtual Firewall.

You can add both IPv4 and IPv6 addresses to the same interface.

Add IPv4 addresses to Virtual Firewall interfaces

You can add one or more static IPv4 addresses for Virtual Firewall interfaces.

Steps • For more details about the product and how to configure features, click Help or press F1.

- Right-click a Virtual Firewall and select Edit Virtual Firewall.
 The Engine Editor opens.
- 2) In the navigation pane on the left, select Interfaces.
 The Interfaces pane opens on the right.
- 3) Right-click a Physical Interface, VLAN Interface, or Tunnel Interface and select New > IPv4 Address.



Note: If you have added VLAN Interfaces to Physical Interfaces, add the IPv4 Addresses to the VLAN Interfaces.

Enter the IPv4 Address.



Tip: To resolve the IP address from a DNS name, right-click the field, then select **Resolve** From DNS Name.

- 5) If necessary, define the contact address information.
 - Enter the **Default** contact address. The default contact address is used by default whenever a component that belongs to another Location connects to this interface.
 - If components from some Locations cannot use the Default contact address, click Exceptions to define Location-specific contact addresses.
- 6) Check the automatically filled-in **Netmask** and adjust it as necessary.
- 7) Click OK.

Next steps

Continue the configuration in one of the following ways:

- Add IPv6 addresses.
- If you are creating a new Virtual Firewall, or if you want to change the roles the different interfaces have in the configuration, select interface options for Virtual Firewall interfaces.
- Otherwise, click Save and Refresh to transfer the configuration changes.

Add IPv6 addresses to Virtual Firewall interfaces

You can add one or more static IPv6 addresses for Virtual Firewall interfaces.

Steps • For more details about the product and how to configure features, click **Help** or press **F1**.

- Right-click a Virtual Firewall and select Edit Virtual Firewall.
 The Engine Editor opens.
- 2) In the navigation pane on the left, select Interfaces.
 The Interfaces pane opens on the right.
- Right-click a Physical interface and select New > IPv6 Address or right-click a VLAN Interface and select New IPv6 Address.

The IP Address Properties dialog box opens.



Note: If you have added VLAN Interfaces to Physical Interfaces, add the IPv6 Addresses to the VLAN Interfaces.

4) Enter the IPv6 Address.



Tip: To resolve the IP address from a DNS name, right-click the field, then select **Resolve From DNS Name**.

- 5) Check the automatically filled-in Prefix Length and adjust it if necessary by entering a value between 0-128. The Network Address is automatically generated.
- 6) Click OK.

Next steps

Continue the configuration in one of the following ways:

- If you are creating a new Virtual Firewall, or if you want to change the roles the different interfaces have in the
 configuration, select interface options for Virtual Firewall interfaces.
- Otherwise, click Save and Refresh to transfer the configuration changes.

Select additional options for Virtual Firewall interfaces

In the Virtual Firewall's interface options, you can select which IP addresses are used in particular roles. Interface Options can only be configured for Virtual Firewalls.

All communication between Virtual Firewalls and the SMC is proxied by the Master NGFW Engine. Virtual Firewalls do not have any interfaces for system communication.

Steps @ For more details about the product and how to configure features, click Help or press F1.

- 1) Right-click a Virtual Firewall, then select Edit Virtual Firewall.
- In the navigation pane on the left, browse to Interface > Interface Options.
- 3) Select the interface options.
- 4) Click OK.

Next steps

Continue the configuration in one of the following ways:

- Add loopback IP addresses for the Virtual Firewall.
- If you are configuring a new Virtual NGFW Engine, click Save, close the Engine Editor, then add routes for the Master NGFW Engine.
- Otherwise, click Save and Refresh to transfer the configuration changes.

Add Virtual IPS elements

Virtual IPS elements store the configuration information related to the Virtual IPS engines.

Selecting a Virtual Resource for the Virtual IPS element automatically adds the Virtual IPS element to the Master NGFW Engine where the Virtual Resource is used.

- 1) Select . Configuration.
- Right-click NGFW Engines and select New > IPS > Virtual IPS.
- 3) In the Name field, enter a unique name.
- 4) Next to the Virtual Resource field, click Select and select a Virtual Resource on the Master NGFW Engine to which you want to add the Virtual IPS.
- 5) (Optional) In the **DNS IP Addresses** field, add one or more IP addresses.
 - DNS IP addresses are IP addresses of external DNS servers. Virtual IPS engines use these DNS servers to resolve Domain names to IP addresses. Virtual IPS engines need DNS resolution to contact services that are defined using URLs or domain names, and to resolve fully qualified domain names (FQDNs) used in policies.
 - To enter a single IP address manually, click Add and select IP Address. Enter the IP address in the dialog box that opens.
 - · To define an IP address using a network element, click Add and select Network Element.
- (Optional) Next to the Category field, click Select and select one or more categories.

Click Save.
 Do not close the Engine Editor.

Next steps

Configure interfaces for the Virtual IPS engine.

Configuring physical interfaces for Virtual IPS engines

Physical interfaces for Virtual IPS engines represent interfaces allocated to the Virtual IPS engine in the Master NGFW Engine.

When you select the Virtual Resource for the Virtual IPS engine, physical interfaces are automatically created based on the interface configuration of the Master NGFW Engine. The number of physical interfaces depends on the number of interfaces allocated to the Virtual IPS engine in the Master NGFW Engine. It is not recommended to create new physical interfaces in the Virtual IPS engine properties, as they might not be valid.

You can optionally change the automatically created physical interfaces in the Virtual IPS engine properties. For detailed instructions, see the *Forcepoint Next Generation Firewall Product Guide*.

If the configuration of the Master NGFW Engine allows it, you can add VLANs to physical interfaces on the Virtual IPS engine. If you do not want to add VLANs, add IP addresses to the physical interfaces.

Add VLAN interfaces to Virtual NGFW Engine interfaces

VLANs divide a single physical network link into several virtual links.

VLAN interfaces can only be added for Virtual NGFW Engines if the creation of VLAN interfaces for Virtual Firewalls is enabled in the Master NGFW Engine Properties. The maximum number of VLANs for a single physical interface is 4094. The VLANs must also be defined in the configuration of the external switch or router to which the interface is connected.



Note: You cannot add VLAN interfaces on top of other VLAN interfaces. Depending on the configuration of the Master NGFW Engine, you might not be able to create valid VLAN interfaces for the Virtual NGFW Engine. Contact the administrator who configured the Master NGFW Engine.

- Right-click a Virtual Firewall, Virtual IPS engine, or Virtual Layer 2 Firewall and select Edit <element type>.
 The Engine Editor opens.
- 2) In the navigation pane on the left, select **Interfaces**. The **Interfaces** pane opens on the right.
- 3) Right-click a physical interface and select New > VLAN Interface.

Define the VLAN interface properties.



CAUTION: The throughput for the Virtual Firewall physical interface must not be higher than the throughput for the Master NGFW Engine interface that hosts the Virtual Firewall. Contact the administrator of the Master NGFW Engine before changing this setting.



CAUTION: Make sure that you set the interface speed correctly. When the bandwidth is set, the Virtual NGFW Engine always scales the total amount of traffic on this interface to the bandwidth you defined. The bandwidth is scaled even if there are no bandwidth limits or guarantees defined for any traffic.

5) Click OK.

The specified VLAN ID is added to the physical interface.

Next steps

Continue the configuration in one of the following ways:

- (Virtual Firewall only) If you do not want to add tunnel interfaces for the Route-Based VPN, add IP addresses directly to the physical interfaces.
- Otherwise, click Save and Refresh to transfer the configuration changes.

Add Virtual Layer 2 Firewall elements

Virtual Layer 2 Firewall elements store the configuration information related to the Virtual Layer 2 Firewalls.

Selecting a Virtual Resource for the Virtual Layer 2 Firewall automatically adds the Virtual Layer 2 Firewall to the Master NGFW Engine where the Virtual Resource is used.

- 1) Select . Configuration.
- Right-click NGFW Engines and select New > Layer 2 Firewall > Virtual Layer 2 Firewall.
 The Engine Editor opens.
- 3) In the Name field, enter a unique name.
- 4) Next to the **Virtual Resource** field, click **Select** and select a Virtual Resource on the Master NGFW Engine to which you want to add the Virtual Firewall.
- 5) (Optional) In the **DNS IP Addresses** field, add one or more IP addresses of DNS servers that the Virtual Firewall uses to resolve domain names. There are two ways to define IP addresses.
 - To enter a single IP address manually, click Add and select IP Address. Enter the IP address in the dialog box that opens.
 - To define an IP address using a network element, click Add and select Network Element.
- (Optional) Next to the Category field, click Select and select one or more categories.

Click

Save.

Do not close the Engine Editor.

Next steps

Configure interfaces for the Virtual Layer 2 Firewall.

Configuring Physical Interfaces for Virtual Layer 2 Firewalls

Physical interfaces for Virtual Layer 2 Firewalls represent interfaces allocated to the Virtual Layer 2 Firewall in the Master NGFW Engine.

When you select the Virtual Resource for the Virtual Layer 2 Firewall, physical interfaces are automatically created based on the interface configuration of the Master NGFW Engine. The number of physical interfaces depends on the number of interfaces allocated to the Virtual Layer 2 Firewall in the Master NGFW Engine. It is not recommended to create new physical interfaces in the Virtual Layer 2 Firewall properties, as they might not be valid.

You can optionally change the automatically created physical interfaces in the Virtual Layer 2 Firewall properties. For detailed instructions, see the *Forcepoint Next Generation Firewall Product Guide*.

Add VLAN interfaces to Virtual NGFW Engine interfaces

VLANs divide a single physical network link into several virtual links.

VLAN interfaces can only be added for Virtual NGFW Engines if the creation of VLAN interfaces for Virtual Firewalls is enabled in the Master NGFW Engine Properties. The maximum number of VLANs for a single physical interface is 4094. The VLANs must also be defined in the configuration of the external switch or router to which the interface is connected.



Note: You cannot add VLAN interfaces on top of other VLAN interfaces. Depending on the configuration of the Master NGFW Engine, you might not be able to create valid VLAN interfaces for the Virtual NGFW Engine. Contact the administrator who configured the Master NGFW Engine.

- Right-click a Virtual Firewall, Virtual IPS engine, or Virtual Layer 2 Firewall and select Edit <element type>.
 The Engine Editor opens.
- 2) In the navigation pane on the left, select **Interfaces**. The **Interfaces** pane opens on the right.
- 3) Right-click a physical interface and select New > VLAN Interface.

4) Define the VLAN interface properties.



CAUTION: The throughput for the Virtual Firewall physical interface must not be higher than the throughput for the Master NGFW Engine interface that hosts the Virtual Firewall. Contact the administrator of the Master NGFW Engine before changing this setting.



CAUTION: Make sure that you set the interface speed correctly. When the bandwidth is set, the Virtual NGFW Engine always scales the total amount of traffic on this interface to the bandwidth you defined. The bandwidth is scaled even if there are no bandwidth limits or guarantees defined for any traffic.

5) Click OK.

The specified VLAN ID is added to the physical interface.

Next steps

Continue the configuration in one of the following ways:

- (Virtual Firewall only) If you do not want to add tunnel interfaces for the Route-Based VPN, add IP addresses directly to the physical interfaces.
- Otherwise, click Save and Refresh to transfer the configuration changes.

■ Forcepoint Next Generation Firewall 6.2 Installation Guide						

CHAPTER 9

Configuring Forcepoint NGFW software

Contents

- Options for initial configuration on page 143
- Using plug-and-play configuration on page 144
- Using automatic configuration on page 147
- Configure Forcepoint NGFW software using the NGFW Initial Configuration Wizard on page 149

After configuring the engine elements in the SMC, configure settings for the NGFW Engine, and contact the Management Server.

Options for initial configuration

You can configure the Forcepoint NGFW software using plug-and-play configuration, automatic configuration, or the NGFW Initial Configuration Wizard.

Your appliance comes pre-loaded with Forcepoint NGFW software. If you have an NGFW Engine license, you can configure the engine in any of the three NGFW Engine roles. If you have a license for a specific type of engine (Firewall/VPN or IPS), you can only use the engine in that specific role.

There are three ways to configure the Forcepoint NGFW software.

Plug-and-play configuration — Connect the antennas (some models only) and the network cables to the appliance. The appliance automatically connects to the Installation Server, downloads the initial configuration, and connects to the Management Server.



Note: Uploading the initial configuration to the Installation Server can only be used with Forcepoint NGFW appliances and proof-of-serial codes. It is only supported for Single Firewalls that have a dynamic control IP address.



Note: If the appliance does not have a DSL port and no 3G modem is connected to the appliance, Ethernet port 0 is the only port that can be used.

Automatic configuration — You can configure the engine automatically with a USB drive that contains the initial configuration.



Note: Automatic configuration using a USB drive is primarily intended to be used with Forcepoint NGFW appliances, and might not work in all other environments.

- NGFW Initial Configuration Wizard If you do not want to use plug-and-play configuration or automatic configuration, or they are not possible to use, you can use the NGFW Initial Configuration Wizard. You can use the NGFW Initial Configuration Wizard in two ways:
 - Connect a serial cable to the appliance and use the NGFW Initial Configuration Wizard on the command line.

Connect an Ethernet cable to the appliance and use the NGFW Initial Configuration Wizard in a web

Before a policy can be installed on the appliance, you must configure some permanent and some temporary network settings for the engine.

To successfully complete the initial configuration:

- The SMC must be installed.
- The NGFW Engine elements (Firewall, IPS, or Layer 2 Firewall elements) must be defined in the Management Client.
- 3) Engine-specific configuration information must be available from the Management Server. The required information depends on the configuration method.
 - For plug-and-play configuration, the engine's initial configuration must be uploaded to the Installation Server.
 - For automatic configuration, you must have the initial configuration file on a USB drive.
 - For the NGFW Initial Configuration Wizard, you must have a one-time password for the engine.

The appliance must contact the Management Server before it can be operational.

Using plug-and-play configuration

In plug-and-play configuration, the Forcepoint NGFW appliance automatically connects to the Installation Server, downloads the initial configuration, and connects to the Management Server.

Prepare for plug-and-play configuration

To use plug-and-play-configuration, save the initial configuration and upload it to the Installation Server.

- In the Management Client, select . Configuration.
- Right-click the engine for which you want to save the initial configuration, then select Configuration > Save **Initial Configuration.**
- 3) (Optional) If you already have a policy you want to use for the engine, click Select, then select a policy as the initial security policy.
 - The selected policy is automatically installed on the engine after the engine has contacted the Management Server.

- (Optional) Select Enable SSH Daemon to allow remote access to the engine command line.
 - Enabling SSH in the initial configuration gives you remote command-line access in case the configuration is imported correctly, but the engine fails to establish contact with the Management Server.
 - After the engine is fully configured, SSH access can be set on or off using the Management Client. We recommend that you enable the SSH access in the Management Client when needed and disable the access again when you are finished. Make sure that your Access rules allow SSH access to the engines from the administrators' IP addresses only.



CAUTION: If you enable SSH, set the password for command-line access after the initial configuration either through the Management Client or by logging on to the command line. When the password is not set, anyone with SSH access to the engine can set the password.

- 5) From the Local Time Zone drop-down list, select the time zone.
 - The time zone selection is used only for converting the UTC time that the engines use internally for display on the command line. All internal operations use UTC time, which is synchronized with the Management Server's time after the engine is configured. For external operations, engines use the time zone of their geographical location.
- 6) From the Keyboard Layout drop-down list, select the keyboard layout used for the engine command line.
- 7) Select Upload to Installation Server to upload the initial configuration automatically to the Installation Server.
- Click Close.

Next steps

Configure the Forcepoint NGFW software using plug-and-play configuration.

Configure Forcepoint NGFW software using plug-and-play configuration

Connect the Forcepoint NGFW to the network to start the plug-and-play configuration.

Before you begin

The NGFW Engine's initial configuration must be uploaded to the Installation Server.

The Forcepoint NGFW appliance uses specific ports in a specific order when it tries to connect to the Installation Server.



Note: Use these default port settings in the properties of the corresponding engine interfaces that you have defined in the Management Client. The initial configuration fails if the port settings on the physical appliance and the interface definitions in the engine element properties are not the same.

Forcepoint NGFW appliances in the Firewall/VPN role first try to contact the Installation Server through the 3G modem if one is connected to a USB port. The 3G modem and the corresponding Modem interface in the Management Client must have the following settings:

- Access Point Name internet
- Phone number *99#
- PIN Code <empty value>



Note: PIN code must also be disabled on the 3G modem.

If attempts to connect to the Installation Server through the 3G modern fail, the appliance tries to connect to the Installation Server through Ethernet port 0. Appliances in the IPS or Layer 2 Firewall role always try to connect to the Installation Server through Ethernet port 0. In the Management Client, the corresponding Physical Interface must have a dynamic IPv4 address.

Steps

- 1) (Optional) If you want to view the progress of the plug-and-play configuration, connect the appliance to a computer using the serial cable supplied with the appliance, and use a terminal console program to connect to the NGFW appliance with these settings:
 - Bits per second 9600 or 115,200
 - Data bits 8
 - Parity None
 - Stop bits 1.



Note: The serial console port speed is 9600 bps in most NGFW appliances. The speed is 115,200 bps in the latest NGFW appliance models. See the hardware guide for your NGFW appliance model for more information.

- (Optional) Plug an empty USB drive into one of the USB ports on the appliance if you want to save information about the progress of the plug-and-play configuration on a USB drive. Saving the progress information about a USB drive can be useful, for example, for troubleshooting purposes.
- Connect the network cables to the appliance. On specific Forcepoint NGFW appliance models in the Firewall/VPN role with wireless support, connect the antennas.



Note: The wireless port on Forcepoint NGFW appliances in the Firewall/VPN role cannot be used for connecting to the Installation Server.

Result

The appliance automatically contacts the Installation Server. When the contact succeeds, the appliance downloads the initial configuration from the Installation Server, and contacts the Management Server. The appliance automatically restarts after initial contact with the Management Server.

If plug-and-play configuration fails

If the plug-and-play configuration fails, check for possible causes and solutions.

If you plugged in a USB drive to the appliance, check the sq autoconfig.log file on the USB drive.

If you see a connection refused error message, make sure that the Management Server IP address is reachable from the engine. Also check the settings that you have defined for the engine's interfaces in the Management Client. The port numbers and settings must match the interface IDs and other interface settings in the Management Client.

If attempts to connect to the Installation Server through the 3G modem and Ethernet port 0 have failed, the appliance starts the connecting process again. It retries the ports in the same order (3G modem, then Ethernet port 0). If necessary, you can run the command sq-reconfigure --stop-autocontact on the engine command line to stop this process.

If plug-and play-configuration continues to fail, save the initial configuration on a USB drive and configure the engine using the automatic configuration method.

Using automatic configuration

In automatic configuration, you configure the engine automatically with a USB drive that contains the initial configuration.

Prepare for automatic configuration

To use automatic configuration, save the initial configuration on a USB drive.

Steps @ For more details about the product and how to configure features, click Help or press F1.

- 1) In the Management Client, select . Configuration.
- Right-click the engine for which you want to save the initial configuration, then select Configuration > Save Initial Configuration.
- 3) (Optional) If you already have a policy you want to use for the engine, click Select, then select a policy as the initial security policy.
 - The selected policy is automatically installed on the engine after the engine has contacted the Management Server.
- 4) From the Local Time Zone drop-down list, select the time zone.
 - The time zone selection is used only for converting the UTC time that the engines use internally for display on the command line. All internal operations use UTC time, which is synchronized with the Management Server's time after the engine is configured. For external operations, engines use the time zone of their geographical location.
- 5) From the **Keyboard Layout** drop-down list, select the keyboard layout used for the engine command line.

- (Optional) Select Enable SSH Daemon to allow remote access to the engine command line.
 - Enabling SSH in the initial configuration gives you remote command-line access in case the configuration is imported correctly, but the engine fails to establish contact with the Management Server.
 - After the engine is fully configured, SSH access can be set on or off using the Management Client. We recommend that you enable the SSH access in the Management Client when needed and disable the access again when you are finished. Make sure that your access rules allow SSH access to the engines from the administrators' IP addresses only.



CAUTION: If you enable SSH, set the password for command-line access after the initial configuration either through the Management Client or by logging on to the command line. When the password is not set, anyone with SSH access to the engine can set the password.

Click Save As, then save the configuration file to the root directory of a USB drive.



CAUTION: Handle the configuration files securely. They include the one-time password that allows establishing trust with your Management Server.

Click Close.

Next steps

Configure the Forcepoint NGFW software using automatic configuration.

Configure Forcepoint NGFW software using automatic configuration

Automatic configuration is primarily intended to be used with Forcepoint NGFW appliances, and might not work in all environments when you use your own hardware.

If the automatic configuration does not work, use the NGFW Initial Configuration Wizard and import or enter the information manually.

When automatic configuration is used, Interface IDs are mapped to network interfaces on the engine in sequential order: Physical Interface ID 0 is mapped to eth0, Physical Interface ID 1 is mapped to eth1, and so forth.



Note: The imported configuration does not contain a password for the root account. You must set the password manually in the Management Client before you can log on for command-line access to the engine. See the Forcepoint Next Generation Firewall Product Guide for more information.

Steps

 Make sure that you have a physical connection to the NGFW appliance using a monitor and keyboard or a serial cable.

If you use a serial cable, use a terminal console program to connect to the NGFW appliance with these settings:

- Bits per second 9600 or 115,200
- Data bits 8
- Parity None
- Stop bits 1.



Note: The serial console port speed is 9600 bps in most NGFW appliances. The speed is 115,200 bps in the latest NGFW appliance models. See the hardware guide for your NGFW appliance model for more information.

- Insert the USB drive.
- 3) Remove the DVD, then press **Enter** at the installation finished prompt.

The engine restarts, imports the configuration from the USB drive, and makes the initial contact to the Management Server.

- If the automatic configuration fails, and you do not have a monitor connected, check sg_autoconfig.log on the USB drive.
- If you see a connection refused error message, make sure that the Management Server IP address is reachable from the node.

Result

The configuration is complete when the appliance successfully contacts the Management Server and restarts.

Configure Forcepoint NGFW software using the NGFW Initial Configuration Wizard

You can import or manually configure the settings for the NGFW Engine using either the command line or the web browser version of the NGFW Initial Configuration Wizard.

There are some limitations for the web browser version of the NGFW Initial Configuration Wizard.

- Only IPv4 addresses are supported
- You must configure the SMC to use 256-bit security for communications
- You cannot connect the appliance to the network through a 3G modem
- You cannot configure PPPoA interfaces
- You cannot make the appliance follow FIPS 140-2 standards



Note: After completing the web browser version of the NGFW Initial Configuration Wizard, to make any changes to the configuration, you must start the configuration from the beginning. If

you only want to make minor changes to the configuration, use the command-line version of the NGFW Initial Configuration Wizard.

Prepare for NGFW Initial Configuration Wizard configuration

To use the NGFW Initial Configuration Wizard, save the initial configuration file or write down the configuration information for manual configuration.

Steps of For more details about the product and how to configure features, click **Help** or press **F1**.

- In the Management Client, select . Configuration.
- Right-click the engine for which you want to save the initial configuration, then select Configuration > Save **Initial Configuration.**
- To see the one-time passwords and fingerprints, click View Details. If you plan to import the configuration information, you do not need to write down or copy these details.
 - a) From the One-Time Password field, write down or copy the one-time password for each engine node. Make a note of which password belongs to which engine node.
 - From the Management Server Addresses field, write down or copy the IP addresses of the Management Server.
 - c) (Optional) From the Management Server Certificate Fingerprint (MD5) or Management Server Certificate Fingerprint (SHA-512) field, write down or copy the fingerprint of the Management Server's certificate.
 - d) Click Close.
- Select the other configuration options.
 - a) (Optional) If you already have a policy you want to use for the engine, click Select, then select a policy. The selected policy is automatically installed on the engine after the engine has contacted the Management Server.
 - b) From the Local Time Zone drop-down list, select the time zone. The time zone selection is used only for converting the UTC time that the engines use internally for display on the command line. All internal operations use UTC time, which is synchronized with the Management Server's time once the engine is configured. For external operations, engines use the time zone of their geographical location.
 - From the Keyboard Layout drop-down list, select the keyboard layout used for the engine command line.

 Select Enable SSH Daemon to allow remote access to the engine command line. Enabling SSH in the initial configuration gives you remote command-line access in case the configuration is imported correctly, but the engine fails to establish contact with the Management Server. After the engine is fully configured, you can set SSH access on or off using the Management Client. We recommend that you enable the SSH access in the Management Client when needed and disable the access again when you are finished. Make sure that your Access rules allow SSH access to the engines from the administrators' IP addresses only.



CAUTION: If you enable SSH, set the password for command-line access after the initial configuration either through the Management Client or by logging on to the command line. When the password is not set, anyone with SSH access to the engine can set the password.

e) Under Manual Installation, click Save As, then save the configuration file.



CAUTION: Handle the configuration files securely. They include the one-time password that allows establishing trust with your Management Server.



Tip: Keep the Save or Upload Initial Configuration dialog box open while you configure the Forcepoint NGFW software.

Next steps

Start the NGFW Initial Configuration Wizard.

Start the NGFW Initial Configuration Wizard on the command line

Start the NGFW Initial Configuration Wizard to configure settings for the Forcepoint NGFW engine.



Tip: You can run the NGFW Initial Configuration Wizard at any time using the sq-reconfigure command on the engine command line.

Steps

- 1) If you are configuring a physical device, connect to the Forcepoint NGFW appliance.
 - a) Connect the Forcepoint NGFW appliance to a laptop or other client device using a serial cable.

- b) On the client device, use a terminal console program to connect to the NGFW appliance with these settings:
 - Bits per second 9600 or 115,200
 - Data bits 8
 - Parity None
 - Stop bits 1.



Note: The serial console port speed is 9600 bps in most NGFW appliances. The speed is 115,200 bps in the latest NGFW appliance models. See the hardware guide for your NGFW appliance model for more information.

- Connect the network cables to the Forcepoint NGFW appliance.
- Turn on the Forcepoint NGFW appliance.
- Start the NGFW Initial Configuration Wizard.



Note: On some appliance models, the NGFW Initial Configuration Wizard starts automatically.

- a) Press Enter to activate the console.
- b) When you are prompted to start the NGFW Initial Configuration Wizard, type Y, then press Enter.
- Select the role for the NGFW Engine.

If you have an NGFW Engine license, you can select any of the NGFW Engine roles. The role must correspond to the engine element (Firewall, Layer 2 Firewall, or IPS) that you defined in the Management Client. You can later change the engine's role. If you have a license for a specific type of engine (Firewall/ VPN or IPS), select the role that corresponds to the type of license you have.

- Highlight Role, then press Enter.
- b) Highlight Firewall, IPS, or Layer 2 Firewall, then press Enter.
- Select one of the following configuration methods:
 - Highlight Import, then press Enter to import a saved configuration.
 - Highlight Next, then press Enter to manually configure the engine's settings.
- If you have stored the configuration on a USB drive, import the configuration.
 - a) Select USB Memory, then press Enter.
 - b) Select the correct configuration file. The files are specific to each engine node.
 - c) Highlight Next, then press Enter.

Configure general settings on the command line

The settings include console keyboard layout, time zone, and other optional settings.

Some of the settings might be filled in if you imported the configuration from a USB drive.

Steps

- 1) Set the console keyboard layout.
 - a) Highlight the entry field for Keyboard Layout, then press Enter.
 - b) Highlight the correct layout, then press **Enter**.

The keyboard layout setting only applies to hardware that you connect to using a directly connected keyboard and monitor. This setting has no effect if you connect to the appliance through the serial console port or over the network using SSH.

If the keyboard layout that you want to use is not listed, select the best-matching available layout or select US_English.



Tip: Type the first letter of the keyboard layout to skip ahead in the list.

- Set the time zone.
 - Highlight the entry field for **Local Timezone**, then press **Enter**.
 - b) Select the time zone from the list.

The time zone setting affects only the way the time is displayed on the engine command line. The actual operation always uses UTC time. The engine's clock is automatically synchronized with the Management Server's clock.

- Set the rest of the settings.
 - a) Enter the name of the engine.
 - b) Enter and confirm the password for the root user account.

This account is the only one with command-line access to the engine.

c) (Optional) Highlight Enable SSH Daemon, then press the spacebar to allow remote access to the engine command line using SSH.



Note: Unless you have a specific reason to enable SSH access to the engine command line, we recommend leaving it disabled.

(Optional) If you are required to follow the FIPS 140-2 standards, select Restricted FIPS-Compatible Operating Mode.



Note: This option only is for environments that are required to follow the FIPS 140-2 standards. Do not select this option unless you have a specific reason to do so.

e) Highlight Next, then press Enter.

Configure network interfaces on the command line

The NGFW Initial Configuration Wizard can automatically detect which network cards are in use. You can also add interfaces manually.

Steps

Define the network interface drivers.

If the list is not populated automatically, use auto-detect.

- Highlight Autodetect, then press Enter.
- Check that the autodetected information is correct and that all interfaces have been detected.



Tip: You can use the Sniff option for troubleshooting the network interfaces. Select Sniff to run a network sniffer on that interface.

If autodetection fails, add network drivers manually.

- Highlight Add, then press Enter.
- Select the correct driver for your network card, then press **Enter**.
- Map interfaces to the IDs you defined.
 - Change the IDs as necessary to define how the interfaces are mapped to the Interface IDs you defined for the engine element in the Management Client.
 - b) If necessary, highlight the Media column, then press Enter to change the settings to match those used by the device at the other end of the link.
 - Make sure that the speed/duplex settings of network cards are identical at both ends of each cable. For IPS and Layer 2 Firewall engines, also make sure that the speed/duplex settings of the inline interfaces match the speed/duplex settings of both links within each inline interface pair.
 - In the Mgmt column, highlight the correct interface for contact with the Management Server, then press the spacebar.



Important: The Management interface must be the same interface on which the control IP address for the corresponding element is configured in the SMC.

(Optional, IPS only) Highlight Initial Bypass, then press Enter to temporarily set the IPS engine to the initial bypass state and define one or more soft-bypass interface pairs through which traffic flows. Setting the appliance to the initial bypass state can be useful during IPS appliance deployment if bypass network interface pairs on the appliance are in Normal mode. Initial bypass allows traffic to flow through the IPS appliance until the initial configuration is ready and an IPS policy is installed on the appliance. Do not set the initial bypass state when the bypass network interface pairs are in Bypass mode.

Contact the Management Server on the command line

Provide the necessary information to allow the NGFW Engine to establish contact with the Management Server.

Before the engine can make initial contact with the Management Server, you activate the initial configuration on the engine. The initial configuration contains the information that the engine requires to connect to the Management Server for the first time.

If the initial configuration was imported from a USB drive, most of the options on the Prepare for Management Contact page are filled in.



Important: If there is a firewall between this engine and the Management Server, make sure that the intermediate firewall's policy allows the initial contact and all subsequent communications.

Steps

1) If the control IP address is dynamic, select DHCPv4, SLAAC (IPv6), or DHCPv6.



Note: The same protocol must be selected in the IP address properties in the Management Client.

- If the NGFW Engine uses PPP for management contact, define the PPP settings. 2)
 - Highlight **Settings**, then press **Enter**.
 - b) On the PPP Settings page, fill in the account details according to the information you have received from your service provider.
 - c) Highlight OK, then press Enter.
- 3) If the NGFW Engine uses a modem for management contact, define the modem settings.
 - Highlight **Settings**, then press **Enter**.
 - b) On the Modem Settings page, fill in the account details according to the information you have received from your service provider.
 - c) Highlight OK, then press Enter.
- If the control IP address is static, select Enter node IP address manually, then define the IP address of 4) the Forcepoint NGFW node.
 - In the IP Address field, enter the IP address.
 - b) In the Netmask/Prefix Length field, enter the netmask (IPv4) or prefix length (IPv6) of the network.
 - If the Management Server is not in a directly connected network, enter the IP address of the next-hop gateway in the Gateway to management field.
- If the control IP address is on a VLAN interface, select Use VLAN, Identifier, then enter the VLAN ID. 5)
- 6) Select Contact or Contact at Reboot, then press the spacebar.

7) Enter the Management Server IP address and the one-time password.



Note: The one-time password is engine-specific and can be used only for one initial connection to the Management Server. After initial contact has been made, the engine receives a certificate from the SMC for identification. If the certificate is deleted or expires, repeat the initial contact using a new one-time password.

(Optional) To use 256-bit encryption for the connection to the Management Server, select 256-bit Security 8) Strength, then press the spacebar.



Note: 256-bit encryption must also be enabled for the Management Server in the SMC.

(Optional) Highlight Edit Fingerprint, then press Enter. Fill in the Management Server's certificate 9) fingerprint (also shown when you saved the initial configuration).

Filling in the certificate fingerprint increases the security of the communications.

10) Highlight **Finish**, then press **Enter**.

> The engine now tries to make initial contact with the Management Server. The progress is displayed on the command line. If you see a connection refused message, make sure that the one-time password is correct and the Management Server IP address is reachable from the node. Save a new initial configuration if you are unsure about the password.



Note: If the initial management contact fails for any reason, you can start the configuration again with the sg-reconfigure command.

Result

After you see notification that Management Server contact has succeeded, the engine installation is complete and the engine is ready to receive a policy.

The engine element's status changes in the Management Client from Unknown to No Policy Installed. The connection state is Connected, indicating that the Management Server can connect to the node.

Next steps

Install a policy on the engine using the Management Client

Related information

Default communication ports on page 195

Start the NGFW Initial Configuration Wizard in a web browser

Start the NGFW Initial Configuration Wizard to configure settings for the Forcepoint NGFW engine.

Steps

- 1) If you are configuring a physical Forcepoint NGFW appliance, connect the appliance to a laptop or other client device.
 - a) Connect an Ethernet cable from the client device to physical port eth0 1 on the NGFW appliance. If the NGFW appliance does not have a port eth0 1, use port eth1 0. If using non-modular interfaces, use port eth1.
 - b) Connect the other network cables to the Forcepoint NGFW appliance.
- Turn on the Forcepoint NGFW appliance.
- 3) On the client device, open a web browser, then connect to https://169.254.169.169.
- When offered a web browser client certificate, accept the certificate.

Configure general settings in a web browser

The settings include keyboard layout, timezone, and other optional settings.

Steps

- 1) On the Welcome screen, select Start.
- Select I agree to the terms and conditions, then select Next.
- 3) Enter and confirm a password for the root user account, then select Next.
- Select the configuration method, then select Next.
 - If you have a .cfg configuration file, select Import.
 - If you want to enter the settings manually, select Manual.
- 5) If you selected **Import**, import the .cfg configuration file.
 - Select **Select File**, browse for the .cfg configuration file, then select the file.
 - b) Select Import Configuration.
 - c) After the file has been imported, select Next.
- If you selected Manual as the configuration method, select the role for the NGFW Engine, then select Next.
- On the Basic Information screen, enter the required information, then select Next.



Note: If you imported a configuration file, some of the information might be filled in automatically.

a) Enter the host name for the appliance.

- b) Select the time zone to use on the appliance.
 - The time zone setting affects only the way the time is displayed on the engine command line. The actual operation always uses UTC time. The engine's clock is automatically synchronized with the Management Server's clock.
- c) Select the keyboard layout to use when working on the command line of the engine.
 - The keyboard layout setting only applies to hardware that you connect to using a directly connected keyboard and monitor. This setting has no effect if you connect to the appliance through the serial console port or over the network using SSH.
- To allow connections to the engine using SSH, select Enable SSH Access.



Note: Unless you have a specific reason to enable SSH access to the engine command line, we recommend leaving it disabled.

Configure network interfaces in a web browser

The NGFW Initial Configuration Wizard can automatically detect which network cards are in use.



Note: If you imported a configuration file, the information is filled in automatically.

Steps

- To change the mapping of the interface IDs, select Change the Mapping.
 - a) Change the IDs as necessary to define how the interfaces are mapped to the interface IDs that you defined for the engine element in the Management Client.
 - b) If necessary, select the Speed/Duplex column to change the settings to match those used by the device at the other end of the link.
 - Make sure that the speed/duplex settings of network cards are identical at both ends of each cable. For IPS and Layer 2 Firewall engines, also make sure that the speed/duplex settings of the inline interfaces match the speed/duplex settings of both links within each inline interface pair.
 - c) Select Save, then select Next.
- Select the interface to use for management connectivity.
 - The Management interface must be the same interface on which the control IP address for the corresponding element is configured in the SMC.
- 3) If the Management interface is on a VLAN interface, enter the VLAN ID.
- 4) Set the interface type.
 - If the interface is a dynamic interface that receives its IP address from a DHCP Server, select Dynamic IPv4 Address (DHCP).
 - If the interface is dynamic interface that receives its IP address from a PPPoE Server, select Dynamic IPv4 Address (PPPoE Server), select PPPoE Settings, then fill in the account details according to the information you have received from your service provider.
 - If the interface is a static interface, select **Static**, then enter the IP address and netmask.

- 5) Select Next.
- 6) Enter the IP address of the Management Server.
- 7) If the Management Server is not located in a directly-connected network, enter the IP address of the next hop gateway in the **Default Gateway** field.
- Select Next.

Contact the Management Server in a web browser

Provide the necessary information to allow the NGFW Engine to establish contact with the Management Server.



Note: If you imported a configuration file, the information is filled in automatically.



Important: If there is a firewall between this engine and the Management Server, make sure that the intermediate firewall's policy allows the initial contact and all subsequent communications.

Steps

- 1) Select when you want the appliance to make contact with the Management Server.
 - At the end of this session The appliance makes contact after you confirm the entered information.
 - After the appliance restarts The appliance makes contact after you confirm the entered information and the appliance restarts.
- Enter the one-time password generated by the SMC.



Note: The one-time password is engine-specific and can be used only for one initial connection to the Management Server. After initial contact has been made, the engine receives a certificate from the SMC for identification. If the certificate is deleted or expires, repeat the initial contact using a new one-time password.

3) (Optional if you set the appliance to attempt to make contact at the end of this session) Enter the SHA-512 fingerprint generated by the SMC.

Filling in the certificate fingerprint increases the security of the communications.

- Select Next.
- 5) Review the configuration summary, then continue the configuration in one of the following ways:
 - . If you set the initial contact to be made at the end of this session, select Finish and Contact the Management Server.
 - If you set the initial contact to be made after the appliance restarts, select Apply Configuration and Finish.

If you set the initial contact to be made after the appliance restarts, after the configuration has been applied, select Finish and Turn Off.

When you turn the appliance back on, the appliance makes the initial contact.

7) If you set the initial contact to be made at the end of this session, and if you did not previously enter the SHA-512 fingerprint generated by the SMC, verify that the fingerprint shown matches, then select Finish and Proceed.



Note: If you do not select Finish and Proceed within the timeout, the Reject option is used, and you must make the initial contact again.

Result

After the initial contact has been made successfully, the NGFW Initial Configuration Wizard shuts down and the Ethernet port used to connect to the appliance is released for regular use.

If you set the initial contact to be made at the end of this session, a notification is shown in the web browser. If you set the initial contact to be made after the appliance restarts, the notification is not shown.

The engine element's status changes in the Management Client from Unknown to No Policy Installed. The connection state is Connected, indicating that the Management Server can connect to the node.



Note: If the status remains Unknown, run the NGFW Initial Configuration Wizard again, and review the settings. All settings can be changed, except for the engine role. To change the engine role, you must first reset the appliance to factory default settings.

Next steps

After the appliance has been configured, install a policy on the engine using the Management Client.

Troubleshoot using the NGFW Initial Configuration Wizard in a web browser

If you are unable to make contact with the Management Server, you can generate an sgInfo file to send to Forcepoint support, or you can reset the appliance to factory default settings and try configuring the appliance again.

Steps

- 1) Generate an sglnfo file that contains information for Forcepoint support to use.
 - a) In the top right corner of the screen, select \Rightarrow > Information for support.
 - b) Select Get Information for support.
 - c) Select **Download**, then save the sginfo.tar.gz file to your client device.
- Reset the appliance to factory default settings.
 - a) In the top right corner of the screen, select ♥ > Reset to factory default settings.



Note: This option is available only after you get to the Configuration Method screen.

b) Select Confirm Reset.



Note: You do not receive confirmation that the reset has completed.

■ Forcepoint Next Generation Firewall 6.2 Installation Guide					

R CHAPTER 10

NGFW Engine post-installation tasks

Contents

- Configuring routing and basic policies on page 163
- Monitor and command NGFW Engines on page 172

After successfully configuring the Forcepoint NGFW software and establishing contact between the NGFW Engines and the Management Server, the engine is left in the initial configuration state. Now you must define basic routing and policies.

Configuring routing and basic policies

Define basic routing and policies using the Management Client.

Configuring routing

Routes to directly connected networks are automatically added according to the interfaces defined for each engine. You must add some other routes manually.



Note: Master NGFW Engines proxy all communication between Virtual NGFW Engines and other SMC components. You do not need to configure routing for Virtual Firewalls, Virtual IPS engines, or Virtual Layer 2 Firewalls.

You must add the following routes for firewalls:

- The default route that packets to any IP addresses not included in the routing configuration takes. The default route always leads to the Internet if the site has Internet access.
- Routes through next-hop gateways to networks that are not directly connected to the engine.



Note: Interfaces that belong to an aggregated link on a firewall have the same network definitions. Only the first interface selected for the aggregated link is shown in the list of interfaces. For aggregated links in load-balancing mode, make sure that the router supports the Link Aggregation Control Protocol (LACP), and that LACP is configured on the router.

The routing information for IPS engines and Layer 2 Firewalls is only used for system communications. The inspected traffic is not routed. Inline interfaces are always fixed as port pairs: traffic that enters through one port is automatically forwarded to the other port.

Most often only one or two simple tasks are required to define routing information for IPS and Layer 2 Firewall elements:

- Add the default route. This route is the one that packets to any IP addresses that are not included in the routing configuration take.
- Add routes to your internal networks that are not directly connected to the IPS or Layer 2 Firewall if the networks cannot be reached through the default gateway.

Routing is configured using the following elements:

- **Network** elements represent a group of IP addresses.
- Router elements represent next-hop routers that are used for single-link routing and to represent the ISP routers inside NetLink elements.
- NetLink elements represent next-hop routers that are used for Multi-Link routing on firewalls. In Multi-Link routing, traffic is automatically distributed between two or more (usually Internet) connections.

Add a default route for a single network link

Add a default route using a single network connection.

For NGFW Engines in the IPS and Layer 2 Firewall roles, you only need to define a default route if the SMC components are not on a directly connected network.

Steps of For more details about the product and how to configure features, click Help or press F1.

- In the Management Client, select . Configuration.
- Right-click the engine element, then select **Edit <element type>**.
- In the navigation pane on the left, browse to **Routing**. 3)
- Expand the routing tree to view routing information for the interfaces.



Tip: If you want to view the full routing information for all interfaces, click Expand All.

- Add a next-hop router to the interface through which you want to create a default route.
 - a) Right-click the Network element, then select Add Router.
 - b) In the Name field, enter a unique name.
 - In the IP Address field, enter the IP address of the router.
 - d) Click OK.
- Right-click the Router element, then select Set as Default Route. The default element Any Network is added to the interface.
- Click H Save.

Add a default route for firewalls with Multi-Link

Add a default route for firewalls that use Multi-Link for multiple network connections.

Steps of For more details about the product and how to configure features, click **Help** or press **F1**.

- Open the routing configuration for the engine.
 - In the Management Client, select . Configuration.
 - b) Right-click the engine element, then select **Edit <element type>**.
 - In the navigation pane on the left, browse to **Routing**.
 - d) Expand the routing tree to view routing information for the interfaces.




Tip: If you want to view the full routing information for all interfaces, click 🗷 Expand

- 2) To create a NetLink element, right-click the network under an interface that is used as one of the default routes (to the Internet), then select Add Static NetLink or Add Dynamic NetLink.
- 3) Select ♥ Tools > New > Static NetLink or ♥ Tools > New > Dynamic NetLink.
- In the Name field, enter a name for the NetLink. 4)
- (Static NetLink only) From the **Gateway** drop-down list, select a gateway. 5)
- 6) (Static NetLink only) Click Select next to the Network list.
- 7) (Static NetLink only) Select **Networks**, then select a network.

To create a network:

- a) Select ♥ Tools > New > Network.
- b) In the Name field, enter a name for the network.
- In the IPv4 Address or IPv6 Address field, enter the IP address of the network.
- In the Netmask or Prefix Length field, enter the netmask or the prefix length (0-128).
- (Optional) Select Broadcast and network addresses included to include broadcast and network addresses in the network.
- Click OK.
- g) Select the network that you created, then click **Select**.
- 8) (Optional) In the Provider Name field, enter the name of the service provider for your own reference.
- 9) Click OK.

10) To add the default route for Multi-Link, right-click the NetLink, then select Set as Default Route. This inserts the default Any Network element.



In the illustration, internal networks are connected to the Internet using two Internet connections. It makes no difference which interfaces are internal and which are external. The firewall policy defines which traffic is allowed.



Note: The configuration outlined is only a part of the Multi-Link configuration. For complete steps required for a fully featured Multi-Link configuration, see the Forcepoint Next Generation Firewall Product Guide.

Click H Save. 11)

Add other routes

The networks that are directly connected to the engine are automatically added to the Routing view. However, you might also need add routes to networks that are not directly connected.

For NGFW Engines in the IPS and Layer 2 Firewall roles, you only need to add other routes if one or more SMC components are not directly connected and cannot be reached through the default gateway.

Steps @ For more details about the product and how to configure features, click Help or press F1.

- 1) In the Management Client, select . Configuration.
- Right-click the engine element, then select Edit <element type>.
- In the navigation pane on the left, browse to **Routing**.

Expand the routing tree to view routing information for the interfaces.



Tip: If you want to view the full routing information for all interfaces, click 🗷 Expand All.

- In the Routing Tools pane at the bottom of the Routing pane, click the Add Route tab.
- In the **Destination** field, enter an IP address.



Tip: You can also double-click the field, then select a destination device.

In the Gateway field, enter an IP address.



Tip: You can also double-click the field, then select a gateway device.

Click Add. The route is added to the configuration.

Click H Save.

Antispoofing

Spoofing an IP address means that someone uses the IP address of some legitimate (internal) host to gain access to protected resources.

Spoofing can be prevented with antispoofing entries. The antispoofing configuration is automatically generated based on the routing information of engines. By default, connection attempts with a source IP address from a certain internal network are only allowed through if they are coming from the correct interface as defined in the routing tree. As the routing entry is needed for the communications to work, antispoofing rarely needs additional modifications.

You can make exceptions for individual hosts to the automatically generated antispoofing configuration. For more information, see the Forcepoint Next Generation Firewall Product Guide.

Defining basic policies for firewalls

To get your firewall up and running, create rules for inspecting traffic.

In addition to the rules in the policy, the other configuration information is also transferred to the firewall when you install a policy. (This information includes the interface definitions and routing information).

Create a Firewall Policy

Create a basic policy for firewalls.

Steps of For more details about the product and how to configure features, click Help or press F1.

1) Select . Configuration.

- 2) Right-click Policies and select New > Firewall Policy.
- 3) In the **Name** field, enter a name for the Policy.
- Select the Firewall Template as the template. 4) Only the Firewall Template is available because you have not created other templates yet.
- 5) Click OK. The policy opens for editing.
- To add a rule, double-click the green row, or right-click the row and select Rule > Add Rule. 6)

Note: Inherited rules are not editable in the policy that inherits the rules.

- Click Save and Install to save the policy and transfer the changes to the engine. 7)
- 8) Select one or more engines, then click Add.
- 9) Leave Validate Policy Before Upload selected if you want to validate the rules in the policy. If you validate the rules and the routing configuration at policy installation, the issues found in the policy are displayed in a separate pane in the tab that opens to show the progress of the policy installation.
- Click OK. 10)

Example: Adding a ping rule

This example shows how to add Access rules and NAT rules to track ping connections.

By default, the engine maintains connection tracking information about connections allowed by a rule. You only have to add rules for allowing the opening of connections. After the connection is opened, reply packets that belong to that connection are allowed through if they are appropriate for the state of that particular connection. A second rule is only needed if connection opening must be allowed from the other end as well.

For the ping rule in this example, the replies to pings made by the Test host are allowed through automatically. However, if someone else tries to ping the Test host through the engine, the connection is blocked.



Note: Multi-Link load balancing requires additional configuration and a specific type of NAT rule. See the Forcepoint Next Generation Firewall Product Guide for information.

Steps of For more details about the product and how to configure features, click Help or press F1.

- Open your Firewall Policy for editing.
 - a) Select . Configuration.
 - b) Browse to Policies > Firewall Policies.
 - c) Right-click your Firewall Policy element and select Edit Firewall Policy.
- On the IPv4 Access tab, right-click the ID cell and select Add Rule Before or Add Rule After.

- Create a Host element.
 - a) Click the Source cell of the new rule. A list of elements opens in the **Resources** pane on the left.
 - b) Right-click Network Elements and select New > Host.
 - c) In the Name field, enter TEST host.
 - d) In the IPv4 Address field, enter the IPv4 address of the Host.
 - e) Click OK.
- Click the Source cell and begin typing TEST host. When the correct element is found, select it from the list.
- Right-click the **Destination** cell and select **Set to ANY**.
- Click the Service cell and type Ping. When the correct element is found, select it from the list.
- Right-click the **Action** cell and select **Allow**.
- (Optional) Add a NAT rule for the ping rule.
 - a) Right-click the IPv4 Access rule you created and select Copy Rule.
 - b) On the IPv4 NAT tab, right-click the green row and select Paste. A NAT rule with the same source, destination, and service as the IPv4 Access rule is added.
 - Right-click the NAT cell and select Edit NAT.
 - d) Select Static as the Translation Type.
 - Click **Address** and enter the public IP address of the Test host.

The original IP address is the content of the Source cell in the NAT rule because this rule defines source address translation. There is no need to specify that the destination address in the reply packets must be translated back to the Test host's private IP address. This return translation is done automatically. The static translation used in this rule is only practical for a few hosts. Dynamic translation is more suitable for many translations, such as for Internet access for the whole office network.

- Click OK.
- Save and install the policy.
 - a) Click Save and Install to save the policy and transfer the changes to the engine.
 - b) Select the correct engine.
 - c) Click Add.
 - If you want to validate the rules in the policy, leave Validate Policy Before Upload selected. If you validate the rules and the routing configuration at policy installation, the issues found in the policy are displayed in a separate pane in the tab that opens to show the progress of the policy installation.
 - e) Click OK.

Installing the initial policy for IPS engines and **Layer 2 Firewalls**

To be able to inspect traffic, the engines must have a policy installed on them.

Installing one of the predefined policies provides an easy way to begin using the system. You can then fine-tune the system as needed. The following table describes the default policy elements for IPS engines and Layer 2 Firewalls.

Table 11: Default Policy elements

Element type	Default element name	Description
IPS Template Policy	High-Security IPS Template	IPS Template Policy that uses Inspection rules from the High-Security Inspection Template.
		A Template Policy containing the predefined Access rules necessary for the IPS engine to communicate with the SMC and some external components.
		The High-Security IPS Template Policy provides an easy starting point for determining what kinds of rules your system needs.
	Medium-Security IPS Template	IPS Template Policy that uses Inspection rules from the Medium-Security Inspection Policy.
IPS Policy	Customized High- Security Inspection IPS Policy	Example of a customized IPS Policy that uses Inspection rules from the Customized High-Security Inspection Template. Used in testing Forcepoint NGFW in the IPS role at ICSA Labs and NSS Labs.
	Default IPS Policy	Basic IPS Policy that uses Inspection rules from the High- Security Inspection Template. Can be used as a starting point for creating a customized IPS Policy.
		The Default IPS Policy does not add any rules to the rules defined in the IPS Template. It allows you to install the predefined rules in the IPS Template on the IPS engine right after installation. (Template Policies cannot be installed on the engines.)
Layer 2 Firewall Template Policy	Layer 2 Firewall Template	A Template Policy that contains the predefined Access rules necessary for the Layer 2 Firewall to communicate with the SMC and some external components.
		The Layer 2 Firewall Template uses Inspection rules from the No Inspection Policy. The rules in the No Inspection Policy do not enforce inspection.
	Layer 2 Firewall Inspection Template	A Template Policy that is based on the Layer 2 Firewall Template.
		The Layer 2 Firewall Inspection Template uses Inspection rules from the High-Security Inspection Template. The Layer 2 Firewall Inspection Template enables deep inspection for all traffic.

Element type	Default element name	Description
Inspection Policy	No Inspection Policy	Suitable for Firewall deployments, in which only packet filtering is needed. Disables deep packet inspection.
	Medium-Security Inspection Template	For Firewalls, Layer 2 Firewalls, inline IPS deployments in asymmetrically routed networks, and IPS deployments in IDS mode. Terminates reliably identified attacks and logs Situations that have some degree of inaccuracy. Low risk of false positives.
	High-Security Inspection Template	For Firewall, Layer 2 Firewall, and inline IPS use. Extended inspection coverage and evasion protection. Not for asymmetrically routed networks. Terminates reliably identified attacks, and Situations that have some inaccuracy. Moderate false positive risk.
	Customized High- Security Inspection Policy	This policy is an example of a highly customized Inspection Policy for network environments in which unconditional inspection coverage and evasion protection are required. The risk of false positives is high in production use.

The default policy elements are introduced when you import and activate a recent dynamic update package (for example, during the installation). The elements might change when you install newer update packages. None of the default policy elements can be changed. However, you can make copies of the default policies if you create an edited version. See the Forcepoint Next Generation Firewall Product Guide for more information about the predefined policies and templates.

Install a ready-made policy for IPS engines and **Layer 2 Firewalls**

Install a ready-made policy on your IPS engine or Layer 2 Firewall.

When you install a policy, all rules in the policy and all IPS engine's or Layer 2 Firewall's other configuration information (including interface definitions and routing information) are transferred to the engines.

For details about product features, usage, and best practices, click? or Help.

Steps

- 1) Select . Configuration.
- Expand the Policies branch and select IPS Policies or Layer 2 Firewall Policies.
- Right-click one of the ready-made policies and select Install Policy. The Policy Upload Task Properties dialog box opens.
- 4) Select one or more engines, then click Add. The selected engines are added to the **Target** list.
- 5) Click OK.

A new tab opens to show the progress of the policy installation.

6) Check that the policy installation is successful.

Monitor and command NGFW Engines

Check system status and give commands to engines.

After a successful policy installation, your system is ready to process traffic. You can control the engines using the right-click menu.

Steps @ For more details about the product and how to configure features, click Help or press F1.

- Select # Home.
- Check the status of the engines and SMC.



Tip: You can select an element to view more information.

Use the **Commands** right-click menu to command engines.



Note: Depending on the selection in the tree, you can give commands individually for each node, for a selected group of nodes, for a whole cluster, or several engines at the same time.

Next steps

To continue setting up your system, see the Forcepoint Next Generation Firewall Product Guide.

PART IVMaintenance

Contents

- Maintaining the SMC on page 175
- Upgrading NGFW Engines on page 183

To maximize the benefit of Forcepoint NGFW, upgrade the SMC and Forcepoint NGFW regularly.



G CHAPTER 11

Maintaining the SMC

Contents

- Upgrading the SMC on page 175
- Uninstall the SMC on page 180

When there is a new version available, upgrade the SMC before upgrading NGFW Engines.

Upgrading the SMC

You can upgrade SMC components without uninstalling the previous version.

Before upgrading, read the Release Notes.

It is important to upgrade the SMC components before upgrading the engines. An old SMC version might not be able to recognize the new version engines and can generate an invalid configuration for them. The Management Server can control several older versions of engines. See the release notes for version-specific compatibility information.



CAUTION: All SMC components (Management Server, Management Client, Log Server, and the optional Web Portal Server) must use the same software version to be able to work together. Plan ahead before upgrading the components. If you have multiple Management Servers and Log Servers, you must upgrade each server separately.

The NGFW Engines do not require a continuous connection to the SMC and they continue to operate normally during the SMC upgrade. The engines temporarily store their logs locally if the Log Server is unavailable and then send them to the Log Server as it becomes available again.

For more detailed instructions, see the Forcepoint Next Generation Firewall Product Guide.

Configuration overview

- Obtain the installation files and check the installation file integrity.
- 2) (If automatic license upgrades have been disabled) Upgrade the licenses.
- 3) Upgrade all components that work as parts of the same SMC.
- 4) Upgrade any locally installed Management Clients by running the Security Management Center installer and any Web Start distributions that are on an external server.

Related concepts

Upgrading licenses for SMC components on page 176

Related tasks

Upgrade SMC servers on page 177

Upgrading licenses for SMC components

You must upgrade the license if you upgrade a component to a new major release.

A change in the first two digits of the version number indicates a major release (for example, from 1.2.3 to 1.3.0, or from 1.2.3 to 2.0.0). If only the last number changes, the existing license is also valid for the higher software version.

When you installed the SMC for the first time, you installed licenses that work with all versions up to that particular version. Each license indicates the highest version for which the license is valid, but the license is also valid for all lower software versions.

If you do not need to upgrade licenses, upgrade the SMC.

Related tasks

Upgrade SMC servers on page 177

Upgrade licenses manually

If you have not enabled automatic license upgrades in the Management Server properties, upgrade licenses manually through the Management Client.

Licenses are valid for any older software versions in addition to the version indicated on the license. You can upgrade the licenses at any time without affecting the system's operation.



Note: IP-address-bound licenses have been previously available for Firewalls and IPS engines. You can use and update a previously generated IP-address-bound engine license, but you must change the license binding to the Management Server's POL code if the engine's control IP address changes.

Steps 9 For more details about the product and how to configure features, click **Help** or press **F1**.

- 1) Select . Configuration, then browse to Administration.
- 2) Select Licenses, then browse to the type of licenses that you want to upgrade.
- Select the license that you want to upgrade.
 Details about the selected license open in the Info pane.
- 4) In the Info pane, copy the license information to the clipboard in one of the following ways:
 - From the **Proof of License** field, copy the POL code.
 - From the Proof of Serial field, copy the POS code.
- 5) Go to https://stonesoftlicenses.forcepoint.com.

- 6) In the License Identification field, paste the POL or POS code, then click Submit.
- 7) Under the license information, click **Update**.
- 8) Enter any information needed for the upgrade request, then select the license files to update.
- 9) To send the license request, click Submit. A confirmation page opens, showing the details of your request. The licenses are available for download on the license page.

Install licenses

After you have upgraded the licenses, install the license in the Management Client.

Steps 9 For more details about the product and how to configure features, click **Help** or press **F1**.

- 1) In the Management Client, select ≡ Menu > System Tools > Install Licenses.
- Select the license files and click Install.
- 3) Select . Configuration, then browse to Administration.
- 4) Browse to Licenses > All Licenses.
- 5) Check that the licenses have now been correctly upgraded to the new version.



Tip: When you only upgrade the software version in the license, old licenses are automatically replaced.

Upgrade SMC servers

You can upgrade SMC servers without uninstalling the previous version. A change in the Management platform, such as a new operating system or different hardware, requires reinstalling the SMC.



CAUTION: All SMC components (Management Server, Management Client, Log Server, and the optional Web Portal Server) must use the same SMC software version to work together. If you have multiple Management Servers or Log Servers, you must upgrade each server separately.

The same installer works with all SMC components, including locally installed Management Clients.

If you have multiple Management Servers or Log Servers, you can upgrade them in any order. Management Servers are automatically isolated from database replication during the upgrade. There is no need to explicitly isolate the Management Servers before upgrading.

If you are upgrading from a very old version of the SMC, you might have to upgrade to an intermediate version first before upgrading to the latest version. See the Release Notes.

Steps 9 For more details about the product and how to configure features, click **Help** or press **F1**.

- 1) Start the installation in one of the following ways:
 - From a .zip file Unzip the file, then run setup.exe on Windows or setup.sh on Linux.
 - From a DVD Insert the installation DVD, then run the setup executable from the DVD.

Operating system	Path to executable
Windows 64-bit	\Forcepoint_SMC_Installer\Windows-x64\setup.exe
Linux 32-bit	/Forcepoint_SMC_Installer/Linux/setup.sh
Linux 64-bit	/Forcepoint_SMC_Installer/Linux-x64/setup.sh



Note: If the DVD is not automatically mounted in Linux, mount the DVD with "mount /dev/cdrom /mnt/cdrom".

- 2) To continue with the installation, read and accept the License Agreement.
 - The Installation Wizard automatically detects the previous installation directory.
- 3) To accept the installation directory, click **Next**.
 - The Installation Wizard displays the components to be upgraded.
- 4) (Management Server only, optional) To save a copy of the current installation that you can revert to at any time after the upgrade, select **Save Current Installation**.
- 5) Click Next.
- 6) (Management Server only) Select whether to back up the server, then click Next:
 - To create a backup that can be used and viewed without a password, select Yes.
 - To create a password-protected backup, select Yes, encrypt the backup. You are prompted for the
 password as you confirm the selection.
 - If you already have a recent backup of the Management Server, select No.
- 7) Check the preinstallation summary, then click **Install**.
 - The upgrade begins.
- (Optional) When the upgrade is complete, click the links in the notification to view the reports of changes the installer has made.
 - The report opens in your web browser.
- To close the installer, click Done.
- 10) Upgrade any SMC components that run on other computers (for example, additional Management Servers or Log Servers) in the same way.
- 11) (Multiple Management Servers only) Synchronize the management database between the Management Servers.

Synchronize databases between active Management Server and additional Management Servers

You must synchronize the configuration information manually through the Management Client after upgrading the Management Servers or after restoring a backup.

Before you begin

There must be a route between the Management Client and the Management Servers. If there is no route between the Management Client and the Management Servers, you cannot send a command through the Control Management Servers dialog box.

Manual management database synchronization is primarily meant for resynchronizing the databases after upgrading the SMC. We do not recommend using manual database synchronization unless you have a specific need to do so.

Steps • For more details about the product and how to configure features, click **Help** or press **F1**.

- 1) Connect to the active Management Server using the Management Client.
- 2) Select ≡ Menu > System Tools > Control Management Servers.
- 3) If the Management Client is in a different network than the additional Management Server, select the **Location** from which to send the command.

This action ensures that the command is sent to the correct Contact Address for the Management Server.

- 4) For each additional Management Server that you want to synchronize:
 - Right-click the Management Server and select Replication > Full Database Replication.
 You are prompted to confirm the replication.
 - b) Click Yes.
 - All existing configurations on the additional Management Server are overwritten.
 - c) Click OK to acknowledge the completion of the synchronization and wait for the Management Server to restart.
 - After the Management Server has restarted, its Replication Status is updated in the **Control Management Servers** dialog box.
- 5) Click Close to close the Control Management Servers dialog box.

Uninstall the SMC

Usually, it is not necessary to uninstall the SMC. You can uninstall the SMC if you have a specific need to do so.



Note: If you have several SMC components installed on the same computer, you cannot uninstall the SMC components one by one.

By default, the SMC is installed in the following directories:

- Windows C:\Forcepoint\Stonesoft Management Center
- Linux /usr/local/forcepoint/smc

There is a .stonegate directory in each user's home directory in the operating system, which contains the Management Client configuration files. These files are not automatically deleted. You can delete them manually after the uninstallation.

The sgadmin account is deleted during the uninstallation of the SMC.



Tip: Back up the Management Server and the Log Server to an external system before uninstalling the SMC if you want to preserve the stored data.

Uninstall the SMC in Windows

Use this process to uninstall the SMC in a Windows environment.

Steps

- 1) Start the uninstaller in one of the following ways:
 - Open the list of installed programs through the Windows Control Panel, right-click Forcepoint Stonesoft Management Center, and select Uninstall/Change.
 - Alternatively, run the script <installation directory>\uninstall\ uninstall.bat.
- When the uninstaller opens, click Uninstall.

All Security Management Center components are uninstalled.

Uninstall the SMC in Linux

Use this process to uninstall the SMC in a Linux environment.

You can uninstall the SMC in graphical mode or in non-graphical mode.

Steps

- 1) Stop the Security Management Center components on the computer.
- 2) Run the uninstaller script.
 - To uninstall in graphical mode, run the script <installation directory>/uninstall/uninstall.sh.

- To uninstall in non-graphical mode, run the script the script <installation directory>/ uninstall/uninstall.sh -nodisplay.
- 3) (Graphical mode only) When the uninstaller starts, click Uninstall.

Result

All SMC components are uninstalled.



G CHAPTER 12

Upgrading NGFW Engines

Contents

- How engine upgrades work on page 183
- Obtain NGFW Engine upgrade files on page 185
- Prepare NGFW Engine upgrade files on page 186
- Upgrading or generating licenses for NGFW Engines on page 186
- Upgrade engines remotely on page 189
- Upgrade engines locally on page 190

When a new version of Forcepoint Next Generation Firewall introduces features that you want to use, upgrade the Forcepoint NGFW engines.

How engine upgrades work

You can remotely upgrade engines using the Management Client or locally on the engine command line.

The upgrade package is imported to the Management Server manually or automatically. Before the import, the Management Server verifies the digital signature of the upgrade package using a valid Trusted Update Certificate. The signature must be valid for the import to succeed. Verification might fail for the following reasons:

- The SMC version is out of date. Upgrade the SMC before upgrading the engines.
- A signature is invalid or missing in the upgrade files. Obtain an official upgrade package.

After the upgrade package has been imported, you can apply it to selected engines through the Management Client. Before the upgrade is installed on the engines, the Management Server again verifies the digital signature of the upgrade package.

The engines have two alternative partitions for the software. When you install a new software version, it is installed on the inactive partition and the current version is preserved. This configuration allows rollback to the previous version in case there are problems with the upgrade. If the engine is not able to return to operation after the upgrade, it automatically switches back to the previous software version at the next restart. You can also switch the active partition manually.

You can upload and activate the new software separately. For example, you can upload the upgrade during office hours but activate it during a service window.

The currently installed working configuration (routing, policies) is stored separately and is not changed in an upgrade or a rollback. Although parts of the configuration can be version-specific (for example, if system communications ports are changed), the new software version can use the existing configuration. Possible version-specific adjustments are made when you refresh the policy after the upgrade.

Lifecycle models

There are two types of Forcepoint Next Generation Firewall releases:

- Long-Term Support (LTS) Long-Term Support versions are major versions of Forcepoint Next Generation
 Firewall that are maintained for at least two years from the release date.
- Feature Stream (FS) Feature Stream versions are major versions of Forcepoint Next Generation Firewall that introduce new features and enhancements. Support for Feature Stream versions is discontinued when a new major version of Forcepoint Next Generation Firewall is available.

We recommend using the most recent Long-Term Support version of Forcepoint Next Generation Firewall if you do not need any features from a later Feature Stream version.

For more information about the Forcepoint Next Generation Firewall lifecycle policy, see Knowledge Base article 10192.

Limitations

It is not possible to upgrade between a 32-bit version and a 64-bit version of the software. If you are running the software on third-party hardware, you can reinstall the software using the other version. In clusters, 32-bit and 64-bit nodes cannot be online simultaneously. Appliances support only the software architecture version that they are preinstalled with.

You cannot upgrade Virtual NGFW Engines directly. To upgrade Virtual NGFW Engines, you must upgrade the Master NGFW Engine that hosts the Virtual NGFW Engines.

What do I need to know before I begin?

The SMC must be up to date before you upgrade the engines. An old SMC version might not be able to recognize the new version engines and can generate an invalid configuration for them. The Management Server can control several older versions of engines. See the Release Notes for version-specific compatibility information.

During a cluster upgrade, it is possible to have the upgraded nodes online and operational side by side with the older version nodes. This way, you can upgrade the nodes one by one while the other nodes handle the traffic. However, you must upgrade all nodes to the same version as soon as possible, as prolonged use with mismatched versions is not supported.

The current engine version is displayed on the **General** tab in the **Info** pane when you select the engine. If the **Info** pane is not shown, select **Menu** > **View** > **Info**.

Beginning from version 5.9, all Forcepoint Next Generation Firewall licenses include the anti-malware feature by default.

Configuration overview

Follow these general steps to upgrade engines:

- 1) (Manual download of engine upgrade files) Prepare the installation files.
- 2) (Manual license updates) Update the licenses.
- 3) Upgrade the engines.

Obtain NGFW Engine upgrade files

If the Management Server is not set up to download engine upgrades automatically or if you want to upgrade engines locally, download the installation files manually.

Check the installation file integrity using the MD5 or SHA-1 file checksums. Windows does not have MD5 or SHA-1 checksum programs by default, but there are several third-party programs available.

Steps

- 1) Go to https://support.forcepoint.com.
- Enter your license code or log on using an existing user account.
- Select Downloads.
- 4) Under Network Security, click the version of the Forcepoint NGFW software that you want to download, then select the type of installation file to download.
 - The .zip file is used in the remote upgrade on all supported platforms. It can also be used for a local upgrade from a USB drive or a non-bootable DVD.
 - The .iso file allows you to create a bootable installation DVD for a local upgrade on platforms that have an
 optical drive.
- On your local computer, change to the directory that contains the files to be checked.
- 6) (Linux only) Generate a checksum of the file using one of the following commands, where filename is the name of the installation file:
 - shalsum filename
 - sha256sum filename
 - sha512sum filename

For Windows, see the documentation for the third-party checksum program.

Example:

```
$ sha1sum sg_engine_1.0.0.1000.iso
869aecd7dc39321aa2e0cfaf7fafdb8f sg engine 1.0.0.1000.iso
```

7) Compare the displayed output to the checksum on the website.



CAUTION: Do not use files that have invalid checksums. If downloading the files again does not help, contact Forcepoint support to resolve the issue.

Next steps

Prepare NGFW Engine upgrade files.

Related tasks

Upgrade engines remotely on page 189 Upgrade engines locally on page 190

Prepare NGFW Engine upgrade files

Prepare the NGFW Engine upgrade files depending on the type of files you downloaded and how you plan to upgrade.

Steps 9 For more details about the product and how to configure features, click **Help** or press **F1**.

- 1) To prepare a downloaded .zip file for a remote upgrade, follow these steps.
 - a) Log on to the Management Client and select ≡ Menu > File > Import > Import Engine Upgrades.
 - b) Select the engine upgrade (sg_engine_version_platform.zip) file and click Import.



Note: The Management Server verifies the digital signature of the .zip file before importing it. The signature must be valid for the import to succeed. If the verification fails, an error message is shown. Verification failure can result from an out-of-date SMC version or an invalid or missing signature.

The status bar at the bottom of the Management Client window shows the progress of the import.

- To prepare a downloaded .zip file for a local upgrade, copy the file to the root directory of a USB drive or a DVD.
- 3) To prepare a downloaded .iso file for a local upgrade, create the installation DVD for the engines with a DVD burning application that can correctly read and burn the DVD structure stored in the .iso images.
 If the end result is a DVD file with the original .iso file on it, the DVD cannot be used for installation.

Next steps

Continue in one of the following ways:

- If your license does not support the version that you are upgrading to, upgrade or generate licenses.
- Upgrade the engines remotely through the Management Server.
- Upgrade the engine locally at the engine site.

Upgrading or generating licenses for NGFW Engines

In some cases, you must upgrade licenses when you are upgrading an engine.

When you installed the engine software for the first time, you installed licenses that work with all versions of the engine up to that particular version. If the first two numbers in the old and the new versions are the same, the upgrade can be done without upgrading licenses (for example, when upgrading from 1.2.3 to 1.2.4). When either of the first two numbers in the old version and the new version are different, you must first upgrade your licenses (for example, when upgrading from 1.2.3 to 1.3.0). By default, licenses are regenerated and installed automatically.

You can view and download your current licenses online at https://stonesoftlicenses.forcepoint.com. You can also upgrade the licenses.

If you do not need to upgrade licenses, upgrade the engines.

Related tasks

Upgrade engines remotely on page 189

Upgrade engines locally on page 190

Upgrade licenses manually

If you have not enabled automatic license upgrades in the Management Server properties, upgrade licenses manually through the Management Client.

Licenses are valid for any older software versions in addition to the version indicated on the license. You can upgrade the licenses at any time without affecting the system's operation.



Note: IP-address-bound licenses have been previously available for Firewalls and IPS engines. You can use and update a previously generated IP-address-bound engine license, but you must change the license binding to the Management Server's POL code if the engine's control IP address changes.

Steps • For more details about the product and how to configure features, click **Help** or press **F1**.

- 1) Select . Configuration, then browse to Administration.
- 2) Select Licenses, then browse to the type of licenses that you want to upgrade.
- Select the license that you want to upgrade.
 Details about the selected license open in the Info pane.
- 4) In the Info pane, copy the license information to the clipboard in one of the following ways:
 - From the **Proof of License** field, copy the POL code.
 - From the Proof of Serial field, copy the POS code.
- 5) Go to https://stonesoftlicenses.forcepoint.com.
- 6) In the License Identification field, paste the POL or POS code, then click Submit.
- Under the license information, click Update.
- 8) Enter any information needed for the upgrade request, then select the license files to update.
- 9) To send the license request, click Submit.
 A confirmation page opens, showing the details of your request. The licenses are available for download on the license page.

Install licenses

After you have upgraded the licenses, install the license in the Management Client.

Steps o For more details about the product and how to configure features, click **Help** or press **F1**.

- In the Management Client, select

 Menu > System Tools > Install Licenses.
- Select the license files and click Install.
- 3) Select . Configuration, then browse to Administration.
- 4) Browse to Licenses > All Licenses.
- 5) Check that the licenses have now been correctly upgraded to the new version.



Tip: When you only upgrade the software version in the license, old licenses are automatically replaced.

Check licenses

After installing the upgraded licenses, check the license information.

When you upgrade licenses, the old licenses are automatically replaced with the new licenses.

Steps @ For more details about the product and how to configure features, click Help or press F1.

- 1) Select . Configuration, then browse to Administration.
- Browse to Licenses > NGFW Engines, Licenses > Firewall, or Licenses > IPS, depending on the type of licenses you have.

The licenses and their status are displayed.

- Verify that all engines are correctly licensed.
- 4) If any engines are not correctly licensed, you might need to upgrade or generate the licenses again.

Next steps

Continue the upgrade in one of the following ways:

- Upgrade the engines remotely through the Management Server.
- Upgrade the engines on the engine command line.

Upgrade engines remotely

The Management Server can remotely upgrade engine components that it manages.

Before you begin

Read the Release Notes for the new version, especially the required SMC version and any other version-specific upgrade issues that might be listed. To access the release notes, select **Configuration**, then browse to **Administration** > **Other Elements** > **Engine Upgrades**. Select the type of engine you are upgrading. A link to the release notes is included in the upgrade file's information. If the Management Server has no Internet connectivity, you can find the release notes at https://support.forcepoint.com/Documentation.

You can upgrade several engines of the same type in the same operation. However, we recommend that you upgrade clusters one node at a time and wait until an upgraded node is back online before you upgrade the other nodes. Clusters operate normally throughout the upgrade when the upgrade is done in stages. However, it is recommended to upgrade all nodes in the cluster to the same version as soon as possible. Prolonged use with mismatched versions is not supported. It is not possible to have 32-bit and 64-bit engines online in the cluster at the same time.

Steps • For more details about the product and how to configure features, click **Help** or press **F1**.

- Select # Home.
- Browse to Engines, then expand the nodes of the engine that you want to upgrade.
- 3) Right-click the node you want to upgrade, then select Commands > Go Offline.
- 4) (Optional) Enter an Audit Comment to be shown in the audit log entry that is generated when you send the command to the engine.
- 5) Click Yes.

The engine is turned offline shortly.

6) Right-click the node you want to upgrade, then select **Upgrade Software** or **Configuration > Upgrade Software** depending on your selection.



Note: You cannot upgrade Virtual NGFW Engines directly. To upgrade Virtual NGFW Engines, you must upgrade the Master NGFW Engine that hosts the Virtual NGFW Engines.

- 7) Select the type of **Operation** you want to perform:
 - Select Remote Upgrade (transfer + activate) to install the new software and reboot the node with the new version of the software.
 - Select Remote Upgrade (transfer) to install the new software on the node without an immediate reboot
 and activation. The node continues to operate with the currently installed version until you choose to
 activate the new version.

Select Remote Upgrade (activate) to reboot the node and activate the new version of the software that was installed earlier.



CAUTION: To avoid an outage, do not activate the new configuration simultaneously on all nodes of a cluster. Activate the new configuration one node at a time, and proceed to the next node only after the previous node is back online.

- 8) If necessary, add or remove **Target** engines. All engines in the same Upgrade Task must be of the same type.
- Select the correct Engine Upgrade file, then click OK.

If you choose to activate the new configuration, you are prompted to acknowledge a warning that the node will be rebooted. A new tab opens showing the progress of the upgrade. The time the upgrade takes varies depending on the performance of your system and the network environment. The engine is automatically rebooted and brought back online.

The upgrade overwrites the inactive partition and then switches the active partition. To undo the upgrade, use the sq-toggle-active command or the engine's boot menu to switch back to the previous software version on the other partition. This switch can also happen automatically at the next reboot if the engine is not able to successfully return to operation when it boots up after the upgrade.



Note: The Management Server verifies the digital signature of the upgrade package before installing it. The signature must be valid for the upgrade to succeed. If the verification fails, an error message is shown. Verification failure can result from an out-of-date SMC version or an invalid or missing signature.

Upgrade engines locally

You can upgrade the engines on the engine command line.

Before you begin

Upgrading locally requires a physical connection to the engine using a monitor and keyboard or a serial cable.

During a Firewall Cluster or Master NGFW Engine cluster upgrade, the upgraded nodes can be online and operational side by side with the older version nodes. However, you must upgrade all nodes to the same version as soon as possible, as prolonged use with mismatched versions is not supported.

There are two ways to upgrade engines locally:

- If the hardware has a DVD drive (a USB DVD drive can be used) and you have an installation DVD, you can upgrade from an installation DVD.
- You can upgrade from a .zip file on a USB drive or on a DVD.

Upgrade from an installation DVD

You can upgrade the engines to the latest version from a DVD that was shipped to you, or from a DVD that you have created from an .iso image that you downloaded from the Forcepoint website.

Steps

- Log on to the node as root with the password you set for the engine (you can set the password through the Management Client).
- 2) Insert the DVD into the engine's DVD drive.
- 3) Restart the node from the DVD with the command reboot (recommended) or by cycling the power (if you cannot log on).
 - You are promoted to select the upgrade type.
- 4) Enter 1 to upgrade the existing installation and press **Enter** to continue.
 - The upgrade process starts.
- 5) When the process is finished, eject the DVD and press **Enter** to restart.
- 6) If the command-line version of the NGFW Initial Configuration Wizard opens, configure the engine in the same way as after the first installation.
 - You can also use the web browser version of the NGFW Initial Configuration Wizard.
- 7) When the upgrade is finished, right-click the node in the Management Client and select Commands > Go Online.
 - A confirmation dialog box opens.
- 8) (Optional) Enter an **Audit Comment** to be shown in the audit log entry that is generated when you send the command to the engine.
- 9) Click Yes.



Note: If you are upgrading a cluster, start the upgrade on the next node only when the upgraded node is back online.

Related tasks

Configure Forcepoint NGFW software using the NGFW Initial Configuration Wizard on page 149

Upgrade from a .zip file

You can use a .zip file to upgrade the engine software locally on the engine command line.

Steps

 Log on to the node as root with the password set for the engine (you can set the password through the Management Client).

- 2) Insert the USB drive or the DVD.
- 3) Run the command sg-reconfigure. The NGFW Initial Configuration Wizard opens.
- 4) Select **Upgrade** and press **Enter**.
- 5) Select the source media where the upgrade file is located.
- 6) Select OK.

The software is upgraded.



Note: The NGFW Engine verifies the digital signature of the upgrade package before installing it. The verification can take several minutes. The signature must be valid for the upgrade to succeed. If the verification fails, an error message is shown. Verification failure can result from an out-of-date Forcepoint NGFW software version or an invalid or missing signature.

7) When prompted, press Enter.

The engine restarts with the new version.

MAPPENDICES

Contents

- Default communication ports on page 195
- Command line tools on page 203
- Installing SMC Appliance software on a virtualization platform on page 225
- Installing Forcepoint NGFW on a virtualization platform on page 227
- Installing Forcepoint NGFW software on third-party hardware on page 229
- Example network (Firewall/VPN) on page 239
- Example network (IPS) on page 245
- Cluster installation worksheet instructions on page 249



Appendix A

Default communication ports


Contents


- Security Management Center ports on page 195
- Forcepoint NGFW Engine ports on page 198

There are default ports used in connections between SMC components and default ports that SMC components use with external components.

Security Management Center ports

The most important default ports used in communications to and from SMC components are presented in the following illustrations.





This table lists the default ports SMC uses internally and with external components. Many of these ports can be changed. The names of corresponding default Service elements are also included for your reference.

Table 12: SMC default ports

Listening host	Port/protocol	Contacting hosts	Service description	Service element name
Additional Management Servers	8902- 8913/TCP	Management Server	Database replication (push) to the additional Management Server.	SG Control
DNS server	53/UDP, 53/TCP	Management Client, Management Server, Log Server	DNS queries.	DNS (UDP)
LDAP server	389/TCP	Management Server	External LDAP queries for display/ editing in the Management Client.	LDAP (TCP)
Log Server	162/UDP, 5162/ UDP	Monitored third-party components	SNMPv1 trap reception from third- party components. Port 162 is used if installed on Windows, port 5162 if installed on Linux.	SNMP (UDP)
Log Server	514/TCP, 514/ UDP, 5514/TCP, 5514/UDP	Monitored third-party components	Syslog reception from third-party components. Port 514 is used if installed on Windows, port 5514 if installed on Linux.	Syslog (UDP) [Partial match]

Listening host	Port/protocol	Contacting hosts	Service description	Service element name
Log Server	2055/UDP	Monitored third-party components	NetFlow or IPFIX reception from third-party components. Port 2055 is used in both Windows and Linux.	NetFlow (UDP)
Log Server	3020/TCP	Log Server, Web Portal Server, NGFW Engines	Alert sending from the Log Server and Web Portal Server.	SG Log
			Log and alert messages; monitoring of blacklists, connections, status, and statistics from NGFW Engines.	
Log Server	8914-8918/TCP	Management Client	Log browsing.	SG Data Browsing
Log Server	8916-8917/TCP	Web Portal Server	Log browsing.	SG Data Browsing (Web Portal Server)
Management Server	3021/TCP	Log Server, Web Portal Server	System communications certificate request/renewal.	SG Log Initial Contact
Management Server	8902-8913/TCP	Management Client, Log Server, Web Portal Server	Monitoring and control connections.	SG Control
Management Server	3023/TCP	Additional Management Servers, Log Server, Web	Log Server and Web Portal Server status monitoring.	SG Status Monitoring
		Portal Server	Status information from an additional Management Server to the active Management Server.	
Management Server	8903, 8907/TCP	Additional Management Servers	Database replication (pull) to the additional Management Server.	SG Control
Monitored third-party components	161/UDP	Log Server	SNMP status probing to external IP addresses.	SNMP (UDP)
NTP server	123/TCP or UDP	SMC Appliance	Receiving NTP information.	NTP
RADIUS server	1812/UDP	Management Server	RADIUS authentication requests for administrator logon.	RADIUS (Authentication)
			The default ports can be edited in the properties of the RADIUS Server element.	
Forcepoint NGFW update service	443/TCP	SMC servers	Update packages, engine upgrades, and licenses.	HTTPS
SMC Appliance	161/UDP	Third-party components	Requesting health and other information about the SMC Appliance.	SNMP
Update servers	443/TCP	SMC Appliance	Receiving appliance patches and updates.	HTTPS
SMC Appliance	22/TCP	Terminal clients	SSH connections to the command line of the SMC Appliance (disabled in FIPS mode).	SSH
Syslog server	514/UDP, 5514/ UDP	Log Server	Log data forwarding to syslog servers.	Syslog (UDP) [Partial match]
			The default ports can be edited in the LogServerConfiguration.txt file.	

Listening host	Port/protocol	Contacting hosts	Service description	Service element name
Terminal Client Firewall, Layer 2 Firewall, IPS, Master NGFW Engine	22/TCP	SMC Appliance	Contacting engines and moving SMC Appliance backups off the appliance. Note: SSH is disabled in FIPS mode.	SSH
Third-party components	2055/UDP	Log Server	NetFlow or IPFIX forwarding to third-party components. Port 2055 is used in both Windows and Linux.	NetFlow (UDP)
Third-party components	162/UDP	SMC Appliance	Sending SNMP status probing to external devices.	SNMP
Third-party components	445/TCP	SMC Appliance	Moving SMC Appliance backups off the appliance. Note: CIFS is disabled in FIPS mode.	CIFS
Web Portal Server	8931/TCP	Log Server	Connections from the Log Server to the Web Portal Server	SG Web Portal Control


Forcepoint NGFW Engine ports


The most important default ports used in communications to and from NGFW Engines and Master NGFW Engines are presented in the following illustrations.

See the table for a complete list of default ports for the engines.



Note: Master NGFW Engines use the same default ports as clustered NGFW Engines. Virtual NGFW Engines do not communicate directly with other system components.





This table lists the default ports for NGFW Engines and Master NGFW Engines. Many of these ports can be changed. The names of corresponding default Service elements are also included for your reference.

Table 13: NGFW Engine and Master NGFW Engine default ports

Listening host	Port/protocol	Contacting hosts	Service description	Service element name
DHCP server	67/UDP	Firewall	Relayed DHCP requests and requests from a firewall that uses dynamic IP address.	BOOTPS (UDP)
DHCPv6 server	547/UDP	Firewall	Requests from a firewall that uses dynamic IPv6 address.	N/A
External DNS server	53/UDP, 53/TCP	Firewall, Master NGFW Engine	Dynamic DNS updates and DNS relay.	DNS (TCP), DNS (UDP)
File reputation server	443/TCP	Firewall, Layer 2 Firewall, IPS, Master NGFW Engine	GTI File Reputation Server	HTTPS
Firewall	67/UDP	Any	DHCP relay on firewall engine.	BOOTPS (UDP)
Firewall	68/UDP	DHCP server	Replies to DHCP requests.	BOOTPC (UDP)
Firewall	80/TCP	Clients that need to authenticate to the Firewall	Browser Based User Authentication	НТТР
Firewall	443/TCP	Clients that need to authenticate to the Firewall	Browser Based User Authentication	HTTPS
Firewall	443/TCP	VPN clients using SSL tunneling	VPN client SSL tunneling	TLS
Firewall	443/TCP	SSL Portal users	SSL VPN Portal	HTTPS
Firewall	546/UDP	DHCPv6 server	Replies to DHCPv6 requests.	N/A
Firewall, Master NGFW Engine	500/UDP	VPN clients, VPN gateways	VPN negotiations, VPN traffic.	ISAKMP (UDP)
Firewall, Master NGFW Engine	636/TCP	Management Server	Internal user database replication.	LDAPS (TCP)
Firewall, Master NGFW Engine	2543/TCP	Any	User authentication (Telnet) for Access rules.	SG User Authentication
Firewall, Master NGFW Engine	4500/UDP	VPN client, VPN gateways	VPN traffic using NAT-traversal.	NAT-T
Firewall Cluster Node, Master NGFW Engine cluster node	3000-3001/UDP, 3002-3003, 3010/TCP	Firewall Cluster Node, Master NGFW Engine cluster node	Heartbeat and state synchronization between clustered Firewalls.	SG State Sync (Multicast), SG State Sync (Unicast), SG Data Sync
Firewall, Layer 2 Firewall, IPS, Master NGFW Engine	22/TCP	Terminal clients	SSH connections to the engine command line (disabled in FIPS mode).	SSH
Firewall, Layer 2 Firewall, IPS, Master NGFW Engine	4950/TCP	Management Server	Remote upgrade.	SG Remote Upgrade
Firewall, Layer 2 Firewall, IPS, Master NGFW Engine	4987/TCP	Management Server	Management Server commands and policy upload.	SG Commands

Listening host	Port/protocol	Contacting hosts	Service description	Service element name
Firewall, Layer 2 Firewall, IPS, Master NGFW Engine	15000/TCP	Management Server, Log Server	Blacklist entries.	SG Blacklisting
Firewall, Layer 2 Firewall, IPS, Master NGFW Engine	161/UDP	SNMP server	SNMP monitoring.	SNMP (UDP)
IPS Cluster Node	3000-3001/UDP, 3002-3003, 3010/TCP	IPS Cluster Node	Heartbeat and state synchronization between clustered IPS engines.	SG State Sync (Multicast), SG State Sync (Unicast), SG Data Sync
LDAP server	389/TCP	Firewall, Master NGFW Engine	External LDAP queries, including StartTLS connections.	LDAP (TCP)
Layer 2 Firewall Cluster Node	3000-3001/UDP, 3002-3003, 3010/TCP	Layer 2 Firewall Cluster Node	Heartbeat and state synchronization between clustered Layer 2 Firewalls.	SG State Sync (Multicast), SG State Sync (Unicast), SG Data Sync
Log Server	3020/TCP	Firewall, Layer 2 Firewall, IPS, Master NGFW Engine	Log and alert messages; monitoring of blacklists, connections, status, and statistics.	SG Log
Malware signature server	80/TCP	Firewall, Layer 2 Firewall, IPS, Master NGFW Engine	Malware signature update service.	НТТР
Management Server	3021/TCP	Firewall, Layer 2 Firewall, IPS, Master NGFW Engine	System communications certificate request/renewal (initial contact).	SG Initial Contact
Management Server	8906/TCP	Firewall, Layer 2 Firewall, IPS	Management connection for single engines with "Node-Initiated Contact to Management Server" selected.	SG Dynamic Control
RADIUS server	1812, 1645/UDP	Firewall, Master NGFW Engine	RADIUS authentication requests.	RADIUS (Authentication), RADIUS (Old)
RPC server	111/UDP, 111/ TCP	Firewall, Master NGFW Engine	RPC number resolve.	SUNRPC (UDP), Sun RPC (TCP)
Server Pool Monitoring Agents	7777/UDP	Firewall, Master NGFW Engine	Polls to the servers' Server Pool Monitoring Agents for availability and load information.	SG Server Pool Monitoring
SNMP server	162/UDP	Firewall, Layer 2 Firewall, IPS, Master NGFW Engine	SNMP traps from the engine.	SNMP Trap (UDP)
TACACS+ server	49/TCP	Firewall, Master NGFW Engine	TACACS+ authentication requests.	TACACS (TCP)
ThreatSeeker Intelligence Cloud server	443/TCP	Firewall, Layer 2 Firewall, IPS, Master NGFW Engine	ThreatSeeker Intelligence Cloud URL categorization service.	HTTPS
VPN gateways	500, 4500/UDP	Firewall, Master NGFW Engine	VPN traffic. Ports 443/TCP (or custom port) can also be used, depending on encapsulation options.	ISAKMP (UDP)

■ Forcepoint Next Generation Firewall 6.2 Installation Guide

Appendix B

Command line tools

Contents

- Security Management Center commands on page 203
- Forcepoint NGFW Engine commands on page 216
- Server Pool Monitoring Agent commands on page 222

There are command line tools for the SMC and the NGFW Engines.

Security Management Center commands

SMC commands include commands for the Management Server, Log Server, and Web Portal Server.

Most of the commands are found in the <installation directory>/bin/ directory. In Windows, the command line tools are *.bat script files. In Linux, the files are *.sh scripts.



Note: If you installed the Management Server in the C:\Program Files\Forcepoint\Stonesoft Management Center directory in Windows, some of the program data is stored in the C:\ProgramData\Forcepoint\Stonesoft Management Center directory. Command line tools can be found in the C:\Program Files\Forcepoint\Stonesoft Management Center\bin directory.

Commands that require parameters must be run through the command line (cmd.exe in Windows). Commands that do not require parameters can alternatively be run through a graphical user interface, and can be added as shortcuts during installation.



CAUTION: login and password parameters are optional. Giving them as command-line parameters can pose a security vulnerability. Do not enter logon and password information unless explicitly prompted to do so by a command line tool.

Table 14: Security Management Center commands

Command	Description
ambr-crl (SMC Appliance only)	Fetches the certificate revocation lists (CRLs) for the CA certificates used by the appliance maintenance and bug remediation (AMBR) utilities.
[-a ADD add=ADD]	-a ADD,add=ADD adds a CRL distribution point URL in the form of http:// <url>.</url>
[-d DELETE delete=DELETE]	-d DELETE,delete=DELETE deletes a CRL distribution point URL.
[-q query]	-q,query lists CRL distribution points.
[-i IMPORT_CRL	-i IMPORT_CRL,import=IMPORT_CRL imports a CRL from a file.
import=IMPORT_CRL]	-c,clean removes existing CRLs before fetching new CRLs.
[-c clean] [-v]	-v increases the verbosity of the command. You can repeat this command up to two times $(-vv or -v -v)$ to further increase the verbosity.
[-l <log file="" path="">]</log>	-1 <log file="" path=""> specifies the path to a log file.</log>
[-h help]	-h,help displays information about the command.
ambr-decrypt (SMC Appliance only)	Decrypts an ambr patch; not normally used by administrators. ambr-install automatically decrypts patches.
ambr-install <patch></patch>	Installs an ambr patch that has been loaded on the system.
(SMC Appliance only)	You can install multiple patches with a space between each patch name.
[-F force]	-F,force forces the reinstallation of the patch or patches.
[-r skip-revocation]	-r,skip-revocation skips the certificate revocation checks.
[no-backup]	no-backup does not create a configuration backup.
[no-snapshot]	no-snapshot does not create a recovery snapshot.
[-v] -1 <log file="" path="">]</log>	-v increases the verbosity of the command. You can repeat this command up to two times to further increase the verbosity.
[-h help]	-1 <log file="" path=""> specifies the path to a log file.</log>
	-h,help displays information about the command.
ambr-load <patch> (SMC Appliance only)</patch>	Loads an ambr patch onto the system from either the patch server or from the local file system. A loaded patch means that the file is copied to the local file system, but not installed.
[-f IN_FILES file=IN_FILES]	You can load multiple patches with a space between each patch name.
[-r skip-revocation]	-f IN_FILES,file=IN_FILES specifies the local file to load.
	-r,skip-revocation skips the certificate revocation checks.
<pre>[-l <log file="" path="">] [-h help]</log></pre>	-v increases the verbosity of the command. You can repeat this command up to two times to further increase the verbosity.
	-1 <log file="" path=""> specifies the path to a log file.</log>
	-h,help displays information about the command.

Command	Description
ambr-query	Displays patch information including:
(SMC Appliance only)	What is loaded or installed on the system
[-1 local]	A list of available updates from the patch server
[-w web]	Detailed information about a specific patch
[-a all]	-1,local displays a description of the installed or loaded patches on the SMC appliance. Displays the same information as the default ambr-query command.
[-i info <patch>]</patch>	-w,web displays a list of applicable updates that are available on the webserver
<pre>[-L <log file="" path="">] [-v]</log></pre>	for the current installation. Patch dependencies and the most direct update path are displayed with this option.
[-h help]	-a,all displays a list of all updates available on the webserver for the current installation.
	-i,info <patch> displays description information about the patch. You can get information about multiple patches in one command by separating the patch names with a space.</patch>
	$_{ m -v}$ increases the verbosity of the command. You can repeat this command up to two times to further increase the verbosity.
	-L <log file="" path=""> specifies the path to the file where log messages are written.</log>
	-h,help displays information about the command.
ambr-unload <patch> (SMC Appliance only)</patch>	Unloads an ambr patch from the system. The command deletes the patch file if it has not been installed, but it does not uninstall the patch.
[-a all]	You can unload multiple patches with a space between each patch name.
[-v]	-a,all unloads all loaded patches.
[-l <log file="" path="">]</log>	-v increases the verbosity of the command. You can repeat this command up to two
 [-h help]	times to further increase the verbosity.
	-1 <log file="" path=""> specifies the path to a log file.</log>
	-h,help displays information about the command.
ambr-verify (SMC Appliance only)	Verifies the signature of a patch file; not normally used by administrators. ambrinstall automatically verifies patches.

Command	Description
sgArchiveExport [host= <management server<="" td=""><td>Displays and exports logs from archive. Supports CEF, LEEF, and ESM formats in addition to CSV and XML.</td></management>	Displays and exports logs from archive. Supports CEF, LEEF, and ESM formats in addition to CSV and XML.
Address[\Domain>] [login= <login name="">]</login>	This command is only available on the Log Server. The operation checks permissions for the supplied administrator account from the Management Server to prevent unauthorized access to the logs.
[pass= <password>]</password>	Enclose details in double quotes if they contain spaces.
<pre>[format=<exporter csv="" format:="" or="" xml="">] i=<input and="" directories="" files="" or=""/></exporter></pre>	Host specifies the address of the Management Server. If the parameter is not defined, the loopback address (localhost) is used. login defines the user name for the account that is used for this operation. If this parameter is not defined, the user name root is used.
[o= <output file="" name="">]</output>	pass defines the password for the user account.
<pre>[f=<filter file="" name="">] [e=<filter expression="">]</filter></filter></pre>	format defines the file format for the output file. If this parameter is not defined, the XML format is used.
[-h -help -?]	i defines the source from which the logs are exported. Can be a folder or a file. The processing recurses into subfolders.
[-v]	o defines the destination file where the logs are exported. If this parameter is not defined, the output is displayed on screen.
	f defines a file that contains the filtering criteria you want to use for filtering the log data. You can export log filters individually in the Management Client through Tools > Save for Command Line Tools in the filter's right-click menu.
	e allows you to enter a filter expression manually (using the same syntax as exported filter files).
	-h, -help, or -? displays information about using the script.
	-v displays verbose output on the command execution.
	Example (exports logs from one full day to a file using a filter): sgArchiveExport login=admin pass=abc123 i=C:\Program Files\Forcepoint\Stonesoft Management Center\data\archive\firewall\year2011\month12\.\sgB.day01\ f=C:\Program Files\Forcepoint\Stonesoft Management Center\export\MyExportedFilter.flp format=CSV o=MyExportedLogs.csv
sgBackupLogSrv	Creates a backup of Log Server configuration data.
[pwd= <password>]</password>	The backup file is stored in the <installation directory="">/backups/ directory.</installation>
[path= <destpath>]destpath [nodiskcheck]</destpath>	Twice the size of the log database is required on the destination drive. Otherwise, the operation fails.
[comment = < comment >]	pwd enables encryption.
[nofsstorage]	path defines the destination path.
 [-h help]	nodiskcheck ignores the free disk check before creating the backup.
	comment allows you to enter a comment for the backup. The maximum length of a comment is 60 characters.
	nofsstorage creates a backup only of the Log Server configuration without the log data.
	-h orhelp displays information about using the script.

Command	Description
sgBackupMgtSrv [pwd= <password>]</password>	Creates a complete backup of the Management Server (including both the local configuration and the stored information in the configuration database). The backup file is stored in the <installation directory="">/backups/ directory.</installation>
<pre>[path=<destpath>] [nodiskcheck]</destpath></pre>	Twice the size of the Management Server database is required on the destination drive. Otherwise, the operation fails.
[comment= <comment>]</comment>	pwd enables encryption.
[-h help]	path defines the destination path.
	nodiskcheck ignores the free disk check before creating the backup. comment allows you to enter a comment for the backup. The maximum length of a comment is 60 characters.
	-h orhelp displays information about using the script.
	Also see sgRestoreMgtBackup and sgRecoverMgtDatabase.
sgCertifyLogSrv [host= <management address[\domain]="" server=""></management>	Contacts the Management Server and creates a certificate for the Log Server to allow secure communications with other SMC components. Renewing an existing certificate does not require changing the configuration of any other SMC components.
radicible (Domaring)	host specifies the address of the Management Server. If the parameter is not defined, the loopback address (localhost) is used.
	Domain specifies the administrative Domain the Log Server belongs to if the system is divided into administrative Domains. If the Domain is not specified, the Shared Domain is used.
	Stop the Log Server before running this command. Restart the server after running this command.
sgCertifyMgtSrv [login= <login name="">] [pass=<password>]</password></login>	Creates a certificate for the Management Server to allow secure communications between the SMC components. Renewing an existing certificate does not require changes on any other SMC components.
[standby-server= <name additional="" management="" of="" server="">] [active-server=<ip address="" of<="" td=""><td>In an environment with only one Management Server, or to certify the active Management Server, stop the Management Server before running the sgCertifyMgtSrv command. Run the command without parameters. Restart the Management Server after running this command.</td></ip></name>	In an environment with only one Management Server, or to certify the active Management Server, stop the Management Server before running the sgCertifyMgtSrv command. Run the command without parameters. Restart the Management Server after running this command.
<pre>active Management Server>] [-nodisplay] [-h -help -?]</pre>	To certify an additional Management Server, stop the additional Management Server before running the sgCertifyMgtSrv command. The active Management Server must be running when you run this command. The management database is replicated to the additional Management Server during the certification. The additional Management Server must have a connection to the active Management Server when you run this command.
	[login= <login name="">] defines the user name for the account that is used for this operation. If this parameter is not defined, the user name root is used.</login>
	[pass= <password>] defines the password for the user account.</password>
	[standby-server] specifies the name of the additional Management Server to be certified.
	[active-server] specifies the IP address of the active Management Server.
	-nodisplay sets a text-only console.
	h, help, or -? displays information about using the script.

Command	Description
sgCertifyWebPortalSrv [host= <management address[\domain]="" server="">]</management>	Contacts the Management Server and creates a certificate for the Web Portal Server to allow secure communications with other SMC components. Renewing an existing certificate does not require changing the configuration of any other SMC components.
	host specifies the address of the Management Server. If the parameter is not defined, the loopback address (localhost) is used.
	Domain specifies the administrative Domain the Web Portal Server belongs to if the system is divided into administrative Domains. If the Domain is not specified, the Shared Domain is used.
	Stop the Web Portal Server before running this command. Restart the server after running this command.
sgChangeMgtIPOnLogSrv <ip address></ip 	Changes the Management Server's IP address in the Log Server's local configuration to the IP address you give as a parameter.
	Use this command if you change the Management Server's IP address. Restart the Log Server service after running this command.
sgChangeMgtIPOnMgtSrv <ip address></ip 	Changes the Management Server's IP address in the local configuration to the IP address you give as a parameter.
	Use this command if you change the Management Server's IP address. Restart the Management Server service after running this command.
sgClient	Starts a locally installed Management Client.
sgCreateAdmin	Creates an unrestricted (superuser) administrator account. The Management Server must be stopped before running this command.

Command	Description
sgExport	Exports elements stored on the Management Server to an XML file.
[host= <management address[\domain]="" server="">]</management>	Enclose details in double quotes if they contain spaces.
[login= <login name="">]</login>	host specifies the address of the Management Server. If the parameter is not defined, the loopback address (localhost) is used.
[pass=password]	Domain specifies the administrative Domain for this operation if the system is divided
file= <file and="" name="" path=""></file>	into administrative Domains. If the Domain is not specified, the Shared Domain is used.
[type= <all nw ips sv rb al vpn></all nw ips sv rb al vpn>	
[name= <element 1,="" 2,="" element="" name="">]</element>	login defines the user name for the account that is used for this operation. If this parameter is not defined, the user name root is used.
[recursion]	pass defines the password for the user account.
[-system]	file defines the name and location of the export .zip file.
_	type specifies which types of elements are included in the export file:
[-h -help -?]	all for all exportable elements
	nw for network elements
	ips for IPS elements
	sv for services
	rb for security policies
	al for alerts
	vpn for VPN elements.
	name allows you to specify by name the elements that you want to export.
	recursion includes referenced elements in the export, for example, the network elements used in a policy that you export.
	-system includes any system elements that are referenced by the other elements in the export.
	-h, -help, or -? displays information about using the script.

Command	Description
sgHA	Controls active and standby Management Servers.
[host= <management address[\domain]="" server="">]</management>	If you want to perform a full database synchronization, use the sgOnlineReplication command.
[login= <login name="">] [pass=<password>]</password></login>	host specifies the address of the Management Server. If the parameter is not defined, the loopback address (localhost) is used.
[master= <management as="" for="" master="" operation="" server="" the="" used="">]</management>	Domain specifies the administrative Domain for this operation if the system is divided into administrative Domains. If the Domain is not specified, the Shared Domain is used.
[-set-active]	login defines the user name for the account that is used for this operation. If this parameter is not defined, the user name root is used.
[-set-standby]	pass defines the password for the user account.
[-check]	master defines the Management Server used as a master Management Server for the operation.
[-force]	-set-active activates and locks all administrative Domains.
[-restart]	-set-standby deactivates and unlocks all administrative Domains.
[-h -help -?]	-check checks that the Management Server's database is in sync with the master Management Server.
	-retry retries replication if this has been stopped due to a recoverable error.
	-force enforces the operation even if all Management Servers are not in sync.
	Note: This option can cause instability if used carelessly.
	-restart restarts the specified Management Server.
	-h, -help, or -? displays information about using the script.
sgImport	Imports Management Server database elements from an XML file.
[host= <management address[\domain]="" server="">]</management>	When importing, existing (non-default) elements are overwritten if both the name and type match.
[login= <login name="">]</login>	host specifies the address of the Management Server. If the parameter is not defined, the loopback address (localhost) is used.
[pass= <password>]</password>	Domain specifies the administrative Domain for this operation if the system is divided
<pre>file=<file and="" name="" path=""> [-replace_all]</file></pre>	into administrative Domains. If the Domain is not specified, the Shared Domain is used.
[-h -help -?]	login defines the user name for the account that is used for this operation. If this parameter is not defined, the user name root is used.
	pass defines the password for the user account.
	file defines the .zip file whose contents you want to import.
	-replace_all ignores all conflicts by replacing all existing elements with new ones.
	-h, -help, or -? displays information about using the script.

Command	Description
sgImportExportUser	Imports and exports a list of Users and User Groups in an LDIF file from/to a Management Server's internal LDAP database.
[host=< <management address[\domain]="" server="">>]</management>	To import User Groups, all User Groups in the LDIF file must be directly under the stonegate top-level group (dc=stonegate).
<pre>[login=<login name="">] [pass=password] action=<import export></import export></login></pre>	CAUTION: The user information in the export file is stored as plaintext. Handle the file securely.
file= <file and="" name="" path=""> [-h -help -?]</file>	host specifies the address of the Management Server. If the parameter is not defined, the loopback address (localhost) is used.
	Domain specifies the administrative Domain for this operation if the system is divided into administrative Domains. If the Domain is not specified, the Shared Domain is used.
	login defines the user name for the account that is used for this operation. If this parameter is not defined, the user name root is used.
	pass defines the password for the user account.
	action defines whether users are imported or exported.
	file defines the file that is used for the operation.
	Example: sgImportExportUser login=admin pass=abc123 action=export file=c:\temp\exportedusers.ldif
	-h, -help, or -? displays information about using the script.
sgInfo	Creates a .zip file that contains copies of configuration files and the system trace files.
SG_ROOT_DIR FILENAME	The resulting .zip file is stored in the logged on user's home directory. The file location is displayed on the last line of screen output. Provide the generated file to support for troubleshooting purposes.
[fast= <timestamp>]</timestamp>	SG_ROOT_DIR SMC installation directory.
[list]	FILENAME name of output file.
[hprof=none limited all]	fast collects only traces that changed after the specified time stamp. Enter the time
[-nolog]	stamp in milliseconds or in the format yyyy-MM-dd HH:mm:ss. No other information is
[-client]	collected, except for threaddumps.
[-h -help -?]	[list] only lists files. It does not create a .zip file or generate threaddumps.
	hprof defines whether hprof memory dump files are included. none does not include hprof memory dump files.
	 none does not include ripror memory dump files. limited includes only hprof memory dump files that are created with makeheap.
	all includes memory dump files that are created with makeheap and java_pid.
	-nolog extended Log Server information is not collected.
	-client collects traces only from the Management Client.
	-h, -help, or -? displays information about using the script.
	1, 101p, or . dioplays information about doing the soript.

Command	Description
sgOnlineReplication [active-server= <name active="" management="" of="" server="">] [-nodisplay] [-h -help -?]</name>	Replicates the Management Server's database from the active Management Server to an additional Management Server. Stop the Management Server to which the database is replicated before running this command. Restart the Management Server after running this command. Use this script to replicate the database only in the following cases: The additional Management Server's configuration has been corrupted. In new SMC installations if the automatic database replication between the Management Servers has not succeeded. Otherwise, synchronize the database through the Management Client. CAUTION: This script also has parameters that are for the internal use of the Management Server only. Do not use this script with any parameters other than the ones listed here. active-server specifies the IP address of the active Management Server from which the Management database is replicated. -nodisplay sets a text-only console. -h, -help, or -? displays information about using the script.
sgReinitializeLogServer	Creates a Log Server configuration if the configuration file has been lost. Note: This script is located in <installation directory="">/bin/install.</installation>
sgRestoreArchive <archive_dir></archive_dir>	Restores logs from archive files to the Log Server. This command is available only on the Log Server. ARCHIVE_DIR is the number of the archive directory (0–31) from where the logs will be restored. By default, only archive directory 0 is defined. The archive directories can be defined in the <installation directory="">/data/LogServerConfiguration.txt file: ARCHIVE_DIR_ xx=PATH.</installation>
sgRestoreLogBackup [-pwd= <password>] [-backup=<backup file="" name="">] [-nodiskcheck] [-overwrite-syslog-template] [-h -help]</backup></password>	Restores the Log Server (logs or configuration files) from a backup file in the <installation directory="">/backups/ directory. -pwd defines a password for encrypted backup. -backup defines a name for the backup file. -nodiskcheck ignores the free disk check before backup restoration. -overwrite-syslog-template overwrites a syslog template file if found in the backup. -h or -help displays information about using the script.</installation>
sgRestoreMgtBackup [-pwd= <password>] [-backup=<backup file="" name="">] [-import-license <license file="" name="">] [-nodiskcheck] [-h -help]</license></backup></password>	Restores the Management Server (database or configuration files) from a backup file in the <installation directory="">/backups/ directory. -pwd defines a password for encrypted backup. -backup defines a name for the backup file. -import-license specifies a license file to import during the backup restoration. -nodiskcheck ignores the free disk check before backup restoration. -h or -help displays information about using the script.</installation>

Command	Description
sgRevert	Reverts to the previous installation saved during the upgrade process.
	The previous installation can be restored at any time, even after a successful upgrade.
	Note: This script is located in <installation directory="">/bin/uninstall.</installation>
sgShowFingerPrint	Displays the CA certificate's fingerprint on the Management Server.
sgStartLogSrv	Starts the Log Server and its database.
sgStartMgtDatabase	Starts the Management Server's database.
	There is usually no need to use this script.
sgStartMgtSrv	Starts the Management Server and its database.
sgStartWebPortalSrv	Starts the Web Portal Server.
sgStopLogSrv	Stops the Log Server.
sgStopMgtSrv	Stops the Management Server and its database.
sgStopMgtDatabase	Stops the Management Server's database.
	There is usually no need to use this script.
sgStopWebPortalSrv	Stops the Web Portal Server.
sgStopRemoteMgtSrv	Stops the Management Server service when run without arguments.
<pre>[host=<management address[\domain]="" server="">]</management></pre>	To stop a remote Management Server service, provide the arguments to connect to the Management Server.
[login= <login name="">]</login>	host is the Management Server's host name if not localhost.
[pass= <password>]</password>	login is an SMC administrator account for the logon.
[-h -help -?]	pass is the password for the administrator account.
	-h, -help, or -? displays information about using the script.

Command	Description
sgTextBrowser	Displays or exports current or stored logs.
<pre>[host=<management address[\domain]="" server="">]</management></pre>	This command is available on the Log Server.
[login= <login name="">]</login>	Enclose the file and filter names in double quotes if they contain spaces.
[pass= <password>]</password>	host defines the address of the Management Server used for checking the logon
[format= <csv xml>]</csv xml>	information. If this parameter is not defined, Management Server is expected to be on the same host where the script is run. If Domains are in use, you can specify the
[o= <output file="">]</output>	Domain the Log Server belongs to. If domain is not specified, the Shared Domain is
[f= <filter file="">]</filter>	used.
[e= <filter expression="">]</filter>	login defines the user name for the account that is used for this export. If this parameter is not defined, the user name root is used.
- [m= <current stored>]</current stored>	pass defines the password for the user account used for this operation.
[limit= <maximum fetch="" number="" of="" records="" to="" unique="">]</maximum>	format defines the file format for the output file. If this parameter is not defined, the XML format is used.
[-h -help -?]	o defines the destination output file where the logs will be exported. If this parameter is not defined, the output is displayed on screen.
	f defines the exported filter file that you want to use for filtering the log data.
	e defines the filter that you want to use for filtering the log data. Type the name as shown in the Management Client.
	$_{ m m}$ defines whether you want to view or export logs as they arrive on the Log Server (current) or logs stored in the active storage directory (stored). If this option is not defined, the current logs are used.
	limit defines the maximum number of unique records to be fetched. The default value is unlimited.
	-h, -help, or -? displays information about using the script.
smca-agent (SMC Appliance only)	SMC uses it to exchange configuration data between SMC and the operating system; not normally used by administrators. The agent configures the NTP and SNMP daemons and sets the logon and SSH banners.
smca-backup	Creates a configuration backup of the operating system and includes an SMC backup.
(SMC Appliance only)	-pwd <password> enables the encryption of the backup file and sets the password.</password>
[-pwd <password>]</password>	-comment <comment> adds a comment to the backup file name.</comment>
[-comment <comment>]</comment>	-nodiskcheck turns off the available disk space check.
[-nodiskcheck]	-nofsstorage excludes the log files for the Log Server from the backup.
[-nofsstorage]	-nomlstorage excludes the SMC Appliance OS log files from the backup.
[-nomlstorage]	-path <destination> specifies a path for backup file storage. The default</destination>
[-path <destination>]</destination>	directory for backups is /usr/local/forcepoint/smc/backups.
[-h help]	-h,help displays information about the command.

Command	Description
smca-cifs	Configures the mounting of remote CIFS file shares on the SMC Appliance.
(SMC Appliance only)	add adds the CIFS share.
[add]	remove removes the CIFS share. Use with the name option.
[remove]	-n <name> specifies the name of the share.</name>
[-n <name>]</name>	-s // <server>/<share> specifies the server or IP address of the share.</share></server>
[-s // <server>/<share>] [-u <username>]</username></share></server>	-u <username> specifies the user name to authenticate with the CIFS server to get access to the share.</username>
[-p <password>]</password>	-p <password> specifies the password on remote system.</password>
[-d <domain>]</domain>	-d <domain> specifies the domain of the share.</domain>
smca-restore	Restores the SMC Appliance to the previous operational state.
(SMC Appliance only)	-pwd <password> specifies the password for decrypting an encrypted backup file.</password>
[-pwd <password>]</password>	-nodiskcheck turns off the available disk space check.
[-nodiskcheck]	-backup <filename> specifies the backup file name.</filename>
[-backup <filename>]</filename>	-overwrite-syslog-template overwrites any existing syslog templates in the log
[-overwrite-syslog-template]	backup file.
[-h -help]	-h,help displays information about the command.
smca-rsync	Configures automated backup tasks. Typically used with the smca-cifs command to
(SMC Appliance only)	move backups off the appliance. add adds a backup task. You can specify an existing source and destination
[add]	directories. If not specified, the default is /usr/local/forcepoint/smc/backups/.
[modify]	modify changes an existing backup task by its task ID. All attributes can be changed,
[remove]	except for the task ID. To change an attribute, use the appropriate option with a new value.
[enable]	remove removes an existing backup task by its task ID.
[disable]	enable enables an existing backup task by its task ID.
[list]	disable disables an existing backup task by its task ID.
[run]	list provides a list of all configured backup tasks.
[-t task_id]	run runs all enabled backup tasks.
[-i <source directory=""/>]	-t task_id specifies the task ID. Use the list command to view the task IDs.
[-o <destination directory="">]</destination>	-i <source directory=""/> specifies the directory where the backups are stored
[-m <mode>] [-h -help]</mode>	when they are created. If omitted, the source directory defaults to the SMC backups directory /usr/local/forcepoint/smc/backups/.
	-o <destination directory=""> specifies the remote location to store the backups.</destination>
	-m <mode> specifies the rsync mode. You can indicate whether rsync appends or mirrors the source directory to the destination directory. Appending the directory means that existing files in the destination directory, that are not in the source directory or are newer than those files in the source directory, are not changed. If omitted, the mode defaults to append.</mode>
	-h,help displays information about the command.

Command	Description
smca-system	Manages recovery snapshots, alternate partition mirroring, and changing system
(SMC Appliance only)	partition boot preference.
[toggle]	toggle restarts the appliance to the alternate partition.
[toggle-vcdrom]	toggle-vcdrom sets the appliance's default boot option to the vcdrom.
[mirror]	mirror mirrors the active system to the alternate system.
[snapshot]	snapshot manages recovery snapshots. Use with the create, restore, or delete options.
[-f]	-f forces the procedure, does not prompt for any confirmation.
[-n <name>]</name>	-n <name> specifies the name of the snapshot, used for mirror or snapshot</name>
[-C create]	operations.
[-R restore]	-C,create creates a snapshot. Use with the snapshot command.
[-D,delete]	-R,restore restores the snapshot. Use with the snapshot command.
[-h -help]	-D,delete deletes the snapshot. Use with the snapshot command.
	-h,help displays information about the command.
smca-user	This utility is used by the SMC Appliance to keep user accounts in sync between the
(SMC Appliance only)	SMC and the operating system; not normally used by administrators.

Forcepoint NGFW Engine commands

There are commands that can be run on the command line on Firewall, Layer 2 Firewall, IPS engines, or Master NGFW Engines.



Note: Using the Management Client is the recommended configuration method, as most of the same tasks can be done through it.



Note: All command line tools that are available for single NGFW Engines are also available for Virtual NGFW Engines that have the same role. However, there is no direct access to the command line of Virtual NGFW Engines. Commands to Virtual NGFW Engines must be sent from the command line of the Master NGFW Engine using the se-virtual-engine command.

Table 15: Forcepoint NGFW command line tools

Command	Engine role	Description
sg-blacklist	Firewall	Used to view, add, or delete active blacklist entries.
show [-v] [-f	Layer 2 Firewall	The blacklist is applied as defined in Access Rules.
FILENAME]	IPS	show displays the current active blacklist entries in format: engine node ID
add [blacklist entry ID (internal) entry creation time (internal) address and port match originally set duration (internal) (internal). Use the -f option to
[-i FILENAME]		specify a storage file to view (/data/blacklist/db_ <number>). The -v option</number>
[src IP_ADDRESS/MASK]		adds operation's details to the output.
[src6 IPv6_ADDRESS/ PREFIX]		add creates a blacklist entry. Enter the parameters or use the -i option to import parameters from a file.
[dst IP_ADDRESS/MASK]		del deletes the first matching blacklist entry. Enter the parameters or use the -i option to import parameters from a file.
[dst6 IPv6_ADDRESS/		iddel removes one specific blacklist entry on one specific engine. NODE_ID
PREFIX] [proto {tcp udp icmp		is the engine's ID, ID is the blacklist entry's ID (as shown by the show command).
NUM }]		flush deletes all blacklist entries.
[srcport PORT {-PORT}]		Add/Del Parameters:
[dstport PORT {-PORT}]		Enter at least one parameter. The default value is used for the parameters that
[duration Nom]		you omit. You can also save parameters in a text file; each line in the file is read as one blacklist entry.
del [src defines the source IP address and netmask to match. Matches any IP
[-i FILENAME]		address by default.
[src IP_ADDRESS/MASK]		src6 defines the source IPv6 and prefix length to match. Matches any IPv6 address by default.
[src6 IPv6_ADDRESS/ PREFIX]		dst defines the destination IP address and netmask to match. Matches any IP address by default.
[dst IP_ADDRESS/MASK]		dst6 defines the destination IPv6 address and prefix length to match.
[dst6 IPv6_ADDRESS/		Matches any IPv6 address by default.
PREFIX] [proto {tcp udp icmp		proto defines the protocol to match by name or protocol number. Matches all IP traffic by default.
<pre>NUM}] [srcport PORT{-PORT}]</pre>		srcport defines the TCP/UDP source port or range to match. Matches any port by default.
[dstport PORT{-PORT}]		dstport defines the TCP/UDP destination port or range to match. Matches any port by default.
[duration NUM]		duration defines in seconds how long the entry is kept. Default is 0, which
1		cuts current connections, but is not kept.
iddel NODE_ID ID		Examples:
flush		sg-blacklist add src 192.168.0.2/32 proto tcp dstport 80 duration 60
		sg-blacklist add -i myblacklist.txt
		sg-blacklist del dst 192.168.1.0/24 proto 47
	<u> </u>	

Command	Engine role	Description
sg-bootconfig	Firewall	Used to edit boot command parameters for future bootups.
[primary-	Layer 2 Firewall	primary-console defines the terminal settings for the primary console.
console=tty0 ttyS PORT,SPEED]	IPS	secondary-console defines the terminal settings for the secondary console.
[secondary- console=[tty0 ttyS		flavor defines whether the kernel is uniprocessor or multiprocessor.
PORT, SPEED]]		initrd defines whether Ramdisk is enabled or disabled.
[flavor=up smp]		crashdump defines whether kernel crashdump is enabled or disabled, and
[initrd=yes no]		how much memory is allocated to the crash dump kernel (Y). The default is 24M. X must always be 16M.
[crashdump=yes no Y@X]		append defines any other boot options to add to the configuration.
[append=kernel		help displays usage information.
options]		apply applies the specified configuration options.
[help]		
apply		
sg-clear-all [fast]	Firewall Layer 2 Firewall	This command restores the factory default settings on the engine. [fast] runs a minimal, non-interactive clear for testing purposes.
[flash-defaults]	IPS	[flash-defaults] assumes that the engine has a flash data partition and a RAM spool partition.
[on-boot]		[on-boot] indicates that engine is starting up. This option is not intended
[verbose]		to be used in normal command line usage.
		[verbose] Shows additional informational messages during command execution.
		Note: If you run the command without specifying any options, the engine restarts and you are prompted to select the system restore options.
		After using this command, you can reconfigure the engine using the sgreconfigure command.
sg-cluster	Firewall	Used to display or change the status of the node.
[-v <virtual engine="" id="">]</virtual>	Layer 2 Firewall	-v (Master NGFW Engine only) specifies the ID of the Virtual NGFW Engine on which to execute the command.
[status [-c SECONDS]]		status displays cluster status. When -c SECONDS is used, the status is shown continuously with the specified number of seconds between updates.
[versions]		version displays the engine software versions of the nodes in the cluster.
[lock-online]		online sends the node online.
[offline]		lock-online sends the node online and keeps it online, even if another
[lock-offline]		process tries to change its state.
[standby]		offline sends the node offline.
[safe-offline]		lock-offline sends the node offline and keeps it offline, even if another process tries to change its state.
[force-offline]		standby sets an active node to standby.
		safe-offline sets the node to offline only if there is another online node.
		force-offline sets the node online regardless of state or any limitations. Also sets all other nodes offline.

Command	Engine role	Description
sg-contact-mgmt	Firewall Layer 2 Firewall	Used for establishing a trust relationship with the Management Server as part of engine installation or reconfiguration (see sg-reconfigure).
	IPS	The engine contacts the Management Server using the one-time password created when the engine's initial configuration is saved.
sg-dynamic-routing	Firewall	start starts the Quagga routing suite.
[start]		stop stops the Quagga routing suite and flushes all routes made by zebra.
[stop]		restart restarts the Quagga routing suite.
[restart]		force-reload forces reload of the saved configuration.
[force-reload]		backup backs up the current configuration to a compressed file.
[backup <file>]</file>		restore restores the configuration from the specified file.
[restore <file>]</file>		sample-config creates a basic configuration for Quagga.
[sample-config]		route-table prints the current routing table.
[route-table]		info displays the help information for the sg-dynamic-routing command,
[info]		and detailed information about Quagga suite configuration with vtysh.
sg-ipsec -d	Firewall	Deletes VPN-related information (use the vpntool command to view the information). Option -d (for delete) is mandatory.
<pre>[-u <username[@domain]> -si <session id=""> </session></username[@domain]></pre>		-u deletes the VPN session of the named VPN client user. You can enter the user account in the form <user_name@domain> if there are several user storage locations (LDAP domains).</user_name@domain>
-ck <ike cookie=""> </ike>		-si deletes the VPN session of a VPN client user based on session identifier.
-tri <transform id=""> -ri <remote ip=""> </remote></transform>		-ck deletes the IKE SA (Phase one security association) based on IKE cookie.
-ci <connection id="">]</connection>		-tri deletes the IPSEC SAs (Phase two security associations) for both communication directions based on transform identifier.
		-ri deletes all SAs related to a remote IP address in site-to-site VPNs.
		-ci deletes all SAs related to a connection identifier in site-to-site VPNs.
sg-logger	Firewall	Used in scripts to create log messages with the specified properties.
-f FACILITY_NUMBER	Layer 2 Firewall	-f defines the facility for the log message.
-t TYPE_NUMBER	IPS	-t defines the type for the log message.
[-e EVENT_NUMBER]		-e defines the log event for the log message. The default is 0
[-i "INFO_STRING"]		(H2A_LOG_EVENT_UNDEFINED).
[-s]		-i defines the information string for the log message.
[-h]		-s dumps information about option numbers to stdout
		-h displays usage information.

Command	Engine role	Description
sg-raid	Firewall	Configures a new hard drive.
[-status] [-add] [-re-add]	Layer 2 Firewall	This command is only for Forcepoint NGFW appliances that support RAID (Redundant Array of Independent Disks) and have two hard drives.
[-force] [-help]		-status displays the status of the hard drive.
		-add adds a new empty hard drive. Use -add -force if you want to add a hard drive that already contains data and you want to overwrite it.
		-re-add adds a hard drive that is already partitioned. This command prompts for the drive and partition for each degraded array. Use -re-add -force if you want to check all arrays.
		-help displays usage information.
sg-reconfigure [maybe-contact]	Firewall Layer 2 Firewall	Starts the NGFW Initial Configuration Wizard. Used for reconfiguring the node manually.
[no-shutdown] [stop-autocontact]	IPS	CAUTION: This script also has parameters that are for the internal use of the engine only. Do not use this script with any parameters other than the ones listed here.
		maybe-contact contacts the Management Server if requested. This option is only available on firewall engines.
		no-shutdown allows you to make limited configuration changes on the node without shutting it down. Some changes might not be applied until the node is rebooted.
		stop-autocontact (unconfigured Forcepoint NGFW appliances with valid POS codes only) prevents the engine from contacting the installation server for plug-and-play configuration when it reboots.
sg-selftest [-d] [-h]	Firewall	Runs cryptography tests on the engine.
		-d runs the tests in debug mode.
		-h displays usage information.
sg-status [-1] [-h]	Firewall	Displays information about the engine's status.
	Layer 2 Firewall	-1 displays all available information about engine status.
	IPS	-h displays usage information.
sg-toggle-active	Firewall	Switches the engine between the active and the inactive partition.
SHA1 SIZE	Layer 2 Firewall	This change takes effect when you reboot the engine.
force [debug]	IPS	You can use this command, for example, if you have upgraded an engine and want to switch back to the earlier engine version. When you upgrade the engine, the active partition is switched. The earlier configuration remains on the inactive partition. To see the currently active (and inactive) partition, see the directory listing of /var/run/stonegate (1s -1 /var/run/stonegate).
		The SHA1 option is used to verify the signature of the inactive partition before changing it to active. If you downgrade the engine, check the checksum and the size of the earlier upgrade package by extracting the signature and size files from the sg_engine_[version.build]_i386.zip file.
		debug reboots the engine with the debug kernel.
		force switches the active configuration without first verifying the signature of the inactive partition.

Command	Engine role	Description
sg-upgrade	Firewall	Upgrades the node by rebooting from the installation DVD.
		Alternatively, the node can be upgraded remotely using the Management Client.
sg-version	Firewall	Displays the software version and build number for the node.
	Layer 2 Firewall	
	IPS	
se-virtual-engine	Firewall (Master	Used to send commands to Virtual Firewalls from the command line of the
-l list	NGFW Engine only)	Master NGFW Engine.
-v <virtual engine="" id=""></virtual>	,,	All commands that can be used for the Firewall role can also be used for Virtual Firewalls.
-e enter		-1 orlist list the active Virtual NGFW Engines.
-E " <command [options]=""/> "		-v specifies the ID of the Virtual NGFW Engine on which to execute the
		command.
-h help		-e orenter enters the command shell for the Virtual NGFW Engine specified with the -v option. To exit the command shell, type exit.
		$^{-\rm E}$ executes the specified command on the Virtual NGFW Engine specified with the $^{-\rm V}$ option.
		-h orhelp displays usage information.
sginfo	Firewall	Gathers system information you can send to Forcepoint support.
[-f]	Layer 2 Firewall	Use this command only when instructed to do so by Forcepoint support.
[-d]	IPS	-f forces sglnfo even if the configuration is encrypted.
[-s]		-d includes core dumps in the sglnfo file.
[-p]		-s includes slapcat output in the sglnfo file.
[]		-p includes passwords in the sglnfo file (by default passwords are erased from the output).
[help]		creates the sglnfo file without displaying the progress.
		help displays usage information.

The following table lists some general Linux operating system commands that can be useful in running your engines. Some commands can be stopped by pressing **Ctrl+C**.

Table 16: General command line tools on engines

Command	Description
dmesg	Shows system logs and other information.
	Use the -h option to see usage.
halt	Shuts down the system.
ip	Displays IP address information.
	Type the command without options to see usage.
	Example: type ip addr for basic information about all interfaces.
ping	Tests connectivity with ICMP echo requests.
	Type the command without options to see usage.

Command	Description
ps	Reports the status of running processes.
reboot	Reboots the system.
scp	Secure copy.
	Type the command without options to see usage.
sftp	Secure FTP.
	Type the command without options to see usage.
ssh	SSH client (for opening a terminal connection to other hosts).
	Type the command without options to see usage.
tcpdump	Gives information about network traffic.
	Use the -h option to see usage.
	You can also analyze network traffic by creating tcpdump files from the Management Client with the Traffic Capture feature.
top	Displays the top CPU processes taking most processor time.
	Use the -h option to see usage.
traceroute	Traces the route packets take to the specified destination.
	Type the command without options to see usage.
vpntool	Displays VPN information and allows you to issue some basic commands.
	Type the command without options to see usage.

Server Pool Monitoring Agent commands

You can test and monitor the Server Pool Monitoring Agents on the command line.

Table 17: Server Pool Monitoring Agent commands

Command	Description	
agent	(Windows only) Allows you to test different configurations before activating them.	
[-v level]	-v sets the verbosity level. The default level is 5. Levels 6–8 are for debugging where available.	
[-c path]	-c uses the specified path as the first search directory for the configuration.	
[test [files]]	test runs in the test mode - status queries do not receive a response. If you specify the files,	
[syntax [files]]	they are used for reading the configuration instead of the default files.	
	syntax checks the syntax in the configuration file. If no files are specified, the default configuration files are checked.	

Command	Description	
sgagentd [-d]	(Linux only) Allows you to test different configurations before activating them.	
[-v level]	-d means Don't Fork as a daemon. All log messages are printed to stdout or stderr only.	
[-c path]	-v sets the verbosity level. The default level is 5. Levels 6–8 are for debugging where available.	
[test [files]]	-c uses the specified path as the first search directory for the configuration.	
[syntax [files]]	test runs in the test mode - status queries do not receive a response. If you specify the files, they are used for reading the configuration instead of the default files. The output is directed to syslog or eventlog instead of the console where the command was run unless you use the -d option.	
	syntax checks the syntax in the configuration file. If no files are specified, the default configuration files are checked. The output is directed to syslog or eventlog instead of the console where the command was run unless you use the -d option.	
sgmon	Sends a UDP query to the specified host and waits for a response until received, or until the	
[status info proto]	timeout limit is reached. The request type can be defined as a parameter. If no parameter is given, status is requested. The commands are:	
[-p port]	status queries the status.	
[-t timeout]	info queries the agent version.	
[-a id]	proto queries the highest supported protocol version.	
host	-p connects to the specified port instead of the default port.	
	-t sets the timeout (in seconds) to wait for a response.	
	-a acknowledge the received log messages up to the specified id. Each response message has an id, and you can acknowledge more than one message at a given time by using the id parameter. Messages acknowledged by sgmon will no longer appear in the firewall logs.	
	host is the IP address of the host to connect to. To get the status locally, you can give localhost as the host argument. This parameter is mandatory.	



Appendix C

Installing SMC Appliance software on a virtualization platform

Contents

- Hardware requirements for installing SMC Appliance software on a virtualization platform on page 225
- Install SMC Appliance software using an .iso file on page 225

You can install the SMC Appliance software as a virtual machine on virtualization platforms such as VMware ESX.

Hardware requirements for installing SMC Appliance software on a virtualization platform

There are some hardware and software requirements when you run SMC Appliance software on a virtualization platform.

The following requirements apply when you run SMC Appliance software on a virtualization platform:

- VMware ESXi version 5.5 as hypervisor
- 120 GB virtual disk minimum
- 8 GB RAM minimum

Install SMC Appliance software using an .iso file

Use an .iso file of the SMC Appliance software to install the SMC Appliance on the VMware ESX virtualization platform.

Steps

- Create the virtual machine and configure it according to your requirements.
- Download the license at https://stonesoftlicenses.forcepoint.com.
- Download the .iso installation file at https://support.forcepoint.com.

- 4) Connect the DVD drive of the virtual machine to the .iso file.
- 5) Restart the virtual machine.
- When the NGFW SMC Appliance installer starts, type I.
- To start the SMC Appliance installation, type Erase and press Enter.
- 8) When the SMC Appliance software installation is complete, type Y to restart the virtual machine.

Next steps

Continue the SMC Appliance installation by configuring the operating system settings on the command line of the SMC Appliance.

Related tasks

Install the SMC Appliance on page 47

Appendix D

Installing Forcepoint NGFW on a virtualization platform

Contents

- Hardware requirements for installing Forcepoint NGFW software on a virtualization platform on page 227
- Install Forcepoint NGFW software using an .iso file on page 228

You can install the Forcepoint NGFW software as a virtual machine on virtualization platforms such as VMware ESX or KVM.

The same Forcepoint NGFW software can be used in the Firewall/VPN role, IPS role, or Layer 2 Firewall role. The engine role is selected during the initial configuration of the engine.

Hardware requirements for installing Forcepoint NGFW software on a virtualization platform

There are some hardware and software requirements, and configuration limitations when you run Forcepoint NGFW software on a virtualization platform.

The following requirements apply when you run Forcepoint NGFW software on a virtualization platform:

 (Recommended for new deployments) Intel® Xeon®-based hardware from the E5-16xx product family or higher



Note: Legacy deployments with Intel® Core™2 are supported.

- · One of the following hypervisors:
 - VMware ESXi versions 5.5 and 6.0
 - KVM (KVM is tested as shipped with Red Hat Enterprise Linux Server versions 7.1 and 7.2)
- 8 GB virtual disk
- 4 GB RAM minimum
- · A minimum of one virtual network interface for the Firewall/VPN role, three for IPS or Layer 2 Firewall roles
- The following network interface card drivers are recommended:
 - VMware ESXi platform vmxnet3.
 - KVM platform virtio_net.

When an NGFW Engine in the Firewall/VPN role is run on a virtualization platform, these limitations apply:

- Only Packet Dispatching CVI mode is supported.
- Only Standby clustering mode is supported.

Heartbeat requires a dedicated non-VLAN-tagged interface.

When an NGFW Engine in the IPS or Layer 2 Firewall role is run on a virtualization platform, clustering is not supported.

Install Forcepoint NGFW software using an .iso file

Use an .iso file of the Forcepoint NGFW software to install Forcepoint NGFW on VMware ESX or KVM virtualization platforms.

Steps

- Create the virtual machine and configure it according to your requirements. 1)
- (IPS and Layer 2 Firewall only) Configure the virtual switches to which the IPS or Layer 2 Firewall inline 2) interfaces are connected:
 - a) Create a port group and assign All (4095) as the VLAN ID.
 - b) Enable the use of Promiscuous Mode.
- Download the license at https://stonesoftlicenses.forcepoint.com. 3)
- 4) Download the .iso installation file at https://support.forcepoint.com.
- 5) Connect the DVD drive of the virtual machine to the .iso file.
- Restart the virtual machine. 6)

The License Agreement appears.

- 7) Type YES and press **Enter** to accept the license agreement and continue with the configuration.
- 8) Select the type of installation:
 - Type 1 for the normal Full Install.
 - Type 2 for the Full Install in expert mode if you want to partition the hard disk manually.
- 9) Enter the number of processors:
 - For a uniprocessor system, type 1 and press Enter.
 - For a multiprocessor system, type 2 and press **Enter**.
- Continue in one of the following ways: 10)
 - If you selected Full Install, type YES and press Enter to accept automatic hard disk partitioning.
 - If you selected Full Install in expert mode, install the engine in expert mode.

Result

The installation process starts.

Appendix E

Installing Forcepoint NGFW software on third-party hardware

Contents

- Hardware requirements for installing Forcepoint NGFW on third-party hardware on page 229
- Start the Forcepoint NGFW installation on third-party hardware on page 234
- Install Forcepoint NGFW in expert mode on page 235

You can install the Forcepoint NGFW software on third-party hardware that meets the hardware requirements.

Hardware requirements for installing Forcepoint NGFW on third-party hardware

There are some basic hardware requirements when you run Forcepoint NGFW on third-party hardware.



CAUTION: Check that the Automatic Power Management (APM) and Advanced Configuration and Power Interface (ACPI) settings are disabled in BIOS. Otherwise, the engine might not start after installation or can shut down unexpectedly.



CAUTION: The hardware must be dedicated to the Forcepoint NGFW. No other software can be installed on it.

The following basic hardware requirements apply:

(Recommended for new deployments) Intel® Xeon®-based hardware from the E5-16xx product family or higher



Note: Legacy deployments with Intel[®] Core[™]2 are supported.

IDE hard disk and CD drive



Note: IDE RAID controllers are not supported.

- Memory:
 - 4 GB RAM minimum for x86-64-small installation
 - 8 GB RAM minimum for x86-64 installation
- VGA-compatible monitor and keyboard
- One or more certified network interfaces for the Firewall/VPN role

- · Two or more certified network interfaces for IPS with IDS configuration
- · Three or more certified network interfaces for Inline IPS or Layer 2 Firewall

Network interface cards

Forcepoint NGFW supports Ethernet, Fast Ethernet, Gigabit, and 10-Gigabit Ethernet interfaces on the Intel platform.

We strongly recommend using network interface cards (NIC) that Forcepoint has certified. For information about certified network interface cards, see Knowledge Base article 9721.

Hardware drivers

We recommend using the listed approved drivers supported by Forcepoint NGFW.

Tested network interface card drivers included in the kernel of Forcepoint NGFW are listed in the following table. These drivers have been tested for use in Forcepoint NGFW.

Table 18: Tested network interface card drivers

Driver	Version	Description
e1000e.ko	2.3.2-k	Intel® PRO/1000 Network Driver
e1000x.ko	7.3.21-k8-NAPI	Intel® PRO/1000 Network Driver
i40e.ko	1.2.37+sg2	Intel® Ethernet Connection XL710 Network Driver
igb.ko	5.1.2+sg7+s1	Intel® Gigabit Ethernet Network Driver
ixgbe.ko	3.14.5+sg10	Intel® 10 Gigabit PCI Express Network Driver
virtio_net.ko	No version	Virtio network driver
vmxnet3.ko	1.2.0.0-k	VMware vmxnet3 virtual NIC driver
xen-netfront.ko	No version	Xen virtual network device frontend

Other network interface card drivers included in the kernel of Forcepoint NGFW are listed in the following table. All drivers are the driver version that is included in the standard Linux 3.16.7 kernel.



Note: These drivers have not been tested for use in Forcepoint NGFW.

Table 19: Other network interface card drivers

Driver	Description
3c59x.ko	3Com 3c59x/3c9xx Ethernet driver
8139cp.ko	RealTek RTL-8139C+ series 10/100 PCI Ethernet Driver
8139too.ko	RealTek RTL-8139 Fast Ethernet Driver
8390.ko	No description
acenic.ko	AceNIC/3C985/GA620 Gigabit Ethernet Driver

Driver	Description
amd8111e.ko	AMD8111 based 10/100 Ethernet Controller. Driver Version 3.0.7
atl1.ko	Atheros L1 Gigabit Ethernet Driver
atl1e.ko	Atheros 1000M Ethernet Network Driver
b44.ko	Broadcom 44xx/47xx 10/100 PCI Ethernet Driver
be2net.ko	Emulex OneConnect NIC Driver 10.2u
bnx2.ko	Broadcom NetXtreme II BCM5706/5708/5709/5716 Driver
bnx2x.ko	Broadcom NetXtreme II BCM57710/57711/57711E/57712/ 57712_MF/57800/57800_MF/57810/ 57810_MF/57840/57840_MF Driver
tg3.ko	Broadcom Tigon3 Ethernet Driver
cxgb.ko	Chelsio 10 Gb Ethernet Driver
cxgb3.ko	Chelsio T3 Network Driver
cxgb4.ko	Chelsio T4/T5 Network Driver
dl2k.ko	D-Link DL2000-based Gigabit Ethernet Adapter
dmfe.ko	Davicom DM910X fast Ethernet Driver
e100.ko	Intel® PRO/100 Network Driver
epic100.ko	SMC 83c170 EPIC series Ethernet Driver
fealnx.ko	Myson MTD-8xx 100/10M Ethernet PCI Adapter Driver
forcedeth.ko	Reverse Engineered nForce Ethernet Driver
hamachi.ko	Packet Engines 'Hamachi' GNIC-II Gigabit Ethernet Driver
hp100.ko	HP CASCADE Architecture Driver for 100VG-AnyLan Network Adapters
i40e_ik.ko	Intel® Ethernet Connection XL710 Network Driver
igb_ik.ko	Intel® Gigabit Ethernet Network Driver
ipg.ko	IC Plus IP1000 Gigabit Ethernet Adapter Linux Driver
ixgb.ko	Intel® PRO/10GbE Network Driver
ixgbe_ik.ko	Intel® 10 gigabit PCI Express Network Driver
mdio.ko	Generic support for MDIO-compatible transceivers
mii.ko	MII hardware support library
mlx4_core.ko	Mellanox ConnectX HCA low-level driver
mlx4_en.ko	Mellanox ConnectX HCA Ethernet Driver
myri10ge.ko	Myricom 10G driver (10GbE)
natsemi.ko	National Semiconductor DP8381x series PCI Ethernet Driver
ne2k-pci.ko	PCI NE2000 clone driver
netxen_nic.ko	QLogic/NetXen (1/10) GbE Intelligent Ethernet Driver

Driver	Description
niu.ko	NIU Ethernet Driver
ns83820.ko	National Semiconductor DP83820 10/100/1000 driver
pcnet32.ko	Driver for PCnet32 and PCnetPCI based ether cards
qla3xxx.ko	QLogic ISP3XXX Network Driver v2.03.00-k5
r6040.ko	RDC R6040 NAPI PCI Fast Ethernet Driver
r8169.ko	RealTek RTL-8169 Gigabit Ethernet Driver
s2io.ko	No description
sc92031.ko	Silan SC92031 PCI Fast Ethernet Adapter Driver
sis190.ko	SiS sis190/191 Gigabit Ethernet Driver
sis900.ko	SiS 900 PCI Fast Ethernet Driver
skge.ko	SysKonnect Gigabit Ethernet Driver
sky2.ko	Marvell Yukon 2-Gigabit Ethernet Driver
starfire.ko	Adaptec Starfire Ethernet Driver
sundance.ko	Sundance Alta Ethernet driver
sungem.ko	Sun GEM Gbit Ethernet Driver
sunhme.ko	Sun HappyMealEthernet(HME) 10/100baseT Ethernet Driver
tehuti.ko	Tehuti Networks® Network Driver
tg3.ko	Broadcom Tigon3 ethernet driver
tulip.ko	Digital 21*4* Tulip Ethernet Driver
typhoon.ko	3Com Typhoon Family (3C990, 3CR990, and variants)
uli526x.ko	ULi M5261/M5263 fast Ethernet Driver
via-rhine.ko	VIA Rhine PCI Fast Ethernet driver
via-velocity.ko	VIA Networking Velocity Family Gigabit Ethernet Adapter Driver
winbond-840.ko	Winbond W89c840 Ethernet driver
yellowfin.ko	Packet Engines Yellowfin G-NIC Gigabit Ethernet Driver

SCSI drivers included in the kernel of Forcepoint NGFW are listed in the following table. All drivers are the driver version that is included in the standard Linux 3.16.7 kernel.



Note: Not all included drivers have been tested for use in Forcepoint NGFW.

Table 20: SCSI drivers

Driver	Description	
3Ware 9xxx SATA_RAID	[CONFIG_SCSI_3W_9XXX]	
Adaptec / IBM ServeRAID	[CONFIG_SCSI_IPS]	

Driver	Description
Adaptec AACRAID	[CONFIG_SCSI_AACRAID]
Adaptec I2O RAID	[CONFIG_SCSI_DPT_I2O]
Adaptec SAS/SATA 3Gb/s	[CONFIG_SCSI_AIC94X]
Adaptec Ultra160	[CONFIG_SCSI_AIC7XXX]
BusLogic MultiMaster and FlashPoint SCSI	[CONFIG_SCSI_BUSLOGIC]
Domex DMX3191D SCSI	[CONFIG_SCSI_DMX3191D]
Fusion MPT ScsiHost for FC/SPI/SAS	[CONFIG_FUSION_FC/SPI/SAS]
Initio INIA100 SCSI	[CONFIG_SCSI_INIA100]
Intel PIIX/ICH PATA/SATA	[CONFIG_ATA_PIIX]
LSI Logic MegaRAID (Legacy)	[CONFIG_MEGARAID_LEGACY]
LSI Logic MegaRAID (NEWGEN)	[CONFIG_MEGARAID_NEWGEN]
LSI Logic MegaRAID (SAS)	[CONFIG_MEGARAID_SAS]
NVIDIA nForce SATA	[CONFIG_SATA_NV]
Pacific Digital ADMA	[CONFIG_PDC_ADMA]
Promise SATA	[CONFIG_SATA_SX4]
Promise SATA TX2/TX4	[CONFIG_SATA_PROMISE]
QLogic IPS2x00	[CONFIG_SCSI_QLA2XXX]
QLogic ISP1240/1x80/1x160/1020/1040 SCSI	[CONFIG_SCSI_QLOGIC_1280]
ServerWorks / Apple K2 SATA	[CONFIG_SATA_SVW]
Silicon Image 3124/3132 SATA	[CONFIG_SATA_SIL24]
Silicon Image SATA	[CONFIG_SATA_SIL]
Silicon Integrated Systems SATA	[CONFIG_SATA_SIS]
Symbios/LSI logic 53C8XX/53C101	[CONFIG_SCSI_SYM53C8XX_2]
Tekram DC390(T) PCI SCSI	[CONFIG_SCSI_DC390T]
ULi Electronics SATA	[CONFIG_SATA_ULI]
VIA SATA	[CONFIG_SATA_VIA]
Vitesse VSC7174 SATA	[CONFIG_SATA_VITESSE]
Vortex GDT Disk Array / Intel Storage RAID	[CONFIG_SCSI_GDTH]

Block device drivers included in the kernel of Forcepoint NGFW are listed in the following table. All drivers are the driver version that is included in the standard Linux 3.16.7 kernel.



Note: Not all included drivers have been tested for use in Forcepoint NGFW.

Table 21: Block device drivers

-				
m٦	-	м		T
₩,		M,	/e	-11

3ware Storage controller

AMD / NS 5535 IDE

CMD-Technologies CMD640 IDE

CMD-Technologies CMD64x IDE

Compag Smart Array 5xxx

Compaq SMART2 Array

Cyrix / NS 5530 IDE

Highpoint 366 IDE

Intel PIIX IDE

ITE 8211 IDE/8212 IDE RAID

Mylec DAC960 / AcceleRAID / eXtremeRAID PCI RAID

RZ1000 IDE

Serverworks OSB4 / CSB5 / CSB6

Silicon Image SiL IDE

Start the Forcepoint NGFW installation on third-party hardware

After configuring the engine elements in the SMC, begin installing the Forcepoint NGFW software on your own hardware.

Before you begin

Before you start installing the Forcepoint NGFW software, make sure that you have the initial configuration and a one-time password for management contact for each engine. These items are generated in the SMC.



CAUTION: Installing the Forcepoint NGFW software deletes all existing data on the hard disk.

Depending on your order, you might have received ready-made SMC and Forcepoint NGFW software DVDs. If the DVDs are not included in the order, you must first create them.

Steps

1) Insert the engine installation DVD into the drive and restart the system. The License Agreement appears.

- Type YES and press Enter to accept the license agreement and continue with the configuration.
- 3) Select the type of installation:
 - Type 1 for the normal Full Install.
 - Type 2 for the Full Install in expert mode if you want to partition the hard disk manually.
- Enter the number of processors:
 - For a uniprocessor system, type 1 and press Enter.
 - For a multiprocessor system, type 2 and press Enter.
- 5) Continue in one of the following ways:
 - If you selected Full Install, type YES and press Enter to accept automatic hard disk partitioning.
 - If you selected Full Install in expert mode, install the engine in expert mode.

Result

The installation process starts.

Install Forcepoint NGFW in expert mode

You can install Forcepoint NGFW in expert mode if you want to partition the hard disk manually. If you are unfamiliar with partitioning hard disks in Linux, use the normal installation process.



CAUTION: When using the command prompt, use the reboot command to reboot and halt command to shut down the node. Do not use the init command. You can also reboot the node using the Management Client.

Partition the hard disk in expert mode

Typically, you need five partitions for an engine.



CAUTION: Partitioning deletes all existing data on the hard disk.

Steps

- 1) If you are asked whether you want to create an empty partition table, type y to continue.
- When prompted, press **Enter** to continue.

3) Create the partitions for the engine as follows:

Partition	Flags	Partition type	File system type	Size	Description
Engine root A	bootable	Primary	Linux	1000 MB	The bootable root partition for the engine element.
Engine root B		Primary	Linux	1000 MB	Alternative root partition for the engine element. Used for the engine upgrade.
Swap		Logical	Linux swap	Twice the size of physical memory.	Swap partition for the engine element.
Data		Logical	Linux	500 MB or more	Used for the boot configuration files and the root user's home directory.
Spool		Logical	Linux	All remaining free disk space.	Used for spooling.

- Check that the partition table information is correct.
- Select Write to commit the changes and confirm by typing yes.
- Select Quit and press Enter.

Allocate partitions in expert mode

After partitioning the hard disk, assign the partitions for the engine.

Steps

- 1) Check that the partition table is correct. Type yes to continue.
- Using the partition numbers of the partition table, assign the partitions. For example:
 - For the engine root A partition, type 1.
 - For the engine root B partition, type 2.
 - For the swap partition, type 5.
 - For the data partition, type 6.
 - For the spool partition, type 7.
- Check the partition allocation and type yes to continue.
 - The engine installation starts.
- When installation is complete, remove the DVD from the system and press **Enter** to reboot.

Related tasks

Configure Forcepoint NGFW software using automatic configuration on page 148
Configure Forcepoint NGFW software using the NGFW Initial Configuration Wizard on page 149

Forcepoint Next Generation Firewall 6.2 Installation Guide		

Appendix F

Example network (Firewall/VPN)

Contents

- Example Firewall Cluster on page 239
- Example Single Firewall on page 242
- Example headquarters management network on page 243


This example gives you a better understanding of how Forcepoint NGFW in the Firewall/VPN role fits into a network.

The example outlines a network with two firewalls: a Single Firewall at a branch office and a Firewall Cluster at headquarters.

Example Firewall Cluster

This example shows Firewall Cluster interfaces in the example network.

In the example network, the HQ Firewall Cluster is located in the Headquarters network. The cluster consists of two cluster nodes: Node 1 and Node 2.



Network	Description
Heartbeat network	The heartbeat and cluster synchronization goes through the heartbeat network. CVI: no CVI defined. NDI: 10.42.1.1 (Node 1) and 10.42.1.2 (Node 2).
Management network (DMZ)	The management network interface is used for the control connections from the Management Server and for connecting to the HQ Log Server. CVI: 192.168.10.1. NDI: 192.168.10.21 (Node 1) and 192.168.10.22 (Node 2).


Network	Description
ISP A external network	This connection is one of the 2 Internet connections from the Headquarters site. It is provided by ISP A. CVI: 212.20.1.254. NDI: 212.20.1.21 (Node 1) and 212.20.1.22 (Node 2).
	Next hop router: 212.20.1.1.
ISP B external network	This connection is the other of the 2 Internet connections from the Headquarters site. It is provided by ISP B. CVI: 129.40.1.254.
	NDI: 129.40.1.21 (Node 1) and 129.40.1.22 (Node 2).
	Next hop router: 129.40.1.1.
HQ intranet	This VLAN (VLAN ID 16) is connected to the same network interface on the firewall with the HQ Accounting VLAN. CVI: 172.16.1.1.
	NDI: 172.16.1.21 (Node 1) and 172.16.1.22 (Node 2).
HQ Accounting network	This VLAN (VLAN ID 17) is connected to the same network interface on the firewall with the HQ intranet VLAN. CVI: 172.17.1.1.
	NDI: 172.17.1.21 (Node 1) and 172.17.1.22 (Node 2).

The Management Server and the HQ Log Server are at the headquarters site, in the DMZ network.

Security Management Center (SMC) component	Description
Management Server	This Management Server manages all firewalls and Log Servers of the example network.
	The Management Server in the Headquarters' Management Network (DMZ) with the IP address 192.168.1.101.
HQ Log Server	This Log Server receives log data from the firewalls.
	The server is located in the Headquarters' Management Network (DMZ) with the IP address 192.168.1.102.

Example Single Firewall


The Branch Office firewall is a Single Firewall located in the Branch Office network.



Example headquarters management network

This example shows a sample management network.





- 1 Internet
- 2 HQ firewall
- 3 192.168.10.1
- 4 212.20.1.254
- 5 Switch
- 6 Management Server 192.168.10.200
- 7 HQ Log Server 192.168.10.201

HQ firewall

The HQ firewall provides NAT for the headquarters management network.

The HQ Firewall uses the following IP addresses with the headquarters management network:

Internal: 192.168.10.1

External: 212.20.1.254

SMC Servers

The example network includes a Management Server and a Log Server.

The following SMC Servers are included in the example network.

SMC Server	Description	
Management Server	The Management Server is located in the headquarters' management network with the IP address 192.168.10.200. This Management Server manages all IPS engines, Firewalls, and Log Servers of the example network.	
HQ Log Server	This server is located in the headquarters' management network with the IP address 192.168.10.201. This Log Server receives alerts, log data, and event data from the DMZ IPS and from the HQ IPS Cluster	

Appendix G

Example network (IPS)

Contents

- Example network overview (IPS) on page 245
- Example headquarters intranet network on page 247
- HQ IPS Cluster on page 247
- Example headquarters DMZ network on page 248

To give you a better understanding of how Forcepoint NGFW in the IPS role fits into a network, this example outlines a network with IPS engines.


Example network overview (IPS)

This example network environment is used in all IPS examples.

There are two example IPS installations:

- An IPS Cluster in the Headquarters intranet network.
- A Single IPS in the Headquarters DMZ network.


Figure 16: Example network



- 1 HQ firewall
- 2 Branch office firewall
- 3 HQ DMZ 192.168.1.0/24
- 4 Internet
- **5** HQ intranet 172.16.1.0/24
- 6 HQ Management 192.168.10.0/24
- 7 Branch Office intranet 172.16.1.0/24

Example headquarters intranet network

This example shows a sample headquarters intranet network.



HQ IPS Cluster


In this example, the HQ IPS Cluster is an inline serial cluster located in the Headquarters network.

The cluster consists of two IPS engine nodes: Node 1 and Node 2.

Network interface	Description	
Capture Interfaces	The HQ IPS Cluster's capture interface on each node is connected to a SPAN port in the headquarters intranet switch. All traffic in this network segment is forwarded to the SPAN ports for inspection.	
Inline Interfaces	The cluster is deployed in the path of traffic between the firewall and the headquarters intranet switch. All traffic flows through each node's Inline Interface pair.	
Normal Interfaces	The normal interface on each node is connected to the headquarters intranet switch. Node 1's IP address is 172.16.1.41 and Node 2's address is 172.16.1.42. This normal interface is used for control connections from the Management Server, sending events to the HQ Log Server, and for sending TCP resets	
Heartbeat Interfaces	The nodes have dedicated Heartbeat Interfaces. Node 1 uses the IP address 10.42.1.41 and Node 2 uses the IP address 10.42.1.42.	

Example headquarters DMZ network

This example shows a sample DMZ network.



DMZ IPS

In this example, the DMZ IPS in the headquarters DMZ network is a single inline IPS engine.

Network interface	Description
Inline Interfaces	The DMZ IPS is deployed in the path of traffic between the firewall and the DMZ network switch. All traffic flows through the IPS engine's inline interface pair.
Normal Interfaces	The normal interface is connected to the DMZ network using the IP address 192.168.1.41. This normal interface is used for control connections from the Management Server, sending event information to the HQ Log Server, and for TCP connection termination.

Appendix H

Cluster installation worksheet instructions

Contents

Cluster installation worksheet on page 249

For planning the configuration of network interfaces for the engine nodes, use the worksheet.

- Interface ID Write the Interface ID (and the VLAN ID, if VLAN tagging is used).
- CVI Write the Interface ID's CVI information (if any) and on the NDI line, write the interfaces NDI information (if any). Use multiple lines for an Interface ID if it has multiple CVIs/NDIs defined.
- **Mode** Select all modes that apply for this Interface ID.
- IP Address and Netmask Define the CVI or NDI network address.
- MAC/IGMP IP Address Define the MAC address used. If the interface's CVI Mode is Multicast with IGMP, define the multicast IP address used for generating automatically the multicast MAC address.
- Comments Define, for example, a name of the connected network. Show how the NDI addresses differ between the nodes. Define a management interface's contact address if different from the interface's IP address.

Interface modes are explained in the following table. These same character codes are displayed in the firewall element interface properties of the Management Client.

Cluster installation worksheet

The following modes apply in the worksheet.

- CVI mode —: U=Unicast MAC, M=Multicast MAC, I=Multicast with IGMP, K=Packet Dispatch, A=Interface's IP address used as the identity for authentication requests
- NDI modes H=Primary heartbeat, h=Backup heartbeat, C=Primary control IP address, c=Backup control IP address, D=Default IP address for outgoing connection

Interface ID	Туре	Mode	IP Address	Netmask	MAC / IGMP IP Address
	CVI	UMIKA			MAC: : : : : :
					or
					IGMP IP:
	NDI	H h C c D	··	··	MAC::::::
	Comments				
	CVI	UMIKA			MAC: : : : : :
					or
					IGMP IP:

Interface ID	Туре	Mode	IP Address	Netmask	MAC / IGMP IP Address
	NDI	H h C c D			MAC::::::
	Comments			~	
	CVI	UMIKA			MAC::::::
					or
					IGMP IP:
	NDI	H h C c D	··		MAC::::::
	Comm	nents		=	
		UMIKA			MAC::::::
	CVI		··		or
					IGMP IP:
	NDI	H h C c D	··		MAC::: ::::
	Comments				
	CVI	UMIKA			MAC::::::
			··	··	or
					IGMP IP:
	NDI	HhCcD	_·_·_		MAC::::::
	Comments				
	CVI	UMIKA			MAC::::::
					or
					IGMP IP:
	NDI	HhCcD	··	··	MAC::::::
	Comments				
		UMIKA			MAC::::::
	CVI		··	··	Or
					IGMP IP:
	NDI	HhCcD		··	MAC::::::
	Comments				