FORCEPOINT

Next Generation Firewall

Release Notes

6.4.1.20056.fips.8 Revision A

Contents

- About this release on page 2
- Lifecycle model on page 2
- System requirements on page 2
- Build version on page 6
- Compatibility on page 6
- New features on page 7
- Enhancements on page 8
- Resolved issues on page 10
- Installation instructions on page 11
- Known issues on page 12
- Find product documentation on page 12

About this release

This document contains important information about this release of Forcepoint Next Generation Firewall (Forcepoint NGFW).

We strongly recommend that you read the entire document.

Forcepoint NGFW build version 6.4.1.20056.fips.8 has been tested and validated to the FIPS 140-2 standard under the Cryptographic Module Validation Program (CMVP). See https://csrc.nist.gov/projects/cryptographic-module-validation-program/Certificate/3317 for more information.

Lifecycle model

This release of Forcepoint NGFW is a Feature Stream (FS) version.

Support for Feature Stream versions is discontinued when a new major version of Forcepoint NGFW is available.

We recommend using the most recent Long-Term Support (LTS) version if you do not need any features from a Feature Stream version.

For more information about the Forcepoint NGFW lifecycle policy, see Knowledge Base article 10192.

System requirements

To use this product, your system must meet these basic hardware and software requirements. For information about FIPS-compatible hardware and configuration, see the Forcepoint NGFW FIPS 140-2 Security Policy

document https://csrc.nist.gov/CSRC/media/projects/cryptographic-module-validation-program/documents/ security-policies/140sp3317.pdf.

Forcepoint NGFW appliances

We strongly recommend using a pre-installed Forcepoint NGFW appliance as the hardware solution for new Forcepoint NGFW installations.



Note: Some features in this release are not available for all appliance models. See Knowledge Base article 9743 for up-to-date appliance-specific software compatibility information.

The following table shows whether you can use an appliance model in the Firewall/VPN (FW), IPS, or Layer 2 Firewall (L2FW) role.

Appliance model	Roles
320X (MIL-320)	FW
FWL321	FW
NGF321	FW, IPS, L2FW
FWL325	FW
NGF325	FW, IPS, L2FW
110	FW
115	FW
1035	FW, IPS, L2FW
1065	FW, IPS, L2FW
1101	FW, IPS, L2FW
1105	FW, IPS, L2FW
1401	FW, IPS, L2FW
1402	FW, IPS, L2FW
2101	FW, IPS, L2FW
2105	FW, IPS, L2FW
3202	FW, IPS, L2FW
3206	FW, IPS, L2FW
3207	FW, IPS, L2FW
3301	FW, IPS, L2FW
3305	FW, IPS, L2FW
5206	FW, IPS, L2FW
6205	FW, IPS, L2FW

Sidewinder S-series appliances

These Sidewinder appliance models can be re-imaged to run Forcepoint NGFW software.

Appliance model	Roles
S-1104	FW
S-2008	FW
S-3008	FW
S-4016	FW
S-5032	FW
S-6032	FW

Basic hardware requirements

You can install Forcepoint NGFW on standard hardware with these basic requirements.

 (Recommended for new deployments) Intel[®] Xeon[®]-based hardware from the E5-16xx product family or higher



Note: Legacy deployments with Intel[®] Core[™]2 are supported.

IDE hard disk and DVD drive



Note: IDE RAID controllers are not supported.

- 4 GB RAM minimum
- VGA-compatible display and keyboard
- · One or more certified network interfaces for the Firewall/VPN role
- Two or more certified network interfaces for IPS with IDS configuration
- · Three or more certified network interfaces for Inline IPS or Layer 2 Firewall

For information about certified network interfaces, see Knowledge Base article 9721.

Master NGFW Engine requirements

Master NGFW Engines have specific hardware requirements.

- Each Master NGFW Engine must run on a separate physical device. For more details, see the *Forcepoint Next Generation Firewall Installation Guide*.
- All Virtual NGFW Engines hosted by a Master NGFW Engine or Master NGFW Engine cluster must have the same role and the same Failure Mode (*fail-open* or *fail-close*).
- Master NGFW Engines can allocate VLANs or interfaces to Virtual NGFW Engines. If the Failure Mode of the Virtual IPS engines or Virtual Layer 2 Firewalls is *Normal* (fail-close) and you want to allocate VLANs to several engines, you must use the Master NGFW Engine cluster in standby mode.
- Cabling requirements for Master NGFW Engine clusters that host Virtual IPS engines or Layer 2 Firewalls:
 - Failure Mode Bypass (fail-open) requires IPS serial cluster cabling.

• Failure Mode Normal (fail-close) requires Layer 2 Firewall cluster cabling.

For more information about cabling, see the Forcepoint Next Generation Firewall Installation Guide.

Virtual appliance node requirements

You can install Forcepoint NGFW on virtual appliances with these hardware requirements. Also be aware of some limitations.

 (Recommended for new deployments) Intel[®] Xeon[®]-based hardware from the E5-16xx product family or higher



Note: Legacy deployments with Intel[®] Core[™]2 are supported.

- One of the following hypervisors:
 - VMware ESXi 6.0 and 6.5
 - KVM (KVM is tested as shipped with Red Hat Enterprise Linux Server 7.1 and 7.2)
 - Microsoft Hyper-V on Windows Server 2012 or Windows Server 2016 (Firewall/VPN role only) An Intel 64-bit processor is required.
- 8 GB virtual disk
- 4 GB RAM minimum
- A minimum of one virtual network interface for the Firewall/VPN role, three for IPS or Layer 2 Firewall roles

When Forcepoint NGFW is run as a virtual appliance node in the Firewall/VPN role, these limitations apply:

- Only Packet Dispatching CVI mode is supported.
- Only standby clustering mode is supported.
- Heartbeat requires a dedicated non-VLAN-tagged interface.

When Forcepoint NGFW is run as a virtual appliance node in the IPS or Layer 2 Firewall role, clustering is not supported.

Supported cloud environments

You can deploy Forcepoint NGFW in the Amazon Web Services (AWS) and Microsoft Azure cloud environments.

Amazon Web Services

Forcepoint NGFW instances can be launched from AWS using 1-Click Launch, and existing instances can be remotely upgraded to the latest Forcepoint NGFW version.

To see the currently available instance types, search for Forcepoint NGFW in the AWS Marketplace.

For more information about deploying in AWS, see the document *How to deploy Next Generation Firewall in the Amazon Web Services cloud* and Knowledge Base article 10156.

Microsoft Azure

Forcepoint NGFW instances can be launched from Azure using custom solution templates, and existing instances can be remotely upgraded to the latest Forcepoint NGFW version.

To see the currently available custom solution templates, search for *Forcepoint NGFW* in the Azure Marketplace.

For more information about deploying in Azure, see the document *How to deploy Next Generation Firewall in the Azure cloud* and Knowledge Base article 14485.

Build version

Forcepoint NGFW 6.4.1 build version is 20056.fips.8.

Product binary checksums

Use the checksums to make sure that the installation files downloaded correctly.

sg_engine_6.4.1.20056.fips.8_x86-64-small.iso

```
SHA1SUM:
927b36647eb16ffb97b6510fa170e4b6227ac98b
SHA256SUM:
7f992588f780a6091ac669b562560c2971d7c43aacb65870849118ef0597d316
SHA512SUM:
564d2e7aa0fb77de3df61236ab294299
af1462a8eca88a34193222aaf90f3508
37c47bc9a63dd74999b23ba7332e67a8
3635f04168b93a00309c31576e83811c
```

sg_engine_6.4.1.20056.fips.8_x86-64-small.zip

```
SHA1SUM:
54d800f9a39a7cf84d6bledc1a52762a067b780a
SHA256SUM:
17302791a8877c2ee6a7aac286eb18c6a5a77ad0d6c59934406600f161775e9c
SHA512SUM:
fedecbb2fbc3c82c7bfea325e00f983e
995ac1e171a73f64d3ca82fa759792ad
13f196858035efda5be516b90f31951f
77b6b13a53b838ce38460cf7d9fd53be
```

Compatibility

Forcepoint NGFW 6.4 is compatible with the following component versions.

- Forcepoint NGFW Security Management Center (SMC) 6.4 or higher
- Dynamic Update 1041 or higher
- Stonesoft[®] VPN Client for Windows 6.0.0 or higher
- Stonesoft[®] VPN Client for Mac OS X 2.0.0 or higher

- Stonesoft® VPN Client for Android 2.0.0 or higher
- Server Pool Monitoring Agent 4.0.0 or higher
- Forcepoint Endpoint Context Agent (ECA) 1.1.0 or higher
- Forcepoint User ID Service 1.1.0 or higher
- McAfee[®] Logon Collector 2.2 and 3.0

New features

This release of the product includes these new features. For more information and configuration instructions, see the *Forcepoint Next Generation Firewall Product Guide* and the *Forcepoint Next Generation Firewall Installation Guide*.

Redirection of HTTP and HTTPS traffic to a proxy

The NGFW Engine can now transparently redirect HTTP and HTTPS traffic to a proxy. The proxy can be onpremises or a cloud-based service, such as the Forcepoint Web Security Cloud service. The traffic does not have to be redirected through a policy-based VPN.

Improved integration of external NTP servers

You can now use external NTP servers to provide time synchronization for both the SMC Appliance and NGFW Engines. External NTP servers were previously supported only for the SMC Appliance. You can use the same NTP servers for the SMC Appliance and the NGFW Engines.

SNMP Agent enhancements

You can now use SNMP Agents when you configure SNMP for the SMC Appliance. SNMP Agents were already supported for NGFW Engines in previous versions.

You can now specify the SNMP engine ID for each NGFW Engine and for the SMC Appliance. The SNMP engine ID is a unique identifier that the SNMP Agent uses to for the NGFW Engine or the SMC Appliance.

SNMP Agents now support IPv6 addresses.



Note: If you configured SNMP for the SMC Appliance before upgrading to version 6.4, you must configure SNMP again after upgrading to version 6.4.0 or higher.

Enhancements

This release of the product includes these enhancements.

Enhancements in Forcepoint NGFW version 6.4.0

Enhancement	Description	
Improved integration of external LDAP servers and Active Directory servers	 The integration of external LDAP servers and Active Directory servers with Forcepoint NGFW has been improved. Support for the LDAPS and Start TLS protocols for securing the LDAP connection has been improved. When LDAPS or Start TLS is enabled for an LDAP Server or Active Directory Server, you can now select a TLS Profile and TLS Server Identity for the LDAP Server. 	
	 A new Authentication Method element for LDAP Authentication has been added. When LDAP Authentication is configured for a user, the user's password is checked against the user's credentials in the LDAP server that is used for user storage. LDAP Authentication can be used with the following existing features: IPsec and SSL tunnels in mobile VPNs, the SSL VPN Portal, and browser-based user authentication. 	
Improvements in browser-based user authentication	Browser-based user authentication now supports certificate-based authentication. Users can authenticate using a certificate file, or a certificate stored on a smart card, such as a Common Access Card (CAC).	
Other authentication enhancements	The Require Authorization and Timeout for Client IP Authorization options have been removed from Authentication options for Access rules. Authorization is automatically required when you add User and Authentication Method elements to the Authentication cell. The Authentication Time-Out option in the Add-Ons > User Authentication branch of the Engine Editor replaces the Timeout for Client IP Authorization option.	
Improvements in application detection	Because Access rules for application detection match traffic based on the payload of connections, the same connection can potentially match more than one rule based on the first SYN packet of the connection. Connection handling such as the use of VPNs, NAT, SSM Proxies, and TCP MSS enforcement is applied according to the initial match. When the final match is different from the initial match in a way that changes connection handling, the connection is dropped. In these cases, a log message that indicates a conflict between rules is generated.	
	Note: Due to changes in application detection, policies that use Network Applications, URL Categories, or URL Lists in the Access rules might work differently after upgrading to NGFW 6.4. Some traffic that was previously allowed might be discarded. After upgrading to NGFW 6.4 or higher, verify that your policies work as expected. For more information, see Knowledge Base article 15411.	

Enhancement	Description	
New Network Application elements of the Cloud Services type	New Network Application elements of the Cloud Services type have be added to the SMC from the Forcepoint cloud access security broker (CASB) service catalog. Including the previous Network Application elements of the Web Applications and Protocols types, there are now over 7000 Network Applications available.	
Duplicate IPv6 address detection for Layer 3 Physical Interfaces	An option for detecting duplicate IPv6 addresses has been added to the Layer 3 Physical Interface properties for NGFW Engines.	
Bootloader password for NGFW Engines	During the initial configuration, you can now specify a bootloader password for the NGFW Engine. To edit the options that appear in the bootloader, you must enter the bootloader password.	
Layer 2 Physical Interfaces on Virtual Firewalls and Master Engines that host Virtual Firewalls	You can now configure Layer 2 Physical Interfaces on Virtual Firewalls and Master Engines that host Virtual Firewalls.	
Easier deployment of NGFW Engines in Microsoft Azure	You can now deploy NGFW Engines from the Microsoft Azure cloud environment without first creating the NGFW Engine element in the Management Client. You deploy the NGFW Engines from the cloud environment, and you can monitor the NGFW Engines in the Management Client.	
Auto-scaling in Microsoft Azure	Support for auto-scaling for NGFW Engines that are deployed in Azure has been added. When the scaling feature is used, additional NGFW Engine instances are automatically created and removed, depending on traffic load. You can monitor the NGFW Engine instances in the Management Client.	
Cloud Sandbox analysis information in the external portal	Idbox analysis information You can now view analysis information in the external portal for the cloud sandbox. You must define a user name for the cloud service in the Management Client to be able to view the analysis information in t external portal.	
Auto-discovery for ECA clients	The NGFW Engine can now advertise its contact address to ECA clients. If the contact address of the NGFW Engine changes, or a new NGFW Engine is added to the network, the ECA clients are still able to connect to the NGFW Engine.	
Monitoring of Forcepoint User ID Service	You can now enable monitoring for the Forcepoint User ID Service. You can also configure that the Forcepoint User ID Service sends log data to the SMC.	
License reporting tool	There is a new tool for MSSP customers that exports all data related to licenses and NGFW Engines to a CSV file.	

Enhancements in Forcepoint NGFW version 6.4.1

Enhancement	Description
QoS throughput alerts added	An alert is now triggered when the QoS throughput limit defined for a Virtual Security Engine is exceeded.

Resolved issues

These issues are resolved in this release of the product. For a list of issues fixed in a previous release, see the Release Notes for the specific release.

Description	Role	Issue number
NGFW appliance models 1401 or 1402 might generate false alerts about the LAN NIC temperature.	FW, IPS, L2FW	NGFW-9629
If dynamic routing diagnostics are left enabled for a long time, the /spool partition on the NGFW Engine might become full.	FW	NGFW-9654
When the "Enable Session Handling" option is enabled, the time-out for browser-based user authentication might be too strict when the client is slow to respond. Authentication might remove the user too aggressively, and rules that require authentication do not match until the user re- authenticates.	FW	NGFW-9904
An issue with the drivers for a gigabit interface might cause the NGFW Engine to go offline. The related messages contain "Detected Tx Unit Hang".	FW, IPS, L2FW	NGFW-10181
The dynamic routing suite for the NGFW Engine has been updated to address the following vulnerabilities: CVE-2018-5378, CVE-2018-5379, CVE-2018-5380, and CVE-2018-5381.	FW	NGFW-10257
When the NGFW Engine processes certain types of MSRPC traffic, the NGFW Engine might write excessively to the console, which can degrade the performance of the engine. As a result, traffic handling might be interrupted, and the node might go offline.	FW, IPS, L2FW	NGFW-10300
The NGFW Engine might not associate the correct user information with connections from IPsec and SSL VPN tunnels. Because the connection might not match the correct Access rules, VPN Client connections might have intermittent issues.	FW	NGFW-10327
If there is a Multi-Link VPN with link selection based on QoS classes, policy installation fails on NGFW Engines running version 6.4.0. When you upgrade NGFW Engines that have this VPN configuration to version 6.4.0, the NGFW Engine goes to the initial configuration state.	FW	NGFW-10331
NetLink and policy-based routes that are configured in the NGFW Engine create static default route entries in the dynamic routing suite routing table, even though these routes match only part of the traffic.	FW	NGFW-10357
Two-factor authentication when authenticating using a Radius server might not work.	FW	NGFW-10471
If browser-based user authentication is enabled for a large number of interfaces, the authentication might not work.	FW	NGFW-10559
The DHCP software for the NGFW Engine has been updated to address the following vulnerability: CVE-2018-5732.	FW, IPS, L2FW	NGFW-10571

Installation instructions

Use these high-level steps to install the SMC and the Forcepoint NGFW Engines.

For detailed information, see the *Forcepoint Next Generation Firewall Installation Guide*. All guides are available for download at https://support.forcepoint.com/Documentation.



Note: The sgadmin user is reserved for SMC use on Linux, so it must not exist before the SMC is installed for the first time.



Note: If you install the SMC on Windows 10 and Windows Defender is enabled, it might take a long time to activate a dynamic update package. For more information, see Knowledge Base article 14055.

Steps

- 1) Install the Management Server, the Log Servers, and optionally the Web Portal Servers.
- Import the licenses for all components. You can generate licenses at https://stonesoftlicenses.forcepoint.com.
- 3) Configure the Firewall, IPS, or Layer 2 Firewall elements in the Management Client from the **Configuration** view.
- 4) To generate initial configurations, right-click each NGFW Engine, then select Configuration > Save Initial Configuration.

Make a note of the one-time password.

- Make the initial connection from the NGFW Engines to the Management Server, then enter the one-time password.
- 6) Create and upload a policy on the NGFW Engines in the Management Client.

Upgrade instructions

Take the following into consideration before upgrading licenses, engines, and clusters.



Note: Upgrading to version 6.4 is only supported from version 6.3 or higher. If you have a lower version, first upgrade to version 6.3.



Note: Starting from Forcepoint NGFW version 6.4, the McAfee Advanced Threat Defense feature is no longer supported. We recommend that you use Forcepoint Advanced Malware Detection instead.

 Forcepoint NGFW version 6.4 requires an updated license. The license upgrade can be requested at https://stonesoftlicenses.forcepoint.com. Install the new license using the Management Client before upgrading the software. If communication between the SMC and the license server is enabled and the maintenance contract is valid, the license is updated automatically.

- To upgrade the engine, use the remote upgrade feature or reboot from the installation DVD and follow the instructions. For detailed instructions, see the *Forcepoint Next Generation Firewall Installation Guide*.
- If you have customized the sshd_config file in the /data/config/ssh directory, you might need to manually
 update the configuration file after upgrading the engine to Forcepoint NGFW version 6.4. See Knowledge
 Base article 10461.

Known issues

For a list of known issues in this product release, see Knowledge Base article 15420.

Known limitations

This release of the product includes these known limitations.

Limitation	Description
Inspection in asymmetrically routed networks	In asymmetrically routed networks, using the stream-modifying features (TLS Inspection, URL filtering, and file filtering) can make connections stall.
Inline Interface disconnect mode in the IPS role	The <i>disconnect mode</i> for Inline Interfaces is not supported on IPS virtual appliances, IPS software installations, IPS appliance models other than IPS-6xxx, or modular appliance models that have bypass interface modules.

For information about feature-specific limitations, see the Forcepoint Next Generation Firewall Product Guide.

Find product documentation

On the Forcepoint support website, you can find information about a released product, including product documentation, technical articles, and more.

You can get additional information and support for your product on the Forcepoint support website at https://support.forcepoint.com. There, you can access product documentation, Knowledge Base articles, downloads, cases, and contact information.

Product documentation

Every Forcepoint product has a comprehensive set of documentation.

- Forcepoint Next Generation Firewall Product Guide
- Forcepoint Next Generation Firewall online Help



Note: By default, the online Help is used from the Forcepoint help server. If you want to use the online Help from a local machine (for example, an intranet server or your own computer), see Knowledge Base article 10097.

Forcepoint Next Generation Firewall Installation Guide

Other available documents include:

- Forcepoint Next Generation Firewall Hardware Guide for your model
- Forcepoint NGFW Security Management Center Appliance Hardware Guide
- Forcepoint Next Generation Firewall Quick Start Guide
- Forcepoint NGFW Security Management Center Appliance Quick Start Guide
- Forcepoint NGFW SMC API Reference Guide
- Stonesoft VPN Client User Guide for Windows or Mac
- Stonesoft VPN Client Product Guide

© 2018 Forcepoint Forcepoint and the FORCEPOINT logo are trademarks of Forcepoint. Raytheon is a registered trademark of Raytheon Company. All other trademarks used in this document are the property of their respective owners.